

[Manuals.plus](#) /

› [Foxnovo](#) /

› Foxnovo Soundbar TV Speaker User Manual

Foxnovo MX2

Foxnovo Soundbar TV Speaker User Manual

Model: MX2 | Brand: Foxnovo

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this product and retain them for future reference. Follow all warnings and instructions marked on the product.

- Do not expose this appliance to dripping or splashing.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

2. PACKAGE CONTENTS

Carefully unpack your Foxnovo Soundbar and ensure all items listed below are present and in good condition.



Image: All components included in the Foxnovo Soundbar package.

- Foxnovo Soundbar (MX2)
- Remote Control
- Power Adapter
- Optical Cable
- AUX Cable
- RCA Cable
- Mount Screws (for wall mounting)
- User Manual
- Start-up Guide

3. PRODUCT OVERVIEW

The Foxnovo Soundbar is an 80W surround sound system designed to enhance your home entertainment experience. It

features an integrated subwoofer, multiple connectivity options, and customizable equalizer modes.



Image: The Foxnovo Soundbar and its remote control.

The soundbar delivers clear and full vocal dialogues with transparent highs, wide mediums, and deep bass, providing an immersive acoustic experience. Its long cavity design creates a 3D surround sound field, with a volume reaching up to 109 dB.

UNIQUE ICE BLUE BREATHING LIGHT


Enhance the atmosphere



Image: The soundbar positioned under a television, highlighting its unique ice blue breathing light feature.

A unique ice blue breathing light follows the rhythm of the sound, enhancing the atmosphere during movie watching or music listening. This feature can be turned on or off as desired.

SOUNDBAR BUILT IN SUBWOOFER



Crisp Highs, Decent bass, Nice mids
All the volumes are here

Image: An internal diagram illustrating the soundbar's tweeter and woofer components for crisp highs, decent bass, and nice mids.

4. SETUP

4.1 Placement

- **Desktop Placement:** Place the soundbar on a stable, flat surface directly in front of your television. Ensure there is no obstruction to the front of the soundbar.
- **Wall Mounting:** The soundbar is mountable. Use the provided mount screws and follow the instructions in the separate start-up guide for secure wall installation.

4.2 Connections

The Foxnovo Soundbar offers various wired and wireless connectivity options to suit your setup. Identify the available ports on your TV or audio source and choose the appropriate connection.

WIRED & WIRELESS CONNECTION

Easily connect via Bluetooth 5.0 and HDMI ARC/OPT/COAX/AUX/USB/RCA



Bluetooth 5.0




Image: Rear panel of the soundbar displaying its various input ports.

- **HDMI ARC:** Connect an HDMI cable from the soundbar's 'ARC' port to your TV's 'HDMI ARC' port. This allows for audio return channel functionality, enabling your TV remote to control the soundbar's volume.
- **Optical:** Connect an optical cable from the soundbar's 'OPT' port to your TV's optical digital audio output.
- **AUX (3.5mm):** Connect an AUX cable from the soundbar's 'AUX' port to the 3.5mm audio output on your device (e.g., TV, phone, tablet).
- **USB:** Insert a USB drive into the 'USB' port to play audio files directly from the drive.
- **RCA:** Use the provided RCA cable to connect to devices with RCA audio outputs.
- **Coaxial:** Connect a coaxial cable from the soundbar's 'COAX' port to your TV's coaxial digital audio output.
- **Power:** Connect the power adapter to the 'DC-IN' port and then to a power outlet.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Press the 'POWER' button on the soundbar or remote control to turn the unit on or off.

5.2 Input Selection

- Press the 'INPUT' or 'MODE' button on the remote control to cycle through available input sources: Bluetooth, HDMI ARC, Optical, AUX, USB, Coaxial. The selected input will be displayed on the soundbar's LED screen.

5.3 Bluetooth Pairing

- Switch the soundbar to Bluetooth mode. The LED display will show 'BT' and flash, indicating it's in pairing mode.
- On your mobile device, enable Bluetooth and search for 'Foxnovo MX2'.
- Select 'Foxnovo MX2' to pair. Once connected, the 'BT' indicator will stop flashing.

5.4 Equalizer Modes

The soundbar features built-in DSP technology with three distinct equalizer modes to optimize audio for different content types.

3 EQUALIZER MODES OPTIMIZED

Sound for Various Content

News



Music



Movie



Image: Visual representation of the three equalizer modes: News, Music, and Movie.

- Press the 'EQ' button on the remote control to switch between modes.
- **MUSIC Mode:** Enhances deep bass, ideal for immersive music listening.
- **FILM Mode:** Provides a dynamic home cinema experience with a powerful effect.
- **TV Mode:** Optimizes sound for television programs, focusing on clear dialogue.

5.5 Volume Control

- Use the 'Volume +' and 'Volume -' buttons on the remote control or the soundbar to adjust the volume.

5.6 Ice Blue Light Control

- The unique ice blue breathing light can be toggled on or off using the dedicated button on the remote control (refer to remote diagram in start-up guide).

6. MAINTENANCE

To ensure the longevity and optimal performance of your Foxnovo Soundbar, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or aerosol cleaners, as they may damage the finish.
- **Ventilation:** Ensure that the ventilation openings are not blocked. Proper airflow prevents overheating.
- **Storage:** If storing the soundbar for an extended period, unplug it from the power outlet and store it in a cool, dry place.
- **Avoid Moisture:** Keep the soundbar away from water and excessive humidity.

7. TROUBLESHOOTING

If you encounter any issues with your Foxnovo Soundbar, refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not working	Ensure power cable is securely connected to the soundbar and a working power outlet. Try a different outlet.
No sound	Incorrect input mode; Volume too low; Cable not connected properly; TV audio settings incorrect	Select the correct input mode (e.g., HDMI ARC, Optical, Bluetooth). Increase volume. Check all audio cables are securely connected. Ensure TV audio output is set to external speakers or PCM.
Bluetooth pairing failed	Soundbar not in pairing mode; Device too far; Bluetooth interference	Ensure soundbar is in Bluetooth pairing mode (BT flashing). Move device closer to the soundbar. Turn off other Bluetooth devices nearby.
Remote control not working	Batteries low/dead; Obstruction between remote and soundbar; Remote not pointed correctly	Replace batteries. Remove any obstructions. Point the remote directly at the soundbar's sensor.

Problem	Possible Cause	Solution
Sound distortion	Volume too high; Poor audio source quality	Lower the volume. Try a different audio source to check if the issue persists.

8. SPECIFICATIONS

Detailed technical specifications for the Foxnovo Soundbar (Model MX2).

Feature	Specification
Model Name	MX2
Brand	Foxnovo
Speaker Type	Soundbar
Maximum Speaker Output Power	80 Watts
Connectivity Technology	Bluetooth 5.0, HDMI ARC, Optical, AUX, USB, Coaxial, RCA
Mounting Type	Table Mount, Wall Mountable
Product Dimensions (L x W x H)	96 x 6 x 8 cm (37.8 x 2.4 x 3.1 inches)
Item Weight	3.28 kilograms (7.23 lbs)
Components Included	Soundbar, Remote Control, Power Adapter, Cables (Optical, AUX, RCA), Mount Screws

9. WARRANTY AND SUPPORT

Foxnovo products are designed for reliability and performance. For any questions regarding product operation or if you require technical assistance, please do not hesitate to contact us via Amazon message. Our support team is ready to assist you.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question