

[Manuals.plus](#) /

› [GLIDiC](#) /

› GLIDiC TW-5200 Wireless Earbuds User Manual

GLIDiC GL-TW5200-YE

GLIDiC TW-5200 Wireless Earbuds

USER MANUAL

Product Overview

The GLIDiC TW-5200 Wireless Earbuds are designed for an enhanced audio experience, featuring Hybrid Active Noise Cancellation (ANC), multi-point connectivity, and advanced noise reduction for calls. These lightweight and compact earbuds also offer convenient functions like rapid charging, an earphone search feature, and a dedicated bass focus mode.





Image: GLiDiC TW-5200 Wireless Earbuds and their charging case in lemon yellow. The earbuds are shown separately above the closed charging case.

1. Setup

1.1 Package Contents

Before you begin, please ensure all items are present in the package:

- Earphone (Left / Right) x 1 pair
- Ear Pieces (XXS/XS/S/M/L) x 2 sets
- Charging Case x 1
- Charging Cable x 1
- Easy Guide x 1

1.2 Initial Charging

For optimal performance, fully charge your GLIDiC TW-5200 earbuds and charging case before first use.

1. Place both earbuds into the charging case, ensuring they are properly seated.
2. Connect the provided charging cable to the charging port on the case and the other end to a USB power source.
3. The indicator light on the charging case will show charging status.
4. **Rapid Charging:** A 10-minute charge provides approximately 1 hour and 50 minutes of use.

完全ワイヤレスイヤホン

TW-5200

 **GLIDiC**
グライディック

静けさを極めた Hybrid 方式の ANC
欲しい機能を凝縮し、超軽量を実現



Image: The GLIDiC TW-5200 earbuds placed inside their open charging case, illustrating how they are stored and charged.

1.3 Pairing with Your Device (Multi-Point Function)

The GLIDiC TW-5200 supports multi-point connectivity, allowing simultaneous connection to two devices.

1. First Device Pairing:

- Open the charging case. The earbuds will automatically enter pairing mode.
- On your first device (e.g., smartphone), go to Bluetooth settings and select "GLIDiC TW-5200" from the list of available devices.
- Once connected, you will hear a confirmation tone.

2. Second Device Pairing:


- After connecting to the first device, put the earbuds back into the case and close it.
- Open the case again to re-enter pairing mode.
- On your second device (e.g., laptop), go to Bluetooth settings and select "GLIDiC TW-5200".
- The earbuds will now be connected to both devices.

3. **Switching Between Devices:** The earbuds will intelligently switch audio playback between the two connected devices. If audio is playing on one device, it will pause and switch to the other device when audio starts playing there.



周囲のノイズを抑え
自分だけの音をより深く楽しめる

高度な Hybrid 方式の ANC（アクティブ
ノイズキャンセリング）機能を搭載。



接続切り替えの煩わしさを無くす

2 台のデバイスと同時に Bluetooth 接続が
できる「マルチポイント」機能を搭載。

Image: A visual representation of the multi-point function, showing the earbuds connected to both a smartphone and a laptop, indicating seamless switching between devices.

2. Operating Instructions

2.1 Active Noise Cancellation (ANC) and External Sound Capture


The GLiDiC TW-5200 features Hybrid ANC to reduce ambient noise and an External Sound Capture function to let you hear your surroundings.

- **Hybrid ANC:** Activates to minimize background noise, providing a quieter listening experience. Ideal for noisy environments.
- **External Sound Capture:** Allows you to hear ambient sounds without removing your earbuds, useful for conversations or being aware of your surroundings.
- **Switching Modes:** These modes can typically be toggled by a long press on one of the earbuds or via the companion app. Refer to the Easy Guide for precise controls.



周囲のノイズを抑え
自分だけの音をより深く楽しめる

高度な Hybrid 方式の ANC（アクティブ
ノイズキャンセリング）機能を搭載。



接続切り替えの煩わしさを無くす

2 台のデバイスと同時に Bluetooth 接続が
できる「マルチポイント」機能を搭載。

Image: A graphic depicting sound waves being cancelled, representing the Hybrid ANC feature of the earbuds.

2.2 Noise Reduction for Calls


Equipped with multiple microphones, the earbuds provide clear call quality by reducing ambient noise during conversations.

- During a call, the earbuds automatically activate noise reduction to ensure your voice is transmitted clearly to the other party, even in noisy environments.



迫力のある重低音も楽しむ

ボタン操作で簡単に切り替え可能な「低音重視モード」を搭載。



相手にクリアな声を届ける
こだわりの通話品質

左右 2 個ずつのマイクで、通話時の周囲の騒音を抑える「ノイズリダクション」機能を搭載。



「_____」 カナルワークス監修

極上のフィット感を追求

カスタムイヤホンメーカー「カナルワークス」監修による、独自のイヤホン形状。

Image: An illustration showing a person's head with a speech bubble, symbolizing clear voice transmission during calls thanks to noise

2.3 Sound Focus Mode (Bass Mode)


Enhance your audio experience with the dedicated Bass Sound Mode.

- This mode emphasizes bass frequencies, providing a richer and more impactful sound for music genres that benefit from strong low-end presence.
- **Activating Bass Mode:** This mode can typically be activated via a button operation on the earbuds or through a dedicated app. Refer to the Easy Guide for precise controls.



迫力のある重低音も楽しむ

ボタン操作で簡単に切り替え可能な「低音重視モード」を搭載。



相手にクリアな声を届ける
こだわりの通話品質

左右 2 個ずつのマイクで、通話時の周囲の騒音を抑える「ノイズリダクション」機能を搭載。



「 」 カナルワークス監修

極上のフィット感を追求

カスタムイヤホンメーカー「カナルワークス」監修による、独自のイヤホン形状。

Image: A close-up of an earbud with a blurred speaker cone in the background, illustrating the focus on powerful bass sound.

2.4 Earphone Search Function (Find with Tile)

Locate your earbuds easily if they are misplaced.

- The GLIDiC TW-5200 is compatible with the "Find with Tile" feature, allowing you to use the Tile app on your smartphone to find your earbuds.
- **How to Use:** Download the Tile app, pair your earbuds with the app, and use the app's features to ring your earbuds or see their last known location on a map.

ライフスタイルに寄り添う 機能も充実



小さなイヤホンでも
スマホですぐに探せる




ゲームや動画などの音と
映像のズレを解消



周囲の音を取り込むから
イヤホンを装着したまま会話できる



雨や水しぶきを気にせずに使える



10分間の充電で約1時間50分使える

Image: An icon displaying "FIND WITH tile", indicating the earbud search functionality.

2.5 Low Latency Mode

Minimize audio-visual delay for a more synchronized experience during gaming or video playback.

- This mode reduces the delay between audio and video, ensuring that sound matches the on-screen action more closely.
- **Activating Low Latency Mode:** This feature is typically activated via a specific control on the earbuds or through a companion app.

ライフスタイルに寄り添う 機能も充実



小さなイヤホンでも
スマホですぐに探せる




ゲームや動画などの音と
映像のズレを解消



周囲の音を取り込むから
イヤホンを装着したまま会話できる



雨や水しぶきを気にせずに使える



10分間の充電で約1時間50分使える

3. Maintenance

3.1 Cleaning Your Earbuds

Regular cleaning helps maintain sound quality and hygiene.

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- For ear tips, remove them from the earbuds and clean with a damp cloth, then dry thoroughly before reattaching.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

3.2 Water Resistance (IPX4)


The GLiDiC TW-5200 earbuds are rated IPX4, meaning they are resistant to splashing water from any direction.

- This rating makes them suitable for use during light rain or sweaty workouts.
- **Important:** The charging case is not water-resistant. Do not submerge the earbuds or expose them to running water.
- If the earbuds get wet, dry them completely before placing them back in the charging case to prevent damage.

ライフスタイルに寄り添う 機能も充実



小さなイヤホンでも
スマホですぐに探せる




ゲームや動画などの音と
映像のズレを解消



周囲の音を取り込むから
イヤホンを装着したまま会話できる



雨や水しぶきを気にせずに使える



10分間の充電で約1時間50分使える

Image: An icon displaying "IPX4" and a water droplet, indicating the earbuds' resistance to splashing water.

4. Troubleshooting

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Earbuds not pairing with device.	• Ensure earbuds are charged and out of the case. • Turn off and on Bluetooth on your device. • Forget "GLIDiC TW-5200" from your device's Bluetooth list and try pairing again. • Ensure no other devices are actively connected to the earbuds.
No sound from one or both earbuds.	• Check earbud battery levels. • Ensure earbuds are properly connected to your device. • Clean any debris from the earbud speaker mesh. • Try resetting the earbuds (refer to Easy Guide for specific reset instructions).
Charging case not charging.	• Ensure the charging cable is securely connected to both the case and the power source. • Try a different USB port or power adapter. • Check the charging cable for any damage.
ANC or External Sound Capture not working.	• Ensure earbuds are properly seated in your ears. • Confirm you are toggling the modes correctly (refer to Easy Guide). • Check for any firmware updates via the companion app.

5. Specifications

Feature	Detail
Model Number	GL-TW5200-YE
Brand	GLIDiC
Connectivity Technology	Wireless
Form Factor	In Ear
Special Features	Lightweight, Hybrid ANC, Multi-point function, Bass Sound Mode, Noise reduction for calls, Earphone Search Function, Rapid Charging, External Sound Capture, Low Latency Mode

Feature	Detail
Battery Type (Earbuds)	Li-Ion
Battery Type (Case)	Lithium Polymer
Material	Plastic
Water Resistance Rating	IPX4
Package Dimensions	18.7 x 9.2 x 5.2 cm
Item Weight	140 g

6. Warranty and Support

6.1 Manufacturer's Warranty

The GLIDiC TW-5200 Wireless Earbuds come with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Note: Simple style models may have a six-month warranty.

6.2 Customer Support

For any inquiries, technical assistance, or warranty claims, please contact GLIDiC customer support:

- **Chatbot Support:** Available 24 hours a day.
- **Phone and Email Support:** Available from 10:00 to 19:00 (excluding specific holidays).
- For contact details, please refer to the official GLIDiC website or the Easy Guide included with your product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question