



[Manuals.plus](#) /

› [DYRABREST](#) /

› DYRABREST Handheld Steam Cleaner User Manual

## DYRABREST HG-ZJ

# DYRABREST Handheld Steam Cleaner User Manual

Model: HG-ZJ

## 1. INTRODUCTION

---

The DYRABREST Handheld Steam Cleaner is a powerful and portable cleaning device designed for various household and automotive cleaning tasks. Utilizing high-temperature, pressurized steam, it effectively removes stubborn stains, grease, and dirt without the need for chemical detergents. Its compact design and multiple attachments make it a versatile tool for maintaining cleanliness in different environments.

## 2. SAFETY INFORMATION

---

**Please read all safety warnings and instructions carefully before using this appliance to prevent injury or damage.**

- Always ensure the steam cleaner is filled with water before turning it on. Operating without water can cause damage.
- The steam output is extremely hot (up to 266 °F / 130 °C) and under high pressure (up to 3 bar). Avoid direct contact with skin or eyes.
- The extension wand and nozzle tips will remain hot after use. Handle with care and allow to cool before storing.
- This appliance features multiple protections including anti-dry and automatic temperature control and reset for enhanced safety.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children and pets.

## 3. PACKAGE CONTENTS

---

Verify that all items listed below are included in your package:

- 1 x DYRABREST Handheld Steam Cleaner Main Unit
- 1 x Steam Hose with Independent Spray Gun
- 1 x Extended Elbow Nozzle (Wand)

- 1 x Large Brush Head (Plastic Bristle)
- 1 x Small Brush Head (Plastic Bristle)
- 1 x Small Brush Head (Wire Bristle)
- 2 x Extra Gaskets



Figure 3.1: Overview of the steam cleaner and its included accessories, highlighting the double-layer steam hose, 6-speed gear adjustment, free add water port, non-slip handle, and independent spray gun.

## 4. SETUP

### 4.1 Adding Water

1. Ensure the steam cleaner is unplugged and turned off.
2. Locate the water inlet cap on the top of the main unit.
3. Carefully open the water inlet cap.
4. Fill the water tank with clean tap water. The tank has a capacity of 500 milliliters (approximately 0.26 gallons). Do not overfill.
5. Securely close the water inlet cap.



Figure 4.1: Demonstrates the process of adding water to the steam cleaner's reservoir.

## 4.2 Attaching Accessories

1. Connect the steam hose with the spray gun to the main unit's steam outlet. Ensure it is firmly attached.
2. Choose the appropriate brush head or the extended elbow nozzle for your cleaning task.
3. Attach the selected accessory to the tip of the spray gun or the extended elbow nozzle. Ensure it clicks securely into place.



Figure 4.2: The main unit, steam hose with spray gun, extended elbow nozzle, and three brush heads are shown, illustrating how they connect for use.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Powering On and Heating

1. After filling the water tank and attaching the desired accessory, plug the power cord into a standard 110V electrical outlet.
2. Turn on the power switch located on the main unit. The indicator light will illuminate.
3. Allow the unit to heat up. The 2500W power enables quick steam preparation in approximately 10 seconds. You will hear a slight noise as it builds pressure and steam begins to emit.

### 5.2 Adjusting Steam Output

The steam cleaner features a 6-gear adjustment dial to control the cleaning force and steam output:

- Rotate the dial to select a setting from 1 to 6.

- Lower settings provide less steam, suitable for delicate surfaces.
- Higher settings (up to 6) provide maximum steam pressure (up to 3 bar) for tackling tougher stains.



Figure 5.1: The 6-gear adjustment dial allows precise control over steam intensity for various cleaning needs.

### 5.3 Cleaning Techniques

Direct the steam output towards the surface to be cleaned. For optimal results, keep the sprayer head close to the surface as temperature decreases with distance. The high temperature steam (up to 266 °F / 130 °C) and high pressure (up to 3 bar) effectively break down stubborn stains, oil, and dust.

# 3 Bar High Pressure Steam

With 229°F/105°C high temperature,  
easy to remove stubborn greasy dirt and stains.



Temperature decreases with distance, to achieve better cleaning effects,  
please keep the sprayer head close to the machine

Figure 5.2: Illustrates the powerful 3 Bar high-pressure steam, effective for removing stubborn greasy dirt and stains.



Figure 5.3: The steam cleaner effectively removes accumulated grease and grime from kitchen surfaces like range hoods. The extended elbow nozzle and 7.22 ft steam hose provide excellent reach, allowing you to clean not only surface stains but also hard-to-reach corner stains and large areas without frequently changing power outlets.

## 2.5 Meters Long Steam Tube

Convenient for cleaning, giving your more movement freedom.



Figure 5.4: The 2.5-meter long steam tube offers extended reach for cleaning, as demonstrated by the before and after comparison of a dirty air conditioner filter.



Figure 5.5: The compact and multipurpose handheld steam cleaner is suitable for a wide range of applications, including toys, sinks, car wheels, and tile grout.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your steam cleaner:

- After each use, turn off and unplug the unit. Allow it to cool completely before handling.
- Empty any remaining water from the tank.
- Wipe down the exterior of the unit and accessories with a damp cloth.
- For stubborn residue on brush heads, clean them under running water.
- Store the steam cleaner and its accessories in a dry, cool place, away from direct sunlight.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your DYRABREST Handheld Steam Cleaner, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
No steam output	No water in tank or insufficient heating time.	Ensure water tank is filled. Allow 10-50 seconds for heating.
Low steam pressure	Dial set to a low gear or mineral buildup.	Adjust the 6-gear dial to a higher setting. If persistent, descale the unit (refer to maintenance for descaling instructions, if applicable).
Water leaking from nozzle	Accessory not properly attached or worn gasket.	Ensure accessories are securely attached. Replace worn gaskets with the provided spares.
Unit not turning on	Not plugged in or power switch off.	Check power connection and ensure the power switch is in the 'ON' position.

## 8. SPECIFICATIONS

Feature	Specification
Brand	DYRABREST
Model Name	Steam Cleaner Machine (HG-ZJ)
Power Source	Corded Electric
Voltage	110 Volts
Wattage	2500 watts
Tank Volume	0.26 Gallons (500 Milliliters)
Maximum Temperature	130 Degrees Celsius (266 °F)
Steam Pressure	Up to 3 Bar
Product Dimensions (D x W x H)	7.48"D x 5.9"W x 5.12"H
Item Weight	3.78 pounds
Color	White



Figure 8.1: Detailed dimensions of the steam cleaner unit.

## 9. WARRANTY & SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or contact DYRABREST customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.