

[Manuals.plus](#) /

› [PERFASCIN](#) /

› PERFASCIN R11CG/E Universal Replacement Remote Control for Midea R11 Air Conditioner User Manual

PERFASCIN R11CG/E

PERFASCIN R11CG/E Universal Replacement Remote Control User Manual

For Midea R11 Series Air Conditioners

INTRODUCTION

This manual provides instructions for the PERFASCIN R11CG/E Universal Replacement Remote Control. This remote is designed to be compatible with various Midea R11 series air conditioner models, including R11CG/E, R11CG-E, R11HG-E, R11HG/E, and R11HQ/E. It functions as a direct replacement without requiring any programming or pairing.

SETUP

Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery compartment with cover removed.

Initial Use

No programming or pairing is required for this universal replacement remote. Once batteries are correctly installed, the remote is ready for use with compatible Midea R11 series air conditioners.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions as shown in the diagram below.





Figure 2: Front view of the remote control with button layout.

Button Functions

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **FAN SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TEMP ▲/▼:** Increases or decreases the set temperature.
- **AIR DIRECTION:** Adjusts the direction of the airflow.
- **SWING:** Activates or deactivates the automatic swing function of the air conditioner's louvers.
- **OK:** Confirms selections or settings.
- **TIMER ON:** Sets a timer for the air conditioner to turn on.
- **TIMER OFF:** Sets a timer for the air conditioner to turn off.
- **CLOCK:** Sets the current time on the remote's display.
- **CANCEL:** Cancels current timer settings or other operations.
- **TIME ADJUST ▲/▼:** Used to adjust time settings for the CLOCK or TIMER functions.
- **ECONOMIC RUNNING:** Activates or deactivates an energy-saving mode (if supported by the air conditioner).

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote stops responding. Always replace both batteries simultaneously with new AAA alkaline batteries.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the device. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.





Figure 3: Back label with important battery information.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control does not work.	Batteries are dead or incorrectly installed.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote control signal is weak or intermittent.	Obstruction between remote and air conditioner. Low battery power.	Ensure a clear line of sight to the air conditioner's receiver. Replace batteries.
Air conditioner does not respond to specific functions.	Function not supported by the specific air conditioner model.	Refer to your air conditioner's manual to confirm supported functions.

If you encounter issues not covered here or require further assistance, please contact customer service for professional suggestions.

SPECIFICATIONS

- **Model Number:** ANG-MBE950-R11HGE-R11CGE-US
- **Compatible Remote Models:** R11CG/E, R11CG-E, R11HG-E, R11HG/E, R11HQ/E
- **Compatible Air Conditioner Brand:** Midea R11 Series
- **Connectivity Technology:** Infrared (IR)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Rated Voltage:** 3VDC
- **Product Dimensions:** 7 x 2 x 0.65 inches (approximately)
- **Item Weight:** 2.3 ounces (approximately)

SUPPORT

For any questions or concerns regarding your PERFASCIN R11CG/E Universal Replacement Remote Control, please do not hesitate to contact our customer service team. We are available to provide professional assistance.

© 2023 PERFASCIN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BL11R6NG>

More documents and user manuals: **<https://manuals.plus/>**