

Linsoul TANGZU Wan'er S.G

Linsoul TANGZU Wan'er S.G HiFi In-Ear Earphone User Manual

Model: TANGZU Wan'er S.G | Brand: Linsoul

1. INTRODUCTION

The Linsoul TANGZU Wan'er S.G in-ear earphones are designed to deliver a high-fidelity audio experience. Featuring a 10mm dynamic driver with a PET diaphragm, these earphones offer a balanced and musical sound signature. The ergonomic design ensures a comfortable fit for extended listening sessions. This manual provides essential information for the proper setup, operation, and maintenance of your Wan'er S.G earphones.

What's in the Box:

- Wan'er S.G In-Ear Monitor
- 6 Pairs Silicone Eartips (various sizes)
- Custom Wan'er S.G Cable
- Exquisite Ancient Portraits (packaging)



Package List:

- | | |
|-----------------------------|-------------------------------|
| 1 Wan'er S.G In Ear Monitor | 2 6 Pairs Silicone Eartips |
| 3 Custom Wan'er S.G Cable | 4 Exquisite Ancient Portraits |

Figure 1.1: Contents of the Wan'er S.G package, including the earphones, various silicone eartips, the custom cable, and the decorative packaging.

2. SETUP

2.1 Attaching the Cable

The Wan'er S.G earphones feature a detachable 0.78mm 2-pin cable. This allows for easy replacement or upgrade. To attach the cable:

1. Identify the left (L) and right (R) earpieces and the corresponding connectors on the cable. The cable connectors are typically marked.
2. Align the 2-pin connector on the cable with the recessed socket on the earpiece. Ensure the pins are correctly oriented.
3. Gently push the connector into the socket until it is firmly seated. Do not force the connection.

4. Repeat for the other earpiece.

Package List:

- 1 Wan'er S.G In Ear Monitor
- 2 6 Pairs Silicone Eartips
- 3 Custom Wan'er S.G Cable
- 4 Exquisite Ancient Portraits



Figure 2.1: Illustration of the detachable 2-pin cable connection, highlighting the 5N high-purity OFC cable and the recessed 2-pin connector.

2.2 Selecting and Installing Eartips

Proper eartip selection is crucial for sound quality and comfort. Experiment with the included silicone eartips to find the best fit for your ears.

1. Gently remove the pre-installed eartips by twisting and pulling.
2. Select a pair of eartips that feel comfortable and create a good seal in your ear canal. A good seal is essential for optimal bass response and passive noise isolation.
3. Push the new eartip onto the nozzle of the earpiece until it is securely attached.

2.3 Wearing the Earphones

The Wan'er S.G earphones are designed for an over-ear fit, which provides stability and reduces microphonics (cable noise).

1. Insert the earpieces into your ear canals.
2. Guide the cable over the top of your ear, wrapping it around the back.
3. Adjust the earpieces and cable until they feel secure and comfortable.



Transparent Shell Insight

Reveal Internal
Craftsmanship



Cultural Pattern Fusion

Oriental Aesthetics
in Design



Put Ease for Daily Use

Full-transparent shells reveal the precise
internal structure. The patterns blending
Eastern aesthetics into design.

Figure 2.2: An illustration demonstrating the ergonomic fit of the Wan'er S.G earphone when worn, with the cable routed over the ear for stability.

3. OPERATING INSTRUCTIONS

3.1 Connecting to an Audio Source

The Wan'er S.G earphones connect to your audio device via a standard 3.5mm jack.

1. Ensure the 3.5mm audio plug is fully inserted into the headphone jack of your smartphone, digital audio player, computer, or other compatible device.
2. Start audio playback on your device.
3. Adjust the volume on your audio source to a comfortable listening level.

Note: This model (Black, Without Mic) does not include inline controls for volume or playback. All controls must be

managed directly from your connected audio device.

4. MAINTENANCE

4.1 Cleaning the Earphones

Regular cleaning helps maintain hygiene and sound quality.

- **Earpieces:** Gently wipe the earpieces with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Eartips:** Remove the silicone eartips and wash them with mild soap and water. Rinse thoroughly and allow them to air dry completely before reattaching.
- **Nozzles:** Use a small, soft brush (like a clean toothbrush) to carefully remove any earwax or debris from the earpiece nozzles. Do not push debris further into the nozzle.

4.2 Cable Care

To prolong the life of your cable:

- Avoid sharp bends or kinks in the cable.
- Store the cable neatly coiled when not in use.
- Do not pull the cable directly to disconnect; always grasp the plug.

4.3 Storage

Store your earphones in a clean, dry place, away from extreme temperatures and direct sunlight. Using a small carrying case can protect them from dust and physical damage.

5. TROUBLESHOOTING

If you encounter issues with your Wan'er S.G earphones, please refer to the following common solutions:

Problem	Possible Cause	Solution
No sound or low volume	Cable not fully connected; incorrect eartip seal; audio source volume too low; audio source not playing.	Ensure cable is securely attached to both earpieces and audio source. Adjust eartips for a proper seal. Increase volume on your audio device. Verify audio playback on your device.
Distorted sound	Audio source volume too high; damaged cable or earpiece; debris in nozzle.	Lower the volume on your audio device. Inspect cable and earpieces for visible damage. Clean earpiece nozzles as described in Maintenance. Try with a different audio source or cable if available.

Problem	Possible Cause	Solution
Uncomfortable fit or falling out	Incorrect eartip size; improper wearing technique.	Experiment with different eartip sizes to find the most comfortable and secure fit. Ensure the cable is routed over your ear.
Sound only from one side	Loose cable connection; damaged cable; audio balance settings.	Check both 2-pin connections and the 3.5mm jack. Try swapping the cable (if you have a spare) or checking audio balance settings on your device.

If the problem persists after attempting these solutions, please contact Linsoul customer support for further assistance.

6. SPECIFICATIONS

The following table outlines the technical specifications for the Linsoul TANGZU Wan'er S.G in-ear earphones:



Figure 6.1: Technical specifications of the Wan'er S.G earphones, including impedance, frequency range, sound pressure level, and distortion rate.

Feature	Specification
Model Name	TANGZU Wan'er S.G

Feature	Specification
Driver Type	10mm Dynamic Driver
Diaphragm Material	PET
Impedance	20 Ohm
Sensitivity	107 dB
Frequency Range	20 Hz - 20 kHz
Headphones Jack	3.5 mm Jack
Connectivity Technology	Wired
Cable Feature	Detachable 0.78mm 2-Pin, 5N OFC Braided Cable
Cable Length	1.2 Meters
Noise Control	Passive Noise Cancellation
Material	Plastic
Item Weight	5.6 ounces

7. WARRANTY AND SUPPORT

Linsoul products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the documentation provided with your purchase or visit the official Linsoul website.

For technical support, troubleshooting assistance beyond what is covered in this manual, or inquiries about replacement parts, please contact Linsoul customer service. You can typically find contact information on the Linsoul website or through your point of purchase.

Linsoul Store: [Visit the Linsoul Store on Amazon](#)

Related Documents

Warranty & Return Policy

Our 1-Year Warranty

At Linsoul, we stand behind the quality of our products. We offer a 1-year warranty on all Linsoul products. If you have any issues with your product, please contact our customer support team for assistance.

The warranty covers manufacturing defects and material issues. It does not cover damage caused by misuse, accidents, or unauthorized repairs. For more details, please refer to the full warranty policy.

Our 30-Day Return Policy

We offer a 30-day return policy for all Linsoul products. If you are not satisfied with your purchase, you can return it for a full refund within 30 days of purchase. The product must be in its original condition and packaging.

Exclusions and Limitations

Some products may have specific warranty terms. Please check the individual product pages for details. The warranty is void if the product is damaged, altered, or used for commercial purposes.

For more information, please visit our website or contact our customer support team. We are committed to ensuring your satisfaction with every purchase.

[Linsoul Warranty & Return Policy](#)

Details Linsoul's 30-day return policy and 1-year warranty for earphones, headphones, and accessories, including exclusions and claim procedures.