

- › [Logitech](#) /
- › [Logitech MK470 Slim Wireless Keyboard and Mouse Combo User Manual](#)

## Logitech MK470

# Logitech MK470 Slim Wireless Keyboard and Mouse Combo User Manual

Model: MK470

## 1. INTRODUCTION

The Logitech MK470 Slim Wireless Keyboard and Mouse Combo offers a minimalist, modern, and slim design for efficient and quiet work. This ultra-thin duo is designed to enhance your desk setup with its sleek profile and reliable wireless connectivity. It provides a comfortable and quiet typing and clicking experience, making it ideal for various computing environments.



Figure 1: Logitech MK470 Slim Wireless Keyboard and Mouse Combo.

## 2. WHAT'S IN THE BOX

Your Logitech MK470 Slim Wireless Keyboard and Mouse Combo package includes the following items:

- MK470 Keyboard & Mouse
- 2 x AAA Batteries (Pre-Installed)
- 1 x AA Battery (Pre-Installed)
- USB Receiver
- User Documentation





Figure 2: Contents included with your MK470 Combo.

## 3. SETUP

### 3.1. Battery Installation

The keyboard requires two AAA batteries, and the mouse requires one AA battery. These batteries are typically pre-installed. If replacement is needed, carefully open the battery compartments as shown in the figures below.



## Compatibility



Figure 3: Keyboard battery compartment with AAA batteries.




Figure 4: Mouse battery compartment with AA battery and USB receiver.

### 3.2. USB Receiver Connection

Locate the USB nano receiver, usually stored inside the mouse's battery compartment or within the product packaging. Plug this receiver into an available USB port on your computer. The combo is designed for plug-and-play connectivity, meaning no additional software installation or manual pairing is typically required for basic functionality.

# RELIABLE WIRELESS CONNECTIVITY



Figure 5: Connecting the USB receiver for reliable wireless connectivity.

## 4. OPERATING

### 4.1. Keyboard Features

The MK470 keyboard features low-profile scissor keys for a comfortable and quiet typing experience. It includes a full number pad and a layout optimized for Windows operating systems. For enhanced productivity, the keyboard offers 12 customizable FN keys. These can be configured using the Logi Options software to assign shortcuts tailored to your needs.




Figure 6: Compact keys with numpad for efficient input.

#### 4.2. Mouse Features

The accompanying mouse is ambidextrous with a comfortable 3-button design. It utilizes high-precision optical tracking for smooth and accurate cursor control, complemented by a mechanical scroll wheel. Both the keyboard and mouse are designed for ultra-quiet operation, minimizing noise in your workspace.





Figure 7: The ultra-slim and quiet design of the combo.

### 4.3. Wireless Connectivity

The combo utilizes a strong and reliable 2.4 GHz wireless connection, offering an operating distance of up to 10 meters (33 feet). Wireless range may vary based on environmental and computing conditions.

## 5. MAINTENANCE

### 5.1. Cleaning

To maintain the appearance and functionality of your keyboard and mouse, gently wipe them with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

### 5.2. Battery Life and Replacement

The auto-sleep feature helps conserve battery life, allowing for up to 36 months of keyboard use and 18 months of mouse use. Actual battery life may vary based on user and computing conditions. When batteries need replacement, refer to section 3.1 for instructions on accessing the battery compartments.

# LONG-LASTING COMBO



Figure 8: Long-lasting battery performance of the combo.

## 6. TROUBLESHOOTING

### 6.1. Connectivity Issues

If you experience intermittent connectivity or unresponsiveness, try the following:

- Ensure the USB receiver is securely plugged into a working USB port.
- Try plugging the USB receiver into a different USB port.
- Ensure the keyboard and mouse are within the 10-meter (33-foot) operating range of the receiver.
- Check and replace the batteries in both the keyboard and mouse if they are low.

### 6.2. Lag or Delayed Response

If you notice lag or delayed response, especially with the mouse, it often indicates low battery power. Replace the batteries in the affected device. Environmental factors or interference from other wireless devices can also cause this; try moving the receiver or the devices to a different location.



### 6.3. Software and Customization

For advanced customization of the FN keys and other settings, download and install the Logi Options software from the official Logitech website. If you encounter issues with software features, ensure your software is up to date.

## 7. SPECIFICATIONS

Feature	Specification
Brand	Logitech
Model Number	920-011311
Keyboard Dimensions (LxWxH)	14.7 x 5.6 x 0.76 inches (373.5 x 143.9 x 19.4 mm)
Keyboard Weight (incl. battery)	19.9 oz (566 g)
Mouse Dimensions (LxWxH)	4.2 x 2.3 x 1 inches (107 x 59 x 26.5 mm)
Mouse Weight (incl. battery)	3.5 oz (100 g)
Keyboard Battery Life	Up to 36 months
Mouse Battery Life	Up to 18 months
Wireless Technology	2.4 GHz USB Receiver
Wireless Range	10 m (33 ft)
Platform Compatibility	Windows 10 or later, Windows 8, Windows 7, Chrome OS, Surface




Figure 9: Keyboard dimensions.



Figure 10: Mouse dimensions.

## 8. WARRANTY AND SUPPORT

Logitech products are manufactured to high quality standards and are designed to provide years of reliable performance. For detailed warranty information and support, please refer to the official user documentation included in your package or visit the [Logitech Store on Amazon](#). You can also find the User Guide (PDF) [here](#).