



[Manuals.plus](#) /

> [Zinus](#) /

> Zinus Suzanne Steel & Wood Bed Frame (Model AJ-IRPF-6S) Instruction Manual

Zinus AJ-IRPF-6S

Zinus Suzanne Steel & Wood Bed Frame (Model AJ-IRPF-6S) Instruction Manual

Model: AJ-IRPF-6S

INTRODUCTION

Thank you for purchasing the Zinus Suzanne Steel & Wood Bed Frame. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The Zinus Suzanne Steel & Wood Bed Frame, showcasing its steel frame and natural wood accents.

IMPORTANT SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Ensure all bolts and screws are securely tightened before use. Periodically check and retighten as necessary.
- Do not jump on the bed frame.
- Distribute weight evenly across the bed frame. Avoid concentrating heavy loads on a single point.
- Use a mattress with a minimum thickness of 5.9 inches (15 cm) to ensure proper support and extend product life.
- Assembly is recommended for two adults.

SETUP AND ASSEMBLY

The Zinus Suzanne Bed Frame is designed for straightforward assembly. All necessary tools are included. Estimated assembly time is 15-30 minutes for two adults.

Before You Begin:

1. **Unpack all components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface (e.g., a carpet or blanket) to prevent scratches.
2. **Verify all parts:** Compare the contents with the parts list provided in your package. Ensure all hardware and frame components are present. Note that some screw parts may be pre-attached to the main unit; check these before assembly.
3. **Gather tools:** The required assembly tools are included in the package.

Assembly Steps:

Follow the step-by-step instructions provided in the separate assembly guide included with your product. Generally, assembly involves:

- Attaching the side rails to the headboard and footboard (if applicable).
- Installing the center support beam and legs.
- Placing the wooden slats onto the frame.
- Securing all connections with the provided hardware.



Image: An example of bed frame components, illustrating the parts involved in assembly.

Once assembled, ensure the frame is stable and all fasteners are tight before placing your mattress on it.

OPERATION AND USAGE

The Zinus Suzanne Bed Frame is designed to provide a stable and comfortable foundation for your mattress. Proper usage ensures longevity and safety.

- **Mattress Compatibility:** This frame is designed for use with a standard single-size mattress. A mattress thickness of at least 5.9 inches (15 cm) is recommended.
- **Weight Capacity:** The bed frame has a maximum weight recommendation of 180 kilograms (approximately 396 pounds), including the mattress and occupants. Do not exceed this limit.
- **Even Weight Distribution:** Avoid placing excessive weight on specific areas of the frame. Distribute weight as evenly as possible.
- **Movement:** When moving the bed, lift it rather than dragging it to prevent damage to the frame or your flooring.

MAINTENANCE

Regular maintenance will help preserve the condition and extend the lifespan of your Zinus bed frame.

- **Cleaning:** Wipe the frame with a dry cloth to remove dust and debris. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Fastener Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any that have become loose to maintain stability and prevent squeaking.
- **Slat Inspection:** Check the wooden slats for any signs of damage or excessive wear. Replace any broken slats immediately to ensure proper mattress support.

TROUBLESHOOTING

If you encounter issues with your bed frame, refer to the following common solutions:

- **Squeaking Noises:**
 - Ensure all bolts and screws are securely tightened. Loose connections are a common cause of squeaking.
 - Check if the slats are properly seated and not rubbing against the frame.
 - Verify that the bed frame is on a level surface.
- **Instability/Wobbling:**
 - Re-check all assembly connections and tighten any loose hardware.
 - Ensure all support legs are firmly on the floor.
- **Damaged Parts:** If any part is damaged or missing upon arrival, do not proceed with assembly. Contact Zinus customer support for assistance.

SPECIFICATIONS

Model Number	AJ-IRPF-6S
Brand	Zinus
Product Type	Bed Frame
Size	Single (Width 38.2 in / 97 cm x Depth 77.8 in / 195 cm x Height 6.1 in / 15.5 cm)
Material	Alloy Steel, Plywood, Pine Wood, PE Resin
Color	Brown (Wood), Black (Steel)
Item Weight	16 kg (35.2 lbs)
Maximum Weight Recommendation	180 kg (396 lbs)
Under Bed Storage Height	3.4 inches (8.6 cm)
Assembly Required	Yes

Product Care	Wipe with Dry Cloth
--------------	---------------------

WARRANTY INFORMATION

Zinus offers a **5-year limited warranty** against initial defects in materials and manufacturing defects for the Suzanne Steel & Wood Bed Frame. This warranty covers defects in workmanship and materials under normal use and service. Please retain your proof of purchase for warranty claims.

For full warranty terms and conditions, please refer to the documentation included with your product or visit the official Zinus website.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Zinus customer support.

Please have your model number (AJ-IRPF-6S) and proof of purchase ready when contacting support.

For contact information, please refer to the Zinus official website or the documentation included in your product packaging.