



[Manuals.plus](#) /

> [PERFASCIN](#) /

> PERFASCIN CXE9605 Replacement Remote Control User Manual for Pioneer Car Stereos

## PERFASCIN ANG-MBE945-CXE9605-US

# PERFASCIN CXE9605 Replacement Remote Control User Manual

For Pioneer DEH-X, DEH-S, and MVH-S Series Car Stereos

## 1. INTRODUCTION

---

This manual provides instructions for the PERFASCIN CXE9605 replacement remote control. This remote is designed to function with various Pioneer car stereo models, offering convenient control over your audio system. No programming or pairing is required for operation.

## 2. PRODUCT OVERVIEW

---

The CXE9605 remote control features an ergonomic design with clearly labeled buttons for intuitive use. It operates using infrared (IR) technology.



Image 2.1: Front view of the CXE9605 remote control, displaying its button layout.

### Compatible Models:

This remote is compatible with the following Pioneer car stereo models:

- DEH-X4900BT, DEH-S4000BT, DEH-X3910BT, DEH-X3900BT
- DEH-S5000BT, DEH-S5010BT, DEH-S6000BS, DEH-S6010BS
- DEH-X6900BT
- FH-S500BT, FH-S501BT, FH-S700BS, FH-S701BS
- FXT-X7269BT
- MVH-S300BT, MVH-S301BT, MVH-S400BT, MVH-S501BS, MVH-S600BS
- MVH-X390BT, MVH-X690BS, MVH-X691BS

## 3. SETUP

### Battery Installation:

The remote control requires two (2) AAA alkaline batteries for operation. No programming or pairing is necessary after battery installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.

3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.






Image 3.1: Back view of the remote control, illustrating the battery compartment and proper battery insertion.

## 4. OPERATING INSTRUCTIONS

---

Point the remote control directly at the infrared receiver on your Pioneer car stereo. Ensure there are no obstructions between the remote and the stereo.

### Button Functions:

- **VOLUME +/-:** Adjusts the audio volume level.
- **MUTE:** Silences or restores the audio output.
- **BAND/ESC:** Changes the radio band (e.g., FM1, FM2, AM) or exits a menu/function.
- **DISC/P.CH (Up/Down Arrows):** Navigates between discs or preset channels.
- **TRACK/SEEK (Left/Right Arrows):** Skips tracks, fast forwards/rewinds, or seeks radio stations.
- **LIST/ENTER (Center Button):** Confirms selections or accesses lists/menus.
- **SRC (Source):** Changes the audio source (e.g., Radio, CD, USB, Bluetooth).
- **Play/Pause (II):** Plays or pauses media playback.
- **Call Answer/End (Phone Icons):** Manages phone calls when connected via Bluetooth.
- **DISP (Display):** Changes the information shown on the stereo's display.
- **SCRL (Scroll):** Scrolls through text or menu options.

## 5. MAINTENANCE

---

To ensure optimal performance and longevity of your remote control:

- Keep the remote clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote to extreme temperatures, direct sunlight, or moisture.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- Do not attempt to disassemble the remote control.

## 6. TROUBLESHOOTING

---

### Remote Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new AAA alkaline batteries.
- **Line of Sight:** Verify there are no objects blocking the path between the remote control and the car stereo's infrared receiver.
- **Distance:** Ensure you are within the effective operating range (approximately 10 meters or 33 feet).
- **Stereo Power:** Confirm that your Pioneer car stereo is powered on.

## 7. SPECIFICATIONS

---

Brand	PERFASCIN
-------	-----------

<b>Model Name</b>	ANG-MBE945-CXE9605-US
<b>Connectivity Technology</b>	Infrared (IR)
<b>Compatible Devices</b>	Pioneer Car Stereos (DEH-X, DEH-S, MVH-S series)
<b>Power Source</b>	2 x AAA Batteries (not included)
<b>Button Quantity</b>	20
<b>Maximum Range</b>	10 Meters (33 feet)
<b>Special Feature</b>	Ergonomic Design

## 8. SUPPORT

---

If you encounter any issues or have questions regarding the PERFASCIN CXE9605 replacement remote control, please contact our customer service for assistance. We are available to provide professional suggestions and support. *Contact information is typically provided by your retailer or on the product packaging.*