

Babymoov A035219_US

Babymoov Babyni Anti-UV Pop-Up Tent Instruction Manual

Model: A035219_US

INTRODUCTION

This manual provides instructions for the safe and effective use of your Babymoov Babyni Anti-UV Pop-Up Tent. This portable baby sun shelter is designed to offer UPF 50+ sun protection and includes a mosquito net for outdoor use.

Key features include:

- **UPF 50+ Sun Protection:** Blocks over 99% of harmful UVA and UVB rays.
- **Instant Pop-Up Setup:** Designed for quick deployment.
- **Lightweight & Travel-Friendly:** Easy to transport and store.
- **Built-In Mosquito Protection:** Detachable fine mesh net for insect deterrence.
- **Versatile Outdoor Shelter:** Provides a shaded space for babies and toddlers.

SAFETY INFORMATION

WARNING:

- Use with adult supervision only.
- Do not use as a sleep device.
- Ensure the tent is securely anchored to prevent tipping, especially in windy conditions.
- Always check the internal temperature of the tent to prevent overheating, particularly on hot days.

SETUP INSTRUCTIONS

1. **Unfolding the Tent:** Remove the tent from its carry bag. The tent is designed to pop open automatically. Gently guide the frame into its full shape.
2. **Attaching the Mosquito Net:** The fine mesh mosquito net can be attached using the integrated Velcro fasteners around the tent's perimeter. Ensure it is securely fastened to keep insects out.
3. **Positioning:** Place the tent on a flat, stable surface. For outdoor use, especially on beaches or grassy areas, consider using sand or other weights to secure the tent against wind.

UPF 50+ Fabric
Blocks 99%
of UV rays.

Fine Mesh Netting
Keeps bugs out.



Easy Pop-Up
Set up and pack
down in seconds.

Carry Bag
Included

Image: The Babymoov Babyni tent shown with its detachable mosquito net and compact carry bag.

OPERATING INSTRUCTIONS

The Babyni tent provides a safe and shaded environment for your baby.

- **Sun Protection:** The tent's UPF 50+ fabric offers high protection against harmful UV rays. Position the tent to maximize shade for your child.
- **Mosquito Protection:** When needed, ensure the mosquito net is fully attached and zipped (if applicable) to protect your child from insects.
- **Ventilation:** The tent is designed with airflow in mind. However, always monitor your child for signs of overheating, especially on warm days.
- **Play Area:** The enclosed design creates a comfortable space for your baby to play or rest.



UPF 50+ Rated Fabric
Blocks 99% of harmful UVA & UVB rays.

Image: A baby enjoying the shade inside the Babymoov Babyini tent on a beach.

Lets The Breeze In, Keeps Bugs Out



Image: The Babymoov Babyni tent positioned poolside, offering shade.

FOLDING AND STORAGE

Folding the pop-up tent requires a specific technique to return it to its compact size. Follow these steps carefully:

1. Lay the tent flat on the ground.
2. Bring the opposite sides of the tent together.
3. Twist the tent into a figure-eight shape, then fold it into a compact circle.
4. Secure with the attached elastic band or strap.
5. Place the folded tent into its carry bag for storage.



Image: The Babymoov Babyni tent folded into its compact carry bag, being carried.

Folding Demonstration Video

Your browser does not support the video tag.

Video: A detailed demonstration on how to properly fold the Babymoov Babyni Baby Tent for storage.

MAINTENANCE

- **Cleaning:** Spot clean the tent fabric with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow the tent to air dry completely before folding and storing to prevent mold or mildew.
- **Storage:** Store the tent in its original carry bag in a cool, dry place away from direct sunlight when not in use.

TROUBLESHOOTING

- **Difficulty Folding:** Refer to the 'Folding and Storage' section and the instructional video for a visual guide. Practice

the twisting motion.

- **Tent Instability:** Ensure the tent is placed on a flat surface. For outdoor use, secure the tent with sand, rocks, or other weights around the base to prevent it from being moved by wind.
- **Mosquito Net Not Staying Attached:** Check that all Velcro fasteners are clean and properly aligned.

SPECIFICATIONS

Feature	Detail
Model Number	A035219_US
Item Weight	1.2 Pounds
Item Dimensions (L x W x H)	37.4"L x 29.5"W x 19.7"H
Size	Small
Coverage	UPF 50+ Sun Protection with Built-In Mosquito Net
Recommended Uses	Beach, Travelling
Required Assembly	Yes (Pop-up design)
Material Type	Polyester
Frame Material	Aluminum, Fiberglass
Ultraviolet Light Protection	UPF 50+
Water Resistance Level	Not Water Resistant
Frame Type	Round
Closure Type	Velcro
Color	Marine
Included Components	Mat and carry bag

WARRANTY INFORMATION

The Babymoov Babyni Anti-UV Pop-Up Tent comes with a**Lifetime Warranty** from the manufacturer. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, product inquiries, or warranty claims, please contact Babymoov customer service. Visit the official Babymoov website for contact details and additional resources.

You can find more information and support at the[Babymoov Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question