

[Manuals.plus](#) /

› [Victrola](#) /

› Victrola Stream Onyx - Wi-Fi Streaming 2-Speed Turntable with Bluetooth Output, Works with Sonos, UPnP Wi-Fi Streaming, Roon Ready Relay, Premium Moving Magnet Cartridge and Aluminum Tonearm (Black) Onyx Stream (works with Sonos) User Manual

Victrola VPT-2000-BLK-ATE

Victrola Stream Onyx Turntable User Manual

Model: VPT-2000-BLK-ATE

Brand: Victrola

INTRODUCTION

The Victrola Stream Onyx is a versatile 2-speed turntable designed for both traditional vinyl playback and modern wireless streaming. It offers seamless integration with Sonos systems, Bluetooth output, UPnP Wi-Fi streaming, and Roon Ready Relay support, providing multiple options for enjoying your vinyl collection. Its robust construction, including a belt-driven metal platter and low-resonance MDF plinth, ensures high-fidelity sound reproduction. This manual provides essential information for setting up, operating, and maintaining your Victrola Stream Onyx turntable.

1. SETUP

1.1 Unpacking and Component Check

Carefully remove all components from the packaging. Ensure all items listed below are present:

- Turntable Unit
- Manual
- Power Cord
- 45 RPM Adaptor
- Dust Cover
- Counterweight
- Platter
- Silicone Slipmat
- Audio Technica AT-VM95E Cartridge (pre-installed or included)
- Gold-Plated RCA Cables
- 6-foot Grounded Phono Cable

1.2 Placement

Place the turntable on a stable, level surface away from direct sunlight, heat sources, and excessive vibrations. Ensure adequate ventilation around the unit.

1.3 Assembly

Follow these steps to assemble your turntable:

1. Place the metal platter onto the turntable spindle.
2. Carefully install the drive belt around the motor pulley and the inner rim of the platter.
3. Place the silicone slipmat on top of the platter.
4. Attach the counterweight to the rear of the tonearm and adjust according to the included quick start guide for optimal tracking force.
5. Ensure the Audio-Technica AT-VM95E cartridge is securely attached to the tonearm's removable headshell.

PREMIUM AUDIO CARTRIDGE

Features an Audio Technica AT-VM95E cartridge for high-fidelity sound



INNOVATIVE COUNTERWEIGHT

One step setup eliminates the need for tonearm balancing

Image: Premium Audio Cartridge and Innovative Counterweight for precise tracking.

BELT-DRIVEN DESIGN

2-speed turntable plays all your favorite 33 1/3, and 45 rpm vinyl records



ILLUMINATED CONTROL KNOB

Control Sonos volume and playback groups directly from the turntable

Image: Illustration of the belt-driven mechanism and the illuminated control knob.

1.4 Power Connection

Connect the power cord to the turntable's power input and then to a suitable wall outlet.

1.5 Connecting to Audio System

The Victrola Stream Onyx offers multiple connectivity options:

- **Sonos (Wi-Fi Streaming):** Download the Victrola Stream app from your device's app store. Follow the in-app instructions to connect your turntable wirelessly to your Sonos system. This allows seamless streaming of vinyl to any Sonos speaker in your home.
- **Bluetooth Output:** Activate Bluetooth pairing mode on the turntable and your desired Bluetooth speaker, soundbar, or headphones. Select the Victrola Stream Onyx from your device's Bluetooth list to establish a connection.
- **UPnP Wi-Fi Streaming & Roon Ready Relay:** For expanded Wi-Fi speaker compatibility, utilize UPnP streaming. The turntable is also Roon Ready, allowing streaming to any Roon endpoint. Refer to the Victrola Stream app for detailed setup.
- **Wired RCA Output:** Use the included gold-plated RCA cables to connect the turntable's RCA output to the phono input of

your amplifier or powered speakers. Ensure your amplifier has a phono pre-amp or use an external one.

- **RJ45 Ethernet Port:** For a stable wired network connection to your Sonos system, connect an Ethernet cable from the turntable to your network router.

CONNECT WITHOUT COMPROMISE

The Victrola Stream app provides easy setup and connects the Victrola Stream Carbon and Onyx model wirelessly to your Sonos system in seconds. Once set up, the turntable fully integrates with the Sonos app.



STEP 01


Download the Victrola Stream app for a step by step installation guide.



Effortlessly download our app directly from the Apple app store or Google Play stores.

STEP 02

Connect your Victrola Stream Turntable to your Sonos System.



Follow the self guided set-up and seamlessly connect your turntable directly to your Sonos system.

STEP 03

Start streaming directly from your Victrola Stream Turntable.



Wirelessly stream your records throughout your home using the Sonos app.

Image: Easy setup and wireless connection to Sonos via the Victrola Stream app.

2. OPERATING YOUR TURNTABLE

2.1 Powering On/Off

To power on the turntable, rotate the illuminated control knob clockwise. To power off, rotate it counter-clockwise until it clicks off.

2.2 Playing a Record

Follow these steps to play a vinyl record:

1. Select the appropriate speed (33 1/3 RPM or 45 RPM) using the speed selector switch located on the turntable. Use the 45 RPM adaptor for records with larger center holes.

2. Place the vinyl record on the silicone slipmat on the platter.
3. Gently lift the tonearm using the cueing lever.
4. Position the tonearm over the desired starting groove of the record.
5. Slowly lower the cueing lever to gently place the stylus onto the record. The music will begin to play.



Image: The 2-speed belt-driven turntable with its silicone slipmat.

2.3 Volume Control

When streaming to Sonos, you can control the volume directly from the turntable's illuminated knob. For Bluetooth or wired connections, volume control is typically managed via the connected audio device.



Image: The illuminated control knob for easy volume and playback management.

2.4 Switching Audio Outputs

Use the Victrola Stream app or the turntable's controls to switch between Wi-Fi (Sonos, UPnP, Roon Ready), Bluetooth, or wired RCA output modes as needed.

3. MAINTENANCE AND CARE

3.1 Cleaning the Turntable

Regularly wipe the turntable's surface, platter, and dust cover with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive cleaners.

3.2 Stylus Care

Gently clean the stylus periodically using a soft brush designed for stylus cleaning, brushing from back to front. Replace the stylus when sound quality degrades or after approximately 1000 hours of playback to prevent damage to your records.

3.3 Belt Maintenance

The drive belt may stretch or degrade over time. If you notice inconsistent platter speed or reduced performance, inspect the belt for wear and replace it if necessary. Replacement belts are available from Victrola authorized dealers.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cord not connected; outlet not active.	Ensure power cord is securely connected to turntable and a working outlet.
No sound	Incorrect audio output selected; volume too low; amplifier/speakers off or disconnected.	Verify correct output (Wi-Fi, Bluetooth, RCA) is selected. Increase volume on turntable and connected audio system. Check all cable connections.
Skipping or distorted sound	Record is dirty or damaged; stylus is worn or dirty; turntable not level; tracking force incorrect.	Clean record. Clean or replace stylus. Ensure turntable is on a level surface. Adjust tonearm counterweight.
Unstable Wi-Fi/Sonos connection	Weak Wi-Fi signal; network interference; outdated app/firmware.	Ensure strong Wi-Fi signal. Reduce interference from other devices. Update Victrola Stream app and turntable firmware. Consider using Ethernet connection for stability.
Bluetooth pairing issues	Turntable not in pairing mode; device too far; interference.	Put turntable in Bluetooth pairing mode. Ensure device is within range. Clear previous pairings and try again.

5. PRODUCT SPECIFICATIONS

- **Product Dimensions:** 13.5 x 16.9 x 4.3 inches
- **Item Weight:** 18.92 pounds
- **Model Number:** VPT-2000-BLK-ATE
- **Connectivity Technology:** Wi-Fi (Sonos, UPnP, Roon Ready), Bluetooth, RCA
- **Maximum Rotational Speed:** 45 RPM (supports 33 1/3 RPM)
- **Material:** Plastic (with MDF plinth)
- **Color:** Onyx (Black)
- **Cartridge:** Audio-Technica AT-VM95E or Ortofon OM5E
- **Tonearm:** Aluminum with adjustable counterweight and removable headshell

6. WARRANTY AND SUPPORT

Victrola products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or replacement parts, please visit the official Victrola website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims. Additional protection plans may be available for extended coverage. Please refer to your retailer for details on available protection plans. For more information and support, visit the [Victrola Store on Amazon](#).

