



[Manuals.plus](#) /

> [Kohler](#) /

> KOHLER 24764-RL-0 Rutledge Nightlight ReadyLatch Slow Close Elongated Toilet Seat User Manual

Kohler 24764-RL-0

KOHLER 24764-RL-0 Rutledge Nightlight ReadyLatch Slow Close Elongated Toilet Seat User Manual

Model: 24764-RL-0 | Brand: Kohler

INTRODUCTION

This manual provides detailed instructions for the installation, operation, maintenance, and troubleshooting of your KOHLER 24764-RL-0 Rutledge Nightlight ReadyLatch Slow Close Elongated Toilet Seat. Designed for comfort and convenience, this toilet seat features a nightlight, quiet-close functionality, and secure grip-tight bumpers.



Image: The KOHLER Rutledge Nightlight ReadyLatch Slow Close Elongated Toilet Seat in a bathroom setting.

SETUP AND INSTALLATION

Ensure you have all components before beginning installation. The ReadyLatch hinge system simplifies the process, allowing for top-mount installation without needing to reach under the bowl.

1. Confirm Toilet Bowl Size

Before installation, verify that your toilet bowl is elongated. The Rutledge seat is designed for elongated bowls.

Two Toilet Seat Sizes

Knowing the shape of your toilet bowl is crucial when choosing the right seat



Image: Comparison of Elongated and Round-Front toilet seat dimensions.

2. Install ReadyLatch Hardware

The ReadyLatch hinge system allows for easy top-mount installation. Insert the mounting hardware into the bolt holes on your toilet bowl. Ensure the mounts are parallel before tightening.



ReadyLatch® Hinges Allow for Installation Without Reaching Below the Bowl

Image: Detail of the ReadyLatch hinges for secure installation.

For a visual guide on installation, please refer to the official video below:

Your browser does not support the video tag.

Video: Official Kohler Readylatch Demo Video, demonstrating the installation process for the toilet seat.

3. Battery Installation for Nightlight

The integrated Nightlight feature requires power. While product specifications state 'No' for batteries required, some models may use 4 AA batteries. Please refer to your product packaging for specific power requirements and battery installation instructions. Ensure correct polarity if batteries are used.

Easily Locate Your Toilet With LED Nightlight



Image: The LED nightlight feature illuminating the toilet bowl.

OPERATING INSTRUCTIONS

Quiet-Close Functionality

The Quiet-Close lid and seat prevent slamming. Simply push the seat or lid down gently, and it will close slowly and silently on its own. Avoid forcing it down, as this can damage the mechanism.

Nightlight Operation

The integrated Nightlight technology allows you to safely locate the toilet in the dark. It offers a choice of three brightness levels, which can be adjusted via a control on the seat. An LED guide light operates on a 10-hour cycle, providing illumination to the bowl when the lid is lifted.

Grip-Tight Bumpers

The unique Grip-Tight bumpers hold the seat firmly in place, preventing shifting during use and enhancing stability.



Image: Detail of the Grip-Tight bumpers for seat stability.

MAINTENANCE AND CLEANING

Regular cleaning will ensure the longevity and hygiene of your toilet seat. The ReadyLatch hinge makes seat removal easy for thorough cleaning.

Removing the Seat for Cleaning

To remove the seat, simply lift the hinge covers and disengage the ReadyLatch mechanism. Lift the seat with an upward motion to detach it from the mounting posts. This allows for easy access to clean both the seat and the toilet bowl area.



Image: Easy seat removal using ReadyLatch hinges for comprehensive cleaning.

Cleaning Instructions

- Use mild soap and water with a soft cloth.
- Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the plastic finish.
- For the nightlight components, wipe gently with a damp cloth and ensure they are dry before re-installing the seat.

TROUBLESHOOTING

Seat is Loose or Shifts

If the seat feels loose or shifts during use, check the ReadyLatch mounting hardware. Ensure the screws are tightened securely and the hinge covers are properly engaged. The Grip-Tight bumpers should also be in good condition and making proper contact with the bowl.

Nightlight Not Functioning

If the nightlight does not turn on or is dim, check the batteries (if applicable). Replace them if necessary, ensuring correct polarity. Verify that the brightness level is set appropriately. If the issue persists after replacing batteries or if your model is not battery-powered, contact Kohler customer support.

SPECIFICATIONS

Feature	Detail
Brand	Kohler
Model Number	24764-RL-0
Color	White
Material	Plastic
Style	Nightlight
Shape	Elongated (Oval)
Product Dimensions	18.05"L x 14.18"W
Item Weight	5 Pounds
UPC	195711000446
Included Components	Rutledge Nightlight ReadyLatch Quiet-Close Elongated Toilet Seat
Batteries Required?	No (Note: Product description mentions nightlight functionality. Please refer to product packaging for specific power requirements.)

WARRANTY INFORMATION

Your KOHLER 24764-RL-0 Rutledge Nightlight ReadyLatch Slow Close Elongated Toilet Seat is covered by a KOHLER® One-Year Limited Warranty. For full details regarding coverage and claims, please refer to the warranty documentation included with your product or visit the official Kohler website.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Kohler customer service. You can find contact information on the official Kohler website or through your product's packaging. Online resources and FAQs may also be available on the [Kohler Store on Amazon](#).