

[Manuals.plus](#) /

› [Puroma](#) /

› Puroma Key Lock Box Instruction Manual

Puroma LB125

Puroma Key Lock Box Instruction Manual

Brand: Puroma | Model: LB125

PRODUCT OVERVIEW

The Puroma Key Lock Box is a versatile and secure solution for storing keys. It features a durable construction and a resettable combination lock, suitable for both indoor and outdoor use. Its design allows for two primary installation methods, providing flexibility for various applications.



Figure 1: Puroma Key Lock Box with its compartment open, revealing the combination dials and internal space.

WHAT'S IN THE BOX

- Aluminum Zinc Alloy Lock Body
- Steel Lock Shackle
- Screws (for wall mounting)

SETUP

1. Setting the Combination Code

The lock box comes pre-set with the code 0-0-0-0. To reset to your custom 4-digit code, follow these steps:

1. Set the dials to the default code (0-0-0-0) to open the key box.

2. Inside the open compartment, locate the RESET button (a small lever). Push the RESET button from position A to position B.
3. While the button is in position B, set your new desired 4-digit combination on the dials.
4. Push the RESET button back from position B to position A to lock in your new code.



Figure 2: Visual guide for resetting the 4-digit combination code.

2. Installation Methods

The Puroma Key Lock Box offers two convenient installation options:

Option A: Hanging with Removable Shackle

The lock box comes with a removable steel shackle, allowing it to be hung on a doorknob, fence, or other suitable location.

1. Open the lock box compartment.
2. Locate the inner button (usually on the side of the shackle housing). Push this button from right to left.
3. While holding the button, pull the shackle upwards to detach it.
4. To reattach, align the shackle with the holes and push it down until it clicks into place.



Figure 3: Instructions for detaching and reattaching the shackle.

Option B: Wall-Mounted Installation

For a more permanent installation, the lock box can be securely mounted to a wall using the provided screws and expansion plugs.

1. Open the lock box compartment and remove the shackle if attached.
2. Place the back of the lock box against the desired wall surface and mark the position of the 4 mounting holes with a pencil.
3. Using an impact drill, drill holes at the marked positions.
4. Insert the provided expansion plugs into the drilled holes, tapping them gently with a hammer until flush with the wall.

5. Align the lock box with the installed plugs and tighten the screws with a Phillips screwdriver until secure.



Figure 4: Step-by-step guide for wall-mounted installation.

2 Mounting Types



Figure 5: Illustration of the two mounting types: wall-mounted and hanging on a doorknob.

OPERATING INSTRUCTIONS

Once installed and the combination is set, operating the Puroma Key Lock Box is straightforward:

1. To open, slide down the protective cover to reveal the dials.
2. Rotate the dials to your set 4-digit combination.

3. Press the release lever (usually on the side or bottom of the dial mechanism) to open the compartment door.
4. Place or retrieve keys from the spacious internal compartment.
5. To close, firmly push the compartment door shut until it latches.
6. Scramble the dials to secure the lock box.
7. Slide the protective cover back up to conceal the dials and protect them from elements.

Safe and Convenient



Figure 6: Demonstrating the safe and convenient key insertion into the lock box.

10,000

Species



High security, offers you 10000 possible combinations

Figure 7: The 4-digit combination system offers 10,000 unique codes for high security.

MAINTENANCE

The Puroma Key Lock Box is designed for durability and minimal maintenance. It is constructed from robust materials to withstand various environmental conditions.

- **Weatherproof:** The lock box is designed to be weatherproof, protecting its internal components from rain and

moisture.

- **Rust-proof & Corrosion-resistant:** Made from aluminum alloy and steel, it resists rust and corrosion, ensuring long-term functionality.
- **Cleaning:** Periodically wipe the exterior with a damp cloth to remove dirt and debris. Avoid using harsh chemicals or abrasive cleaners.
- **Lubrication:** If the dials become stiff over time, a small amount of silicone-based lubricant can be applied to the moving parts.





Figure 8: The lock box is made from premium materials, ensuring durability against weather and wear.

TROUBLESHOOTING

While the Puroma Key Lock Box is designed for reliable operation, here are some common issues and solutions:

- **Difficulty opening:** Ensure the dials are precisely aligned with your set combination. Sometimes, slight misalignment can prevent opening.
- **Stiff dials:** If the dials are hard to turn, apply a small amount of silicone spray lubricant to the dial mechanism.
- **Forgotten combination:** If the combination is forgotten, there is no master key or backdoor to open the lock box without the correct code. It is crucial to record your combination in a secure place.

SPECIFICATIONS

Feature	Detail
Brand	Puroma
Product Dimensions	1.54"D x 3.07"W x 5.75"H
Lock Type	Mechanical Code Lockbox
Color	Gray
Material	Aluminum Zinc Alloy, Steel
Special Feature	4 Digit Combination Lockbox, Wall Mounted Key Lock Box, Large Capacity Lock Box, Portable Key Storage Box, Weatherproof Lockbox for House Keys
Mounting Type	Wall Mount, Hanging
Control Type	Combination Code
Included Components	Aluminum Zinc Alloy Lock Body, Steel Lock Shackle, Screws
Item Weight	9.6 ounces
Water Resistance Level	Water Resistant
Chamber Depth	1.5 Inches
Chamber Height	2.99 Inches
UPC	840064901659
Item model number	LB125

Large Capacity



Figure 9: Detailed dimensions of the Puroma Key Lock Box, highlighting its large capacity.

WARRANTY AND SUPPORT

Specific warranty and support information is not provided in this manual. Please refer to the product packaging or the manufacturer's official website for details regarding warranty coverage, customer service, and technical support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question