

[Manuals.plus](#) /

› [BALDERIA](#) /

› BALDERIA Finn Electric Fireplace EF44 User Manual

BALDERIA EF44

BALDERIA Finn Electric Fireplace EF44 User Manual

Model: EF44

1. INTRODUCTION

Thank you for choosing the BALDERIA Finn Electric Fireplace. This manual provides essential information for the safe and effective use of your new electric fireplace. Please read these instructions carefully before installation and operation, and retain them for future reference.

The BALDERIA Finn Electric Fireplace offers a realistic 3D flame effect, providing a cozy ambiance without the need for real fire. It features a powerful 2000W heating element, integrated LED ambiance lighting, and convenient control via a remote control or the unit's control panel. Its timeless design, with a white MDF casing, integrates seamlessly into various interior styles.



Image 1.1: BALDERIA Finn Electric Fireplace, front view.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this fireplace.
- Ensure the power outlet voltage matches the rating label on the appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned or been dropped/damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 1 meter (3 feet) from the front of the fireplace and away from the sides and rear.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fireplace.
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always unplug the fireplace when not in use.
- The fireplace is equipped with an overheat protection system. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool down before restarting.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

DIMENSIONS



Image 2.1: Safety features including cold flame, overheat protection, and power specifications.

3. PACKAGE CONTENTS

Please check that all components are present and undamaged:

- BALDERIA Finn Electric Fireplace Unit
- Remote Control
- User Manual (this document)
- AAA Batteries (2) for Remote Control

4. SETUP AND ASSEMBLY

The BALDERIA Finn Electric Fireplace is designed for easy assembly. Follow these general steps:

1. **Unpacking:** Carefully remove all components from the packaging. Keep packaging materials until assembly is complete to ensure no parts are discarded.
2. **Assembly of Casing:** Assemble the MDF casing according to the included assembly diagram. Ensure all screws are tightened securely.
3. **Insert Fireplace Unit:** Carefully slide the electric fireplace insert into the assembled casing.
4. **Placement:** Place the assembled fireplace on a stable, level surface. Ensure there is adequate clearance from walls and other objects as specified in the safety instructions.
5. **Power Connection:** Plug the power cord into a grounded 220-240V AC outlet.

The fireplace is designed to be stable on various surfaces once assembled.



Image 4.1: The BALDERIA Finn Electric Fireplace integrated into a room setting.

5. OPERATING INSTRUCTIONS

The fireplace can be operated using the control panel on the unit or the supplied remote control.

5.1 Control Panel and Remote Control



Image 5.1: Control panel and remote control overview.

1. **Digital Display:** Shows current settings (e.g., temperature, timer).
2. **Flame and Decorative Wood Lighting:** Activates and adjusts the flame effect.
3. **Main Switch:** Powers the unit on/off.
4. **Temperature Setting:** Adjusts the desired room temperature.
5. **Heating Switch:** Turns the heating function on/off.
6. **Weekly Timer:** Programs the fireplace to operate at specific times throughout the week.
7. **Timer:** Sets a countdown timer for automatic shutdown.

5.2 Flame Effect

The realistic 3D flame effect can be adjusted to three different intensity levels to suit your preference. Use the dedicated button on the control panel or remote to cycle through the settings.



Image 5.2: Flame intensity adjustable in 3 levels.

5.3 Heating Function

The fireplace features a 2000W heating element capable of warming large rooms. Use the heating switch to activate the heater and the temperature setting to select your desired room temperature. The integrated thermostat will maintain the set temperature.

5.4 Timer Functions

The fireplace includes both a general timer and a weekly timer. The general timer allows you to set a countdown for automatic shutdown. The weekly timer enables programming of specific operating times for each day of the week, enhancing energy efficiency and convenience.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace.

- **Cleaning:** Always unplug the fireplace before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Ventilation Openings:** Ensure that the ventilation openings are kept clear of dust and debris to prevent overheating. Use a vacuum cleaner with a brush attachment to clean these areas periodically.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location.

7. TROUBLESHOOTING

If you experience issues with your BALDERIA Finn Electric Fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, main switch off, remote control batteries dead.	Check power connection, ensure main switch is on, replace remote batteries.
No heat output.	Heating function off, thermostat set too low, overheat protection activated.	Turn on heating, increase temperature setting, unplug and allow to cool if overheated.
Flame effect not working.	Flame effect function off.	Activate flame effect using the dedicated button.
Remote control not responding.	Dead batteries, obstruction.	Replace batteries, ensure no obstruction between remote and fireplace.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	BALDERIA
Model Number	EF44
Color	White
Dimensions (Product)	25P x 82W x 100H cm (approx. 9.8 x 32.3 x 39.4 inches)
Power Output	2000 Watts
Material	Engineered Wood, Metal
Special Features	3D Flame Effect, Timer, Ambiance Lighting, Remote Control, Thermostat, Overheat Protection
Item Weight	17.3 Kilograms (approx. 38.1 lbs)
Power Source	Corded Electric
Batteries (Remote)	2 AAA (included)

PANNEAUX DE CONTRÔLE ET TÉLÉCOMMANDE



Image 8.1: Product dimensions.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact your retailer. BALDERIA typically offers spare parts availability for 5 years. For specific inquiries or technical assistance, please reach out to the manufacturer's customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question