

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ECR4Kids](#) /

› [ECR4Kids Adjustable Stacking Shelf with Full Edge \(Model ELR-3135-GW\) Instruction Manual](#)

ECR4Kids ELR-3135-GW

ECR4Kids Adjustable Stacking Shelf with Full Edge

Model: ELR-3135-GW (Grey Wash)

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your ECR4Kids Adjustable Stacking Shelf with Full Edge. Designed for versatility, this shelf can be used independently or stacked with additional units to create a vertical storage solution. Its adjustable tray allows for flat or tilted positioning, and the full edge perimeter helps contain items. Constructed from durable rubberwood with a grey wash finish, this shelf is suitable for various environments, including living rooms, bedrooms, dorm rooms, and classrooms.

SAFETY INFORMATION

- Do not overload the shelf. Ensure that the weight distribution is even to prevent tipping.
- When stacking multiple units, ensure they are securely interlocked and stable.
- Regularly inspect the shelf for any loose or worn parts. Tighten or replace components as needed to maintain structural integrity.
- Keep small children away from the product during assembly to prevent access to small parts.

The ECR4Kids Adjustable Stacking Shelf is UL GREENGUARD Gold Certified for low VOCs, TSCA, and CPSIA compliant, ensuring a safe environment for use.

INCLUDED COMPONENTS

Your package should contain the following:

- 1 x Adjustable Stacking Shelf with Full Edge (main unit)
- Necessary assembly hardware and tool (typically an Allen wrench)

Please check all components against the packing list. If any parts are missing or damaged, contact ECR4Kids customer support immediately.

SETUP AND ASSEMBLY

Assembly of the ECR4Kids Adjustable Stacking Shelf is designed to be quick and straightforward.

1. Unpack all components and verify against the included parts list.

2. Identify the main shelf unit and the leg components.
3. Attach the legs to the main shelf unit using the provided hardware and tool. Ensure all screws are tightened securely.
4. Decide on the desired shelf orientation: flat or tilted. The shelf can be assembled to lie flat or at a forward tilt. Adjust the internal fasteners to secure your preferred angle.
5. Ensure the protective rubber pads on the bottom of the legs are properly affixed to prevent scratching surfaces.



Image: The shelf can be assembled for a flat or tilted display. Legs include protective rubber pads.

OPERATING INSTRUCTIONS

Adjusting the Shelf Tilt

The shelf tray can be set to a flat position or a forward tilt. This adjustment is typically made during assembly by securing the internal fasteners at the desired angle. If you wish to change the tilt after assembly, carefully loosen the fasteners, adjust the tray, and re-tighten them securely.

Stacking Multiple Units

For a vertical space-saving solution, multiple ECR4Kids Adjustable Stacking Shelves can be inter-stacked

up to four units high. Align the legs of an upper shelf with the top surface of a lower shelf and gently place it into position. The design ensures a stable stack. Additional shelves are sold separately.



Image: Multiple shelves can be stacked up to four high for vertical storage.

Product Overview Video

Video: This video provides a visual overview of the ECR4Kids Adjustable Stacking Shelf, demonstrating its features, assembly, and various uses in different settings.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your ECR4Kids Adjustable Stacking Shelf, follow these simple care guidelines:

- **Cleaning:** Wipe clean with a soft, damp cloth or sponge using a mild soap and water solution. Dry immediately with a clean towel to prevent water spots or damage.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, harsh chemicals, or solvents, as these can damage the wood finish.
- **Regular Inspection:** Periodically check all connections and hardware for tightness. Re-tighten any loose screws to maintain stability.

- **Environmental Factors:** Avoid prolonged exposure to direct sunlight or extreme temperature changes, which can cause fading or warping.



Image: Cleaning the shelf surface with a soft cloth.

Cleaning and Care Tips Video

Video: This video provides general cleaning and care tips for ECR4Kids hardwood and birch products, applicable to your stacking shelf.

TROUBLESHOOTING

If you encounter any issues with your ECR4Kids Adjustable Stacking Shelf, please consider the following:

- **Instability:** Ensure all assembly screws are fully tightened. If stacking, verify that units are properly aligned and interlocked.
- **Scratches/Wear:** For minor scratches, wood repair kits or markers designed for furniture can be used. For significant wear, contact customer support for advice.

For persistent issues or concerns not addressed here, please contact ECR4Kids customer support.

SPECIFICATIONS

Feature	Detail
Model Name	Adjustable Stacking Shelf with Full Edge
Model Number	ELR-3135-GW
Color	Grey Wash
Material	Rubberwood
Product Dimensions (L x W x H)	25.75" x 12" x 16" (65.4 cm x 30.5 cm x 40.6 cm)
Interior Shelf Dimensions (W x D)	22.8" x 10.75" (57.9 cm x 27.3 cm)
Item Weight	9.6 pounds
Number of Shelves	1 (per unit)
Stackability	Up to 4 units high
Special Features	Adjustable tilt, Durable, Lightweight, Full Edge Perimeter
Certifications	UL GREENGUARD Gold, TSCA Compliant, CPSIA Compliant



Image: Product dimensions for the Adjustable Stacking Shelf.

WARRANTY AND SUPPORT

ECR4Kids is committed to providing high-quality, durable products. While specific warranty details are not provided in this manual, for any questions regarding product defects, missing parts, or general support, please contact ECR4Kids customer service directly through their official website or the retailer where the product was purchased.

For more information about ECR4Kids and their product range, visit their official brand store [ECR4Kids Brand Store](#).