Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Google /
- > Google Pixel 7 5G, US Version, 128GB, Obsidian Unlocked (Renewed) 128GB Obsidian Unlocked Renewed

Google Pixel 7

Google Pixel 7 5G User Manual

Model: Pixel 7

PRODUCT OVERVIEW

Meet Pixel 7. Powered by Google Tensor G2, it's fast and secure, with amazing battery life and the advanced Pixel Camera. Take beautifully authentic, accurate photos with Real Tone and stunning video with Cinematic Blur. And with the certified Titan M2 security chip and a built-in VPN, Pixel helps protect your personal data.

Key Features:

- 6.3" FHD+, 1080 x 2400 OLED at 416 ppi, 20:9 aspect ratio, 90Hz, HDR10+, 1000nits (HBM), 1400nits (peak)
- 128GB 8GB RAM, Octa-core, Google Tensor G2 (5 nm), Mali-G710 MP7, Android 13
- Rear Camera: 50MP, f/1.9 + 12MP, f/2.2, Front Camera: 10.8MP, f/2.2, 4355mAh Battery
- 2G: GSM 850/900/1800/1900, CDMA 800/1700/1900, 3G: HSDPA 800/850/900/1700(AWS)/1900/2100, CDMA2000 1xEV-DO, 4G LTE: 1/2/3/4/5/7/8/12/13/14/17/18/19/20/25/26/28/29/30/32/38/39/40/41/42/46/48/66/71, 5G: 1/2/3/5/7/8/12/14/20/25/28/30/38/40/41/48/66/71/75/76/77/78 SA/NSA/Sub6 - Single SIM
- Unlocked for freedom to choose your carrier. Compatible with both GSM & CDMA networks. The
 phone is unlocked to work with all GSM Carriers & CDMA Carriers Including AT&T, T-Mobile,
 Verizon, Sprint., Etc.

WHAT'S INCLUDED

Your Google Pixel 7 package includes the following items:

- · Google Pixel 7 Cell Phone
- USB Cable

PHYSICAL OVERVIEW

Familiarize yourself with the physical components of your Google Pixel 7.

Front View



The front of the Google Pixel 7 features a vibrant OLED display with a punch-hole camera at the top center.

Rear View



The back of the device showcases the distinctive camera bar housing the dual rear cameras and flash, along with the Google logo.

Side View



The side of the Google Pixel 7 features the power button, volume rocker, and SIM card tray. The USB-C port is located at the bottom.

SETUP

Initial Power On

To power on your Google Pixel 7 for the first time, press and hold the power button located on the right side of the device until the Google logo appears on the screen. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account sign-in.

SIM Card Installation

Locate the SIM card tray on the side of your Pixel 7. Use the SIM ejector tool (not included, but typically comes with renewed phones or can be a paperclip) to open the tray. Insert your nano-SIM card into the tray with the gold contacts facing down and the cut corner aligned. Gently push the tray back into the device until it clicks into place.

Fingerprint and Face Unlock Setup

For enhanced security, set up fingerprint unlock and Face Unlock. Navigate to**Settings** > **Security & privacy** > **Device unlock**. Follow the instructions to register your fingerprints on the in-display sensor and set up Face Unlock using the front camera. For optimal performance, register the same finger multiple times from different angles.

OPERATING INSTRUCTIONS

Basic Navigation

The Google Pixel 7 uses intuitive Android gestures for navigation. Swipe up from the bottom of the screen to go to the home screen. Swipe up and hold to view recent apps. Swipe from the left or right edge of the screen to go back. You can also enable traditional three-button navigation in **Settings** > **System** > **Gestures** > **System navigation**.

Camera Usage

Open the Camera app from your home screen or app drawer. Tap the shutter button to take a photo. Swipe left or right to switch between photo, video, portrait, and other modes. Use the zoom slider to adjust magnification. The Pixel 7's camera system excels in various lighting conditions, offering features like Real Tone for accurate skin tones and Cinematic Blur for video.

Battery Management

The Pixel 7 features an Adaptive Battery that learns your usage patterns to optimize battery life. To extend battery life, go to **Settings** > **Battery**. Here you can enable Battery Saver mode, which restricts background activity and reduces visual effects. The phone supports 20W fast charging, wireless charging, and reverse wireless charging (Battery Share) to charge compatible accessories by placing them on the back of the phone.

MAINTENANCE

Cleaning Your Device

To clean your Google Pixel 7, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using abrasive materials, harsh chemicals, or aerosol sprays, as these can damage the screen and finish. The device has an IP68 water resistance rating, but it is not waterproof. Avoid submerging it in water.

Software Updates

Keep your device's software up to date to ensure optimal performance and security. Navigate to **Settings** > **System** > **System update**. Your Pixel 7 will receive regular updates directly from Google, often including new features and security patches.

Troubleshooting

Common Issues and Solutions

- **Device Unresponsive:** If your phone becomes unresponsive, press and hold the power button for about 30 seconds until it restarts.
- Battery Draining Quickly: Check battery usage in Settings > Battery to identify apps consuming excessive power. Enable Battery Saver or restrict background activity for certain apps.
- Fingerprint Sensor Issues: Ensure your screen is clean and dry. Re-register your fingerprints in Settings > Security & privacy > Fingerprint Unlock, registering the same finger multiple times for better accuracy.

• **Network Connectivity Problems:** Try toggling Airplane Mode on and off. Restart your device. If issues persist, check your SIM card installation or contact your carrier.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6.13 x 2.88 x 0.34 inches
Item Weight	6.9 ounces
Item model number	Pixel 7
OS	Android 13.0
RAM	8 GB
Memory Storage Capacity	128 GB
Standing screen display size	6.3 Inches
Resolution	1080 x 2400
Battery Capacity	4355 Milliamp Hours
Wireless Carrier	Unlocked for All Carriers
Manufacturer	Google
Color	Obsidian

WARRANTY AND SUPPORT

This renewed Google Pixel 7 typically comes with a 90-day return policy for refund or replacement from the seller. For specific warranty details and support, please refer to the documentation provided by your renewed product seller or contact Google support directly for general device inquiries. For additional assistance, visit the official Google Pixel support website or contact their customer service.

Related Documents - Pixel 7

