

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE TV Stand Instruction Manual

## WLIVE ADSG028PL

# WLIVE TV Stand Instruction Manual

Model: ADSG028PL | Brand: WLIVE

## 1. PRODUCT OVERVIEW

The WLIVE TV Stand is a versatile entertainment center designed to accommodate televisions up to 65 inches. Featuring a retro brown finish, this stand includes two storage cabinets and a 3-level adjustable shelf, offering ample space for media devices, accessories, and decor. Its robust construction with engineered wood ensures durability and stability for your living room, bedroom, or office.



Image 1.1: The WLIVE TV Stand in a living room setting, showcasing its design and functionality with a television and various media components.

## 2. SAFETY INFORMATION

- **Weight Capacity:** Do not exceed the maximum weight capacity of 110 lbs (50 kg) on the tabletop. Ensure the television and any items placed on the stand do not exceed this limit.
- **Assembly:** Assembly should ideally be performed by two adults to ensure safety and ease of handling large components.
- **Stability:** Place the TV stand on a flat, level, and stable surface. If placed on carpet, ensure the stand remains stable and does not wobble. Consider using anti-tip kits (not included) for added safety, especially in households with children or pets.
- **Component Check:** Before assembly, verify all parts are present and undamaged. Do not proceed with assembly if any parts are missing or broken.
- **Tools:** Use appropriate tools as specified in the assembly manual. Do not overtighten screws, as this may damage the material.
- **Cable Management:** Utilize the designated cable management holes to organize and secure all wires, preventing tripping hazards and ensuring proper ventilation for electronic devices.

## 3. PACKAGE CONTENTS

Before beginning assembly, ensure all components listed in the included detailed installation manual are present. Typically, the

package contains:

- All necessary engineered wood panels for the TV stand structure.
- Hardware kit (screws, dowels, cam locks, hinges, etc.).
- Adjustable shelves.
- Legs and central support leg.
- Detailed installation manual.
- Basic assembly tools (e.g., Allen wrench).

## 4. ASSEMBLY INSTRUCTIONS

---

Follow the step-by-step instructions provided in the detailed installation manual included with your product. Assembly is designed to be straightforward, but having a second person can greatly assist, especially with larger panels.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or cardboard) to prevent scratches. Identify each part using the labels in the manual.
2. **Assemble Frame:** Begin by assembling the main frame of the TV stand according to the diagrams. Ensure all connections are secure.
3. **Install Shelves:** Insert the adjustable shelves into the designated slots. The 3-level adjustable shelf allows for customization of storage space.



Image 4.1: Detail of the 3-level adjustable shelf, allowing flexible storage configurations.

4. **Attach Doors:** Install the cabinet doors using the provided soft-close hinges. Adjust hinges as needed to ensure doors are flush and operate smoothly.



Image 4.2: Illustration of the soft-close hinge mechanism for quiet and safe door operation.

5. **Attach Legs:** Securely attach the five legs, including the mid solid leg, which provides additional support and stability to the center of the unit.



Image 4.3: The stable structure of the TV stand, highlighting the central support leg for enhanced stability.

6. **Final Check:** Once assembled, gently move the stand to its desired location. Ensure all screws are tightened and the stand is stable before placing any items on it.

## 5. OPERATING INSTRUCTIONS

- **Cable Management:** Utilize the pre-drilled cable management holes located at the back of the open compartments to route and organize your electronic device cables. This helps maintain a tidy appearance and prevents cable clutter.
- **Adjusting Shelves:** To adjust the height of the shelves within the open compartments, remove any items, lift the shelf, and reposition the shelf pins into the desired holes. Ensure the shelf is level and securely seated before placing items back.
- **Storage Cabinets:** The two side cabinets provide concealed storage. Open and close the doors gently, utilizing the soft-close hinges for quiet operation.

## 6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the wood grain finish. The engineered wood material is designed to be stain-resistant and waterproof for easy

cleaning.

- **Spills:** In case of spills, wipe them immediately with a dry cloth to prevent moisture absorption.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Movement:** When moving the TV stand, lift it rather than dragging it to prevent damage to the legs and base.
- **Under-stand Cleaning:** The design provides 6.2 inches of clearance from the floor, allowing for easy cleaning underneath the unit.



Image 6.1: The TV stand's design provides ample clearance for easy cleaning underneath.

## 7. TROUBLESHOOTING

### Issue: Stand wobbles after assembly.

**Solution:** Ensure the stand is on a flat, even surface. Re-check all screws and connections to confirm they are tightened securely. The central support leg should be firmly on the ground. If on carpet, ensure the carpet pile does not cause instability. Consider using furniture pads or shims if necessary.

### Issue: Cabinet doors are not flush or close properly.

**Solution:** Adjust the soft-close hinges. Most hinges have adjustment screws that allow for minor alignment corrections (up/down, left/right, in/out). Refer to the hinge adjustment section in your detailed assembly manual.

**Issue: Missing or damaged parts.**

**Solution:** Do not attempt to assemble the product with missing or damaged parts. Contact WLIVE customer support immediately for assistance and replacement parts.

8. SPECIFICATIONS

|                                |                                                                                                |
|--------------------------------|------------------------------------------------------------------------------------------------|
| Brand                          | WLIVE                                                                                          |
| Model Name                     | ADSG028 Wood TV Stand With Leg/PL                                                              |
| Product Dimensions (D x W x H) | 15.7"D x 58.3"W x 25.4"H                                                                       |
| Item Weight                    | 56.1 Pounds (25.4 kg)                                                                          |
| Color                          | Retro Brown                                                                                    |
| Material                       | Engineered Wood (High-Quality MDF)                                                             |
| Max TV Size Supported          | Up to 65 inches                                                                                |
| Tabletop Max Weight Capacity   | 110 lbs (50 kg)                                                                                |
| Number of Compartments         | 6 (2 cabinets, 4 open shelves)                                                                 |
| Assembly Required              | Yes                                                                                            |
| Special Features               | Adjustable shelves, Soft-close hinges, Cable management holes, Mid solid leg for stabilization |

# PRODUCT SIZE



Max Weight Capacity



Image 8.1: Detailed product dimensions and maximum TV size compatibility.

## 9. WARRANTY AND SUPPORT

For any issues, missing parts, or questions regarding your WLIVE TV Stand, please contact WLIVE customer support. Refer to the contact information provided in your product packaging or visit the official WLIVE store on Amazon for assistance.

**WLIVE Store:** [Visit the WLIVE Store on Amazon](#)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**