

Amazon Fire 7 Kids (12th Generation)

Amazon Fire 7 Kids Tablet User Manual

Model: Fire 7 Kids (12th Generation)

INTRODUCTION

The Amazon Fire 7 Kids tablet is designed for children aged 3-7, offering a full-featured tablet experience with robust parental controls and access to a vast library of age-appropriate content through Amazon Kids+. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device, ensuring a safe and engaging digital experience for your child.

fire 7 kids

If it breaks, we will replace it.



Disney nick



Figure 1: Amazon Fire 7 Kids Tablet with Kid-Proof Case.

WHAT'S INCLUDED

Your Amazon Fire 7 Kids tablet package includes the following components:

- Fire 7 tablet
- Amazon Kid-Proof Case
- USB-C cable
- 5W power adapter
- Quick Start Guide

SETUP

1. Charging Your Tablet

Before first use, fully charge your Fire 7 Kids tablet. Connect the included USB-C cable to the tablet's USB-C port and the 5W power adapter to a wall outlet. A full charge typically takes approximately 4 hours.

2. Powering On and Initial Setup

Press and hold the power button located on the side of the tablet until the Amazon logo appears. Follow the on-screen instructions to:

1. Select your language.
2. Connect to a Wi-Fi network. The tablet supports single-antenna dual-band Wi-Fi (802.11a/b/g/n) with WEP, WPA, and WPA2 security.
3. Register your tablet to an Amazon account.
4. Set up child profiles and parental controls.

OPERATING YOUR TABLET

Basic Navigation

The Fire 7 Kids tablet features a 7-inch touchscreen display. Navigate by tapping, swiping, and pinching. The home screen provides access to Amazon Kids+ content and other applications.

Amazon Kids+

Your tablet includes a 1-year subscription to Amazon Kids+, an award-winning digital content service. This service provides thousands of ad-free books, interactive games, videos, and apps from trusted brands like Disney, Nickelodeon, and PBS Kids. Content is curated by age range to evolve with your child's interests.



Figure 2: Amazon Kids+ Interface.



Content is curated by age range so it evolves with kids' interests as they grow.

Figure 3: Diverse Content Available on Amazon Kids+.




Select ad-free Disney episodes
now included with Amazon Kids+

Figure 4: Ad-Free Disney Content on Amazon Kids+.

Parental Controls

The Parent Dashboard allows you to manage your child's digital experience. You can filter content based on age, set educational goals, establish time limits, and grant access to additional content like Netflix and Disney+.



An app made just for parents to help customize their kids' digital experience.

Figure 5: Amazon Parent Dashboard for Customizing Digital Experience.

Storage Management

The tablet comes with either 16 GB (9.5 GB user available) or 32 GB (25 GB user available) of internal storage. You can expand storage up to 1 TB using a microSD card. Some apps may require installation on internal storage. Regularly check available storage to ensure optimal performance.

Camera Usage

The Fire 7 Kids tablet is equipped with 2 MP front and rear-facing cameras, capable of 720p HD video recording. Access the camera app from the home screen to capture photos and videos.

MAINTENANCE

Cleaning Your Tablet

To clean the screen, use a soft, lint-free cloth. For the tablet body and Kid-Proof Case, a slightly damp cloth can be used. Avoid using abrasive cleaners or solvents.

Kid-Proof Case Care

The sturdy Kid-Proof Case is designed to protect against drops and bumps. It can be cleaned with mild soap and water if necessary. Ensure the case is completely dry before reattaching it to the tablet.

TROUBLESHOOTING

- Tablet is slow or sluggish:**

This can occur if internal storage is nearly full. Consider moving content to a microSD card or uninstalling unused apps. The 16 GB model has limited user storage (9.5 GB), so an SD card is highly recommended for optimal performance.
- Battery life is shorter than expected:**

Battery life varies based on usage. Reduce screen brightness, close unused apps, and limit background activities to extend battery life. Certain software features or apps may also reduce battery life.
- Cannot connect to Wi-Fi:**

Ensure your Wi-Fi router is on and within range. Verify the Wi-Fi password. Restarting both the tablet and the router can often resolve connectivity issues.
- Content not appearing in Amazon Kids+:**

Check your parental control settings in the Parent Dashboard to ensure the content is allowed for the child's profile. Verify your Amazon Kids+ subscription is active.
- Tablet is unresponsive:**

Perform a forced restart by holding the power button for 40 seconds until the device powers off and then back on.

SPECIFICATIONS

Feature	Detail
Display	7" touchscreen, 1024 x 600 resolution at 171 ppi, SD video playback, with IPS technology.
Size	6.4" x 7.9" x 1.1" (162mm x 201mm x 28mm)
Weight	15.1 ounces (429 grams). Actual size and weight may vary.
CPU & RAM	Quad-Core 2.0 GHz with 2 GB of RAM
Storage	16 GB (9.5 GB available) or 32 GB (25 GB available) internal storage. Expandable up to 1 TB with microSD.
Battery life	Up to 10 hours of mixed use. Varies based on settings and usage.
Charge time	Approximately 4 hours using included 5W power adapter.
Wi-Fi connectivity	Single-antenna dual-band Wi-Fi (802.11a/b/g/n). Supports WEP, WPA, WPA2. Does not support Wi-Fi 6 (802.11ax).
Ports	USB-C, microSD slot for external storage.
Audio	3.5 mm stereo jack and integrated speaker.
Sensors	Accelerometer.

Feature	Detail
Camera specs	2 MP front and rear-facing cameras with 720p HD video recording.
Location services	Location-based services via Wi-Fi.
Available colors	Blue, Purple, and Red.
Additional features	External volume controls, built-in Bluetooth (A2DP, LE support).
Accessibility features	VoiceView screen reader, Screen magnifier, Closed Captioning, Font Size, High Contrast Text, Color Inversion, Color Correction, Convert Stereo to Mono audio.
Subscription	Includes 1 year of Amazon Kids+ for new subscribers.
Age range	Ages 3 and up. WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.
Generation	12th generation - 2022 release.
Software Security Updates	Guaranteed until at least four years after last available for purchase as new.



Figure 6: Size Comparison of Fire Kids Tablets.

WARRANTY AND SUPPORT

2-Year Worry-Free Guarantee

The Amazon Fire 7 Kids tablet comes with a 2-year worry-free guarantee. If the device breaks, Amazon will replace it for free within 2 years of purchase. This guarantee covers accidental damage.

Customer Service

For further assistance, technical support, or warranty claims, please visit the Amazon Customer Service website or contact Amazon support directly. Refer to the Quick Start Guide included in your package for initial contact information.

