

NEEWER PA002

NEEWER PA002 Smartphone Tripod Mount User Manual

Brand: NEEWER

Model: PA002

INTRODUCTION


This manual provides detailed instructions for the NEEWER PA002 Smartphone Tripod Mount. This aluminum alloy mount is designed for secure and flexible smartphone positioning, featuring 360° rotation, tilt adjustments, and multiple mounting options for various accessories and tripods. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.

PRODUCT FEATURES

- **Unbeatable Compatibility:** Adjustable from 2.6" to 4" (6.6 to 10.2cm), compatible with a wide range of smartphones including iPhone 15 Pro Max, Galaxy S24 Ultra, Google Pixel 7 Pro, and more.
- **Flexible 360° Adjustment:** Features a 360-degree rotation ball head and three vertical tilt notches, allowing for versatile phone positioning in both vertical and horizontal orientations. A large knurled locking knob ensures secure adjustment.
- **Arca Type Base for Tripod Mounting:** Designed with an Arca type base for direct attachment to compatible quick release plates. Also mounts on mini tripods, tabletop tripods, monopods, light stands, and handgrips via 1/4" and 3/8" threads.
- **Easy Accessory Connection:** Includes one cold shoe and three 1/4" mounting points for connecting LED video lights, microphones, articulating arms, and other accessories for professional setups.
- **Integrated Foldable Stand:** A built-in folding stand transforms the mount into an independent desktop stand for video calls, selfies, remote working, and live streaming.

HIGHLY FLEXIBLE THREE U GROOVE BALL HEAD

Easily adjustable, providing you with a variety of shooting support angles.



√ Pitch 110°



√ Flip 180°



√ 360° Rotation



Figure 1: Illustrates the 360° rotatable ball head and vertical tilt capabilities of the mount.

WIDELY COMPATIBLE

The mobile phone clamp has double end stretching to achieve a larger clamping distance and is compatible with more sizes and brands of models for installation and use.



SPRING TENSION
KNOB



INELASTIC TENSION
CLAMP



Figure 2: Demonstrates the wide compatibility and adjustable clamping mechanism for various smartphone sizes.



MULTIFUNCTIONAL BASE

Three fixed interface designs, suitable for tripods, light stands, slide rails, etc.



Note: Only the phone clamp tripod mount is included.

Figure 3: Shows the multifunctional base with Arca-type compatibility and 1/4" and 3/8" threads for diverse mounting options.


PACKAGE CONTENTS

- 1 x Rotatable Smartphone Tripod Mount (PA002)
- 1 x User Manual

PACKAGE CONTENTS



1 x Multifunctional metal mobile phone clamp



1 x User Manual

SPECIFICATIONS

Model: PA002

Material: Aluminum alloy

Name: Multifunctional metal mobile phone clamp

Weight: 5.5oz / 156g

Clamp distance: 2.6" ~ 4" / 6.6 ~ 10.2cm

Size: 5.4" x 1.6" x 2.7" / 138 x 40 x 68mm

Figure 4: The contents included in the product package.

SETUP AND INSTALLATION

1. Attaching Your Smartphone

1. Locate the top tightening knob on the phone clamp. Rotate it counter-clockwise to expand the clamp jaws.
2. Carefully place your smartphone between the expanded jaws, ensuring it is centered and the rubber pads securely grip the phone without obstructing buttons or ports.
3. Rotate the top tightening knob clockwise to securely clamp your smartphone. Ensure the phone is held firmly but do not overtighten.

WIDELY COMPATIBLE

The mobile phone clamp has double end stretching to achieve a larger clamping distance and is compatible with more sizes and brands of models for installation and use.



Figure 5: Adjusting the phone clamp to secure a smartphone.

2. Mounting to a Tripod or Support

1. **Using Arca-Type Base:** If your tripod or support has an Arca-type quick release clamp, simply slide the mount's Arca-type base into the clamp and secure it.
2. **Using 1/4" or 3/8" Threads:** For other tripods, monopods, or light stands, use the 1/4" or 3/8" threaded holes on the base of the mount. Screw the mount onto the corresponding screw on your support device.



MULTIFUNCTIONAL BASE

Three fixed interface designs, suitable for tripods, light stands, slide rails, etc.

Note: Only the phone clamp tripod mount is included.



Figure 6: Demonstrates various mounting methods using the Arca-type base and threaded holes.

OPERATING INSTRUCTIONS

1. Adjusting Phone Orientation and Angle

- **360° Rotation:** Loosen the large knurled locking knob located on the side of the mount. Rotate your smartphone to the desired horizontal or vertical orientation. Tighten the knob to secure the position.
- **Vertical Tilt:** The mount features three vertical tilt notches. Loosen the same large knurled locking knob, adjust the tilt angle, and then tighten the knob to lock it.

HIGHLY FLEXIBLE THREE U GROOVE BALL HEAD

Easily adjustable, providing you with a variety of shooting support angles.




Figure 7: Adjusting the phone's angle and orientation using the ball head.

2. Using the Integrated Foldable Stand

The mount includes a foldable stand for desktop use. Simply unfold the base to create a stable stand for your smartphone. This is ideal for hands-free viewing, video calls, or live streaming without a tripod.



Figure 8: Unfolding the integrated stand for desktop use.

3. Attaching External Accessories

- **Cold Shoe Mount:** Use the cold shoe mount on top of the phone clamp to attach small LED lights, microphones, or other cold shoe compatible accessories.
- **1/4" Mounting Points:** The mount features three 1/4" threaded holes. These can be used to attach articulating arms, additional lights, or other accessories with 1/4" screws.

EASY EXPANSION

You can stably install microphones, fill lights and other lightweight auxiliary equipment through different expansion interfaces.

Note: Only the phone clamp tripod mount is included.



Figure 9: Attaching external accessories using the cold shoe and 1/4" mounting points.

MAINTENANCE

- Clean the mount regularly with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials, as these can damage the aluminum alloy finish and rubber pads.
- Ensure all knobs and screws are tightened before use to prevent accidental drops or damage to your smartphone.
- Store the mount in a dry, cool place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Phone feels loose in the clamp:** Ensure the top tightening knob is fully tightened. If the phone is still loose, verify that your phone's width is within the 2.6" to 4" (6.6 to 10.2cm) compatible range.
- **Mount is unstable on tripod:** Check that the Arca-type base or the 1/4"/3/8" threads are securely attached to your tripod or support. Ensure the tripod itself is stable and on a flat surface.
- **Difficulty rotating or tilting:** Loosen the large knurled locking knob slightly before attempting to adjust the angle or orientation. Do not force adjustments.

SPECIFICATIONS

Model	PA002
Material	Aluminum Alloy
Product Dimensions	6.61 x 3.94 x 2.13 inches
Item Weight	7.8 ounces
Compatible Phone Width	2.6" to 4" (6.6 to 10.2cm)
Mounting Type	Tripod (Arca-Type, 1/4", 3/8" threads)
Accessory Mounts	1 x Cold Shoe, 3 x 1/4" threads

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official NEEWER website or contact their customer service directly. Keep your purchase receipt for any warranty claims.