

[Manuals.plus](#) /

> [TRILINK](#) /

> TRILINK Undetectable Mechanical Mouse Jiggler User Manual

TRILINK Undetectable Mouse Jiggler

TRILINK Undetectable Mechanical Mouse Jiggler User Manual

Model: Undetectable Mouse Jiggler

INTRODUCTION

Thank you for choosing the TRILINK Undetectable Mechanical Mouse Jiggler. This device is designed to simulate mouse movement, preventing your computer from entering sleep mode or activating screen savers. It operates without software installation, ensuring it remains undetectable by IT departments.



Image Description: The TRILINK Undetectable Mechanical Mouse Jiggler, a compact black rectangular device, is displayed alongside its USB power cable. The device features a circular patterned area on its top surface and a small blue indicator light on the front.

PRODUCT OVERVIEW

Familiarize yourself with the components of your TRILINK Mouse Jiggler.

Mouse Jiggler non rilevabile



Image Description: A close-up view of the TRILINK Mouse Jiggler, highlighting its key components. Labels point to the mouse movement disk, the indicator light, the ON/OFF button, and the power interface.

- **Mouse Movement Disk:** The rotating platform where the mouse is placed to simulate movement.
- **Indicator Light:** Illuminates to show the device's operational status.
- **ON/OFF Button:** Controls the power and activation of the mouse jiggler.
- **Power Interface:** USB-C port for connecting the power cable.

SETUP INSTRUCTIONS

Follow these steps to set up your TRILINK Mouse Jiggler:

1. **Connect the USB Cable:** Connect the USB-C end of the provided power cable to the power interface on the mouse jiggler.

Tecnologia dei chip aggiornata



Non rilevabile e sicuro



Nessun software



Funzionamento libero



Movimento meccanico



Non si blocca



Image Description: A four-panel image illustrating the setup process. The first panel shows connecting the USB-C cable to the mouse jiggle.

- 2. Connect to Power Source:** Connect the USB-A end of the power cable to a USB port on your computer or a 5V USB power adapter.

Tecnologia dei chip aggiornata



Non rilevabile e sicuro



Nessun software



Funzionamento libero



Movimento meccanico



Non si blocca



Image Description: The second panel of the four-panel image shows connecting the USB-A cable to a power adapter plugged into a wall socket.

3. **Place Your Mouse:** Position your optical mouse on the mouse movement disk of the jiggler. Ensure the mouse's optical sensor is centered over the disk.

Tecnologia dei chip aggiornata



Non rilevabile e sicuro



Nessun software



Funzionamento libero



Movimento meccanico



Non si blocca



Image Description: The third panel shows a mouse placed on the TRILINK Mouse Jiggler, which is connected to a laptop.

4. **Activate the Jiggler:** Press the ON/OFF button located on the side of the device to start the mouse movement. The indicator light will illuminate.

Tecnologia dei chip aggiornata



Non rilevabile e sicuro



Nessun software



Funzionamento libero



Movimento meccanico



Non si blocca



Image Description: The fourth panel shows the mouse jiggler in operation next to a laptop, with the mouse on its surface and the indicator light on.

OPERATING INSTRUCTIONS

Once set up, the TRILINK Mouse Jiggler will automatically simulate mouse movement. The device is designed for continuous operation to keep your computer active.

- To stop the movement, press the ON/OFF button again. The indicator light will turn off.
- To resume movement, press the ON/OFF button.
- The device operates silently, ensuring a disturbance-free environment.

Funzionamento Ultra-Silenzioso

Mantiene un ambiente silenzioso durante il funzionamento del dispositivo



Image Description: A laptop screen displaying a serene mountain landscape, with the TRILINK Mouse Jiggler and a mouse positioned next to it. A graphic indicates "Bassa Latenza" (Low Latency) and a silent operation icon, suggesting quiet performance even while a person sleeps in the background.

COMPATIBILITY

The TRILINK Mouse Jiggler offers broad compatibility across various operating systems and device types:

- **Operating Systems:** Compatible with Windows (XP/7/8/10), Mac OS, and all versions of Linux.
- **Device Types:** Works with laptops, PCs, and tablets.
- **Mouse Types:** Supports both wired and wireless optical mice.

This device is particularly useful for preventing inactivity detection on communication platforms like Lync, Zoom, Skype, and WebEx, where settings cannot be easily modified.

Ampia compatibilità

Compatibile con tutti i sistemi operativi, inclusi Windows XP/7/8/10, Mac OS, sistema Linux, Android, ecc.



Windows



Linux



Mac OS



Android

- ✓ Mouse con Filo
- ✓ Mouse Wireless



Image Description: The TRILINK Mouse Jiggler is shown with icons representing Windows, Linux, Mac OS, and Android, indicating wide operating system compatibility. Text confirms compatibility with wired and wireless mice.

KEY FEATURES

- **Keeps Computer Active:** Designed to simulate cursor movement, preventing your computer from entering sleep mode or activating screen savers during important tasks, online lessons, remote work, or presentations.
- **100% Undetectable:** Operates independently of your computer, requiring no software installation or USB dongle. This ensures it cannot be detected by IT departments.
- **Ultra-Silent Operation:** Equipped with a quiet motor, producing sound levels below 20 dB, ensuring a peaceful working environment.
- **Plug and Play:** Simply connect to a USB power source, place your mouse, and press the ON/OFF button.

Mantiene il Computer Attivo

per qualsiasi periodo di tempo



Image Description: A laptop displaying an active screen, with the TRILINK Mouse Jiggler and a mouse positioned next to it, illustrating its function of keeping the computer awake.

SPECIFICATIONS

Brand	TRILINK
Model Name	Undetectable Mouse Jiggler
Dimensions	14.4 x 8 x 3.61 cm
Weight	209 grams
Operating System Compatibility	Windows, Linux, Mac OS
Compatible Devices	Laptop, PC, Tablet
Special Features	Silent Operation

Power Type	Wired Electric (USB)
Connector Type	USB
Motion Sensing Technology	Optical
Hand Orientation	Ambidextrous




Image Description: A diagram of the TRILINK Mouse Jiggler with its dimensions clearly marked: 12 cm in height, 7.6 cm in width, and 3 cm in depth.

WHAT'S IN THE BOX

The package includes the following items:

- 1x TRILINK Mouse Jiggler
- 1x USB-C to USB-A Power Cable (1 meter)
- 1x User Manual



Image Description: An image showing the TRILINK Mouse Jiggler, its USB power cable, and the user manual, all neatly arranged as they would appear in the product packaging.

TROUBLESHOOTING

- **Device not turning on:**
 - Ensure the USB power cable is securely connected to both the jiggler and a working USB power source (computer USB port or 5V adapter).
 - Press the ON/OFF button to activate the device. Check if the indicator light illuminates.
- **Mouse not moving:**
 - Verify that your mouse is an optical mouse. The jiggler relies on the optical sensor.
 - Ensure the mouse is placed centrally on the movement disk, with its optical sensor directly over the disk.
 - Check if the jiggler is powered on (indicator light is active).
- **Unusual noise during operation:**
 - The device is designed for ultra-silent operation (below 20 dB). If you hear excessive noise, ensure the device is on a flat, stable surface.
 - Contact customer support if the noise persists or is significantly loud.

MAINTENANCE

The TRILINK Mouse Jiggler requires minimal maintenance:

- Keep the device clean and free from dust. Use a soft, dry cloth for cleaning.
- Avoid exposing the device to liquids or extreme temperatures.
- Do not attempt to disassemble the device, as this may void the warranty.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official TRILINK website. We are committed to providing high-quality service and support for our products.

