

Manuals.plus /

› Brightup /

› Brightup USB Charger for Beard Trimmer Body Hair Trimmer YP-7017, YH-7282 Instruction Manual

Brightup WX-W-IY0552A



The logo features the word "Brightup" in a serif font. Above the letter "i" is a stylized graphic of a hair curl or a decorative flourish.

Brightup USB Charger Instruction Manual

For Beard Trimmer and Body Hair Trimmer Models YP-7017, YH-7282

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Brightup USB Charger. This charger is specifically designed for Brightup Beard Trimmer and Body Hair Trimmer models YP-7017 and YH-7282. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Brightup USB Charger, designed for convenient charging of compatible trimmers.

IMPORTANT SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following precautions:

- **Keep away from water sources:** Do not expose the charger or connected device to water or other liquids.
- **Not for infants:** This product is not intended for use with infants.
- **Unplug before cleaning:** Always disconnect the charger from the power source before cleaning.

- **Blade safety:** When charging a trimmer, ensure blades are kept away from eyes and skin.
- **General caution:** Always use with caution and follow all instructions.

Statements regarding dietary supplements have not been evaluated by the FDA and are not directly related to the charger's function.

PRODUCT OVERVIEW

The Brightup USB Charger (Model WX-W-IY0552A) provides a convenient and reliable power source for your compatible Brightup trimmers. Its compact design makes it ideal for travel and everyday use.

Key Features:

- USB Charging capability.
- Compatible with Brightup Trimmer Models YP-7017 and YH-7282.
- Compact and portable design.

SETUP

To set up your Brightup USB Charger:

1. **Identify the charging port:** Locate the charging port on your Brightup Beard Trimmer (YP-7017) or Body Hair Trimmer (YH-7282).
2. **Connect the charger:** Insert the charger's connector into the trimmer's charging port. Ensure a secure connection.
3. **Connect to power source:** Plug the USB end of the charger into a compatible USB power adapter (e.g., wall adapter, computer USB port, power bank). The power source should provide standard USB voltage (typically 5V).
4. **Verify charging:** Most trimmers will indicate charging status with an LED light. Refer to your trimmer's manual for specific charging indicators.

OPERATING INSTRUCTIONS

The Brightup USB Charger operates automatically once connected to a power source and a compatible trimmer. It is designed to provide the necessary power for charging the trimmer's internal battery.

- **Charging duration:** Charging times may vary depending on the trimmer's battery level and capacity. Refer to your trimmer's manual for estimated charging durations.
- **Overcharge protection:** The charger is designed to work with trimmers that typically have built-in overcharge protection. However, it is generally recommended to disconnect the charger once the trimmer is fully charged to prolong battery life.
- **Power source:** Use only certified USB power adapters to ensure safe and efficient charging.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your Brightup USB Charger:

- **Cleaning:** Disconnect the charger from all power sources and devices. Wipe the charger with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the charger in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid bending or kinking the cable excessively.

- **Inspection:** Periodically inspect the cable and connector for any signs of damage, such as fraying or exposed wires. If damage is found, discontinue use and replace the charger.

TROUBLESHOOTING

If you encounter issues with your Brightup USB Charger, consider the following:

- **Trimmer not charging:**
 - Ensure the charger is securely connected to both the trimmer and the USB power source.
 - Verify that the USB power source is active and providing power (e.g., try charging another device with the same USB port/adaptor).
 - Check if the trimmer's charging port is clean and free of debris.
 - Confirm that your trimmer model (YP-7017 or YH-7282) is compatible with this charger.
- **Charger appears damaged:** Discontinue use immediately if the charger cable or connector shows signs of damage.

If problems persist, contact Brightup customer support for further assistance.

SPECIFICATIONS

Model Number	WX-W-IY0552A
Brand	Brightup
Compatibility	Brightup Beard Trimmer YP-7017, Brightup Body Hair Trimmer YH-7282
Power Source	USB (for Battery Powered Trimmer)
Special Features	USB Charging
Product Dimensions	2.76 x 0.79 x 0.39 inches
Item Weight	0.63 ounces
Manufacturer	Brightup

WARRANTY AND SUPPORT

Specific warranty information for the Brightup USB Charger (Model WX-W-IY0552A) is not provided in this document. For warranty details, please refer to the documentation included with your original Brightup trimmer or visit the official Brightup website.

For technical support or further inquiries, please contact Brightup customer service through their official channels.