Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VOGOE HR310

VOGOE 4-in-1 Cordless Epilator for Women

Model: HR310 - Instruction Manual

1. Important Safety Information

Please read all instructions carefully before using the VOGOE HR310 epilator. Keep this manual for future reference.

- The device body is not waterproof. Do not immerse the device in water or use it in the shower. Keep the device dry.
- Do not use the device while it is charging.
- Keep out of reach of children.
- If excessive pressure is applied during use, the HR310 will pause due to a safety lock. To resolve this, turn the product off and then on again.
- Do not use on irritated, sunburnt, or broken skin. Consult a doctor if you have any skin conditions.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

2. Product Overview

The VOGOE HR310 is a versatile 4-in-1 cordless epilator designed for effective hair removal and body care. It includes multiple interchangeable heads to suit various needs.



Image: The VOGOE HR310 device with its four interchangeable heads: Epilator, 3-in-1 Foil Shaver, Massage Roller, and Callus Remover.

The device features 21 hypoallergenic electric tweezers for precise hair removal, two speed settings for customized use, and an LED light for improved visibility. It is rechargeable and designed for cordless operation.




Image: Detailed diagram of the VOGOE HR310 epilator, highlighting its components including the replacement head, release button, LED lights, control button, USB charging port, and accessories.

Product Overview Video

Video: An overview of the VOGOE 4-in-1 epilator for women, demonstrating its electric and rechargeable features.

3. Setup and Charging

Before first use, ensure the device is fully charged. The epilator is powered by a 700mAh lithium-ion battery.

1. Connect the provided USB charging cable to the USB charging port on the device.
2. Plug the other end of the USB cable into a suitable USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate during charging. A full charge takes approximately 2.5 hours.

4. Once fully charged, the device provides up to 4 hours of cordless operation.



Image: The epilator connected to a charger, indicating a 2.5-hour charge provides 4 hours of usage.

To change attachment heads: Hold the shaver, press the release buttons on both sides of the device with your fingers, and pull the current head out. Align the new head and push it firmly until it clicks into place.

4. Operating Instructions

The VOGOE HR310 offers two speed settings. Use the On/Off Button & Speed Adjustable Button to select your preferred speed. Speed 1 is generally for sensitive areas or finer hair, while Speed 2 is for larger areas or coarser hair.

General Usage Tips:

- Ensure your skin is clean and dry before use.
- Hold the device at a 90-degree angle to your skin for optimal performance.
- Move the device slowly and gently against the direction of hair growth.

Using the Epilator Head:

The epilator head is equipped with 21 hypoallergenic tweezers to remove hair from the root, resulting in smoother skin for weeks and finer regrowth.




Image: Illustration demonstrating the epilator's 21 tweezers removing hair from the root when held at a 90-degree angle.

Follow these steps for effective epilation:

1. Prepare your skin: Ensure softer hairs and open pores for easier removal.
2. Choose the appropriate speed setting (1 or 2).
3. Move the epilator slowly and gently at a 90-degree angle on your skin, against the direction of hair growth.

4. After epilation, relax your skin, possibly with a soothing lotion.




Image: A visual guide detailing the four steps for using the epilator effectively.

Using the 3-in-1 Foil Shaver Head:

The foil shaver head is designed for shaving stray hairs or trimming longer hairs short, suitable for various body areas including armpits, arms, face, bikini area, and legs. It features advanced floating foil and hypoallergenic stainless steel blades.



Image: Detailed view of the shaver head, illustrating the floating foil, curved blade, and straight blade, along with recommended angles for trimming and shaving.

Using the Massage Roller Head:

Attach the massage roller head for a relaxing skin massage. Gently roll over desired areas.

Using the Callus Remover Head:

Attach the callus remover head to gently remove calluses from your feet. Use on dry skin and follow with a moisturizer.

Attachments Usage Video

Video: Demonstrates how to use each of the four attachments: epilator, shaver, massage roller, and callus remover.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your VOGOE HR310 epilator.

1. Turn off the device and remove the attachment head.
2. Rotate the epilator head clockwise to open it for cleaning.
3. Use the provided cleansing brush to remove any trapped hairs from the tweezers or blades.
4. Rinse the attachment head under running water and allow it to air dry completely before reattaching.
5. **Important:** Do not immerse the main body of the device in water. Clean the main body with a dry or slightly damp cloth.



Image: Visual guide for cleaning the epilator head, including warnings against using while charging and immersing the main body in water.

6. Troubleshooting

If you encounter issues with your VOGOE HR310 epilator, refer to the following common solution:

- **Device pauses during use:** If excessive pressure is applied, the HR310 will temporarily pause due to its safety lock mechanism. To resume operation, simply turn the device off and then turn it back on.

7. Product Specifications

Feature	Specification
Model Number	HR310
Power Source	Battery Powered (700mAh Lithium-ion)
Charging Time	2.5 Hours
Operating Time	4 Hours
Number of Tweezers	21
Speed Settings	2 (1400±200RPM)
Water Resistance Level	Not Water Resistant
Product Dimensions	6.22 x 1.85 x 5.43 inches
Item Weight	11.29 ounces (0.32 Kilograms)
Included Components	Battery, Multiple Attachment Heads, USB Charging Cable, Cleansing Brush

8. Warranty and Support

For any questions, concerns, or support regarding your VOGOE HR310 epilator, please contact VOGOE customer

service. Refer to the product packaging or the official VOGOE website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLGY25RX

More documents and user manuals: **https://manuals.plus/**