ALLIMITY AKB74935621

ALLIMITY AKB74935621 Remote Control Instruction Manual

Model: AKB74935621 | Brand: ALLIMITY

1. Introduction

This ALLIMITY AKB74935621 replacement remote control is designed for use with various LG Sound Bar models. It provides full functionality for controlling your sound bar's features.

Compatible Models:

- LG Sound Bar SJ2
- LG Sound Bar SPJ2B-W
- LG Sound Bar SJ2.AEUSLLK
- LG Sound Bar SJ2.DEUSLLK
- LG Sound Bar COV33552424

This remote control operates using infrared technology and requires no additional setup or programming. Simply insert batteries and begin use.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always remove exhausted batteries promptly.
- Dispose of used batteries according to local regulations.
- Keep the remote control out of reach of small children.

3. Setup

3.1 Battery Installation

The remote control requires two (2) 1.5V AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating correct AAA battery placement.

3.2 No Programming Required

This remote control is pre-programmed to work with the specified LG Sound Bar models. No manual code entry or synchronization process is necessary. Once batteries are installed, the remote is ready for immediate use.

4. Operating Instructions

Point the remote control directly at your LG Sound Bar when pressing buttons. Ensure there are no obstructions between the remote and the sound bar's infrared receiver.



Image: Front view of the remote control displaying all functional buttons.

Button Functions:

- **Power (⏻):** Turns the sound bar on or off.
- **OPTICAL:** Selects the optical input source.
- **VOL (+/-):** Adjusts the main volume level.
- **⏻:** Mutes or unmutes the sound.
- **STANDARD:** Activates the standard sound effect mode.
- **BASS BLAST:** Enhances bass for a more powerful sound.
- **⏻:** Skips to the previous track/file.
- **⏻:** Plays or pauses media playback.
- **⏻:** Skips to the next track/file.
- **DRC ON/OFF:** Toggles Dynamic Range Control on or off.
- **WOOFER LEVEL (+/-):** Adjusts the subwoofer volume level.
- **AUTO POWER ON/OFF:** Enables or disables the auto power function of the sound bar.
- **F (Function):** Cycles through available input functions/sources.

5. Maintenance

5.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's finish or internal components.

5.2 Battery Replacement

Replace the batteries when the remote control's response becomes sluggish, or if the sound bar no longer responds to commands. Refer to Section 3.1 for battery installation instructions.

5.3 Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for several months, it is advisable to remove the batteries to prevent leakage.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh ones.
  - Ensure there is a clear line of sight between the remote control and the sound bar's infrared receiver. Remove any obstructions.
  - Confirm that your sound bar model is listed as compatible with this remote control.
- **Intermittent response:** This often indicates low battery power. Replace the batteries.

If the issue persists after following these steps, please refer to your LG Sound Bar's original manual for further troubleshooting or contact the sound bar manufacturer's support.

7. Specifications

Product Dimensions	6.5 x 1.38 x 0.72 inches

Item Weight	1.13 ounces
Batteries Required	2 x 1.5V AAA batteries (not included)
Connectivity Technology	Infrared
Compatible Devices	LG Sound Bar (SJ2, SPJ2B-W, SJ2.AEUSLLK, SJ2.DEUSLLK, COV33552424)

8. Warranty and Support

For specific warranty information or technical support regarding this ALLIMITY remote control, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question