Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ SPL-800, SPL-800R, SPL-800I, SPL-1000R, SPL-1200R, SPL-1500R, SPL-800II, SPL-1000II, SPL-1200II, SPL10RBG

HCDZ Replacement Remote Control User Manual

For Velodyne Acoustics SPL Ultra Series Subwoofers

Introduction

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your HCDZ replacement remote control. This remote is designed to be compatible with various Velodyne Acoustics SPL Ultra Series subwoofers, offering a direct replacement for your original remote without the need for programming.

Package Contents

- 1 x HCDZ Replacement Remote Control
- *Note: Batteries and detailed instructions are not included in the package.*

Setup

1. Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.



Image: Back of the remote control with the battery cover open, revealing the battery compartment.

3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Do not mix new and old batteries.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Image: Back of the remote control with the battery cover securely closed.

2. Initial Use

This replacement remote control requires no programming. Once batteries are correctly installed, it is ready for immediate use with compatible Velodyne Acoustics SPL Ultra Series subwoofers.

Operating Instructions

Point the remote control directly towards the infrared (IR) sensor on your Velodyne Acoustics subwoofer. Ensure there are

no obstructions between the remote and the subwoofer's sensor.
The remote functions are designed to replicate the original remote control for your specific Velodyne Acoustics SPL Ultra Series subwoofer model. Refer to your subwoofer's original manual for specific button functionalities if needed.

Maintenance

- **Battery Replacement:** Replace both AAA batteries when the remote's performance degrades or stops functioning. Always replace both batteries simultaneously with new ones. Do not use a new battery with an old one.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.
- **Environmental Conditions:** Avoid exposing the remote to extreme heat, humidity, or direct sunlight, as this can cause malfunction or damage. Do not leave the remote in an extremely hot or humid place. Do not expose the remote sensor to direct sunlight or lighting apparatuses.

Troubleshooting

Problem	Possible Cause	Solution
Remote not working	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity. Check battery terminals for corrosion.
Remote works intermittently	Weak batteries; Obstruction between remote and subwoofer.	Replace batteries. Remove any objects blocking the signal path.
Remote range is poor	Weak batteries; Remote too far from subwoofer; Direct sunlight interfering with IR sensor.	Replace batteries. Move closer to the subwoofer. Reposition subwoofer or remote to avoid direct sunlight on the IR sensor.
Specific buttons not responding	Subwoofer model incompatibility (rare); Button malfunction.	Verify your subwoofer model is listed as compatible. Contact customer support if issue persists. Ensure the power cord to your device is plugged in and turned on.

Specifications

- **Brand:** HCDZ
- **Compatibility:** Velodyne Acoustics SPL Ultra Series Subwoofers (SPL-800, SPL-800R, SPL-800I, SPL-1000R, SPL-1200R, SPL-1500R, SPL-800II, SPL-1000II, SPL-1200II, SPL10RBG)
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA Batteries (not included)
- **Special Feature:** No programming required
- **Max Number of Supported Devices:** 1

Warranty and Support

For warranty information or technical support, please refer to the seller's policies on the platform where the product was purchased. This product is a replacement remote control and typically comes with a standard return policy.
Seller: Sure-Win
Return Policy: 30 days (refund/replacement)

For further assistance, you may visit the HCDZ Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLH713KX

More documents and user manuals: **https://manuals.plus/**