

Celly KIDSWATCHPK

CELLY Kidswatch KIDSWATCHPK 4G Smartwatch User Manual

Model: KIDSWATCHPK

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your CELLY Kidswatch KIDSWATCHPK 4G Smartwatch. Please read this manual thoroughly before using the device to ensure proper setup, operation, and maintenance. Keep this manual for future reference.

2. PRODUCT OVERVIEW

The CELLY Kidswatch KIDSWATCHPK is a 4G waterproof smartwatch designed for children, offering communication, safety, and activity tracking features. Key functions include two-way calling, messaging, GPS tracking, an SOS alarm, a pedometer, and a camera.



Figure 1: Front view of the CELLY Kidswatch KIDSWATCHPK 4G Smartwatch. The image displays the pink smartwatch with its screen showing the time (08:08), date (09/18 Mon), a heart icon with '9', and network/battery indicators. The left side of the watch body features icons for a USB charging port and a SIM card slot. A camera lens is visible above the screen.

3. SETUP

3.1. SIM Card Installation

1. Ensure the smartwatch is powered off before inserting the SIM card.
2. Locate the SIM card slot on the side of the watch (refer to Figure 1).
3. Carefully open the SIM card slot cover.
4. Insert a Nano-SIM card with an active 4G data plan, ensuring the correct orientation as indicated by the diagram near the slot.
5. Close the SIM card slot cover securely to maintain water resistance.

3.2. Initial Charging

1. Connect the provided charging cable to the USB charging port on the watch.
2. Connect the other end of the cable to a standard USB power adapter (not included) or a computer USB port.
3. Charge the watch fully before first use. A full charge typically takes approximately 2-3 hours.

3.3. App Installation and Pairing

1. Download the official CELLY Kidswatch application from your smartphone's app store (iOS or Android).
2. Register an account within the application.
3. Follow the in-app instructions to pair the smartwatch with your smartphone. This usually involves scanning a QR code displayed on the watch screen or entering a unique device ID.
4. Configure essential settings such as emergency contacts, safe zones, and school mode schedules through the app.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- **Power On:** Press and hold the power button (located on the side of the watch) until the screen illuminates.
- **Power Off:** Press and hold the power button, then select 'Power Off' on the screen, or use the remote power-off function via the companion app.

4.2. Making and Receiving Calls

- **Making Calls:** From the watch interface, navigate to the 'Contacts' menu. Select a contact and tap to initiate a call. Only pre-approved numbers can be called.
- **Receiving Calls:** When a call comes in, the watch will ring and display the caller ID. Tap the green icon to answer or the red icon to reject.

4.3. Messaging

The watch supports sending and receiving short voice messages and pre-set text messages. Manage and configure these options through the companion app.

4.4. SOS Function

In an emergency, press and hold the SOS button (usually the power button, if configured) for a few seconds. The watch will automatically call the pre-set emergency contacts in a loop until one answers and send a location alert.

4.5. GPS Tracking

The watch utilizes GPS to provide real-time location tracking. Parents can view the child's location history and set up geofences (safe zones) through the companion app. Alerts are sent if the watch enters or exits a defined safe zone.

4.6. Pedometer

The built-in pedometer tracks daily steps. This data can be viewed on the watch and synchronized with the companion app to monitor activity levels.

4.7. School Mode

School mode can be activated via the companion app to disable most watch functions during specific times, preventing distractions during school hours. Only SOS calls and time display remain active.

4.8. Camera Function

The watch includes a small camera for taking photos. Navigate to the 'Camera' application on the watch screen to use this feature. Photos can be viewed on the watch and may be accessible via the companion app.

4.9. Water Resistance (IP67)

The watch is IP67 rated, meaning it is protected against dust and can withstand immersion in water up to 1 meter for up to 30 minutes. It is suitable for showering and short periods underwater but not for swimming or diving. Ensure all ports and covers are securely closed to maintain water resistance.

5. MAINTENANCE

5.1. Cleaning

- Wipe the watch regularly with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the watch's finish and seals.
- Ensure the charging port is dry before charging.

5.2. Battery Care

- Avoid fully discharging the battery frequently.
- Charge the watch using only the provided cable.
- Do not expose the watch to extreme temperatures, as this can affect battery life and performance.

5.3. Water Resistance Precautions

- Always ensure the SIM card slot cover and charging port cover are fully sealed before exposing the watch to water.
- Do not press buttons underwater.
- Avoid exposing the watch to hot water, steam, or high-pressure water jets.
- If the watch gets wet, dry it thoroughly with a soft cloth before charging.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch does not power on	Low battery; device malfunction	Charge the watch for at least 30 minutes. If it still doesn't turn on, contact support.
No network signal	SIM card not inserted correctly; no active data plan; out of network coverage	Check SIM card insertion. Ensure SIM card has an active 4G plan. Move to an area with better network coverage.
GPS location is inaccurate	Poor GPS signal; indoor environment	Ensure the watch is outdoors with a clear view of the sky. GPS accuracy can be affected by buildings and weather.
Battery drains quickly	Frequent use of features; poor network signal; old battery	Reduce screen brightness. Limit continuous GPS tracking. Ensure good network signal. If issue persists, battery may need service.
Cannot make/receive calls	No network signal; contacts not whitelisted; school mode active	Check network signal. Verify contacts are added to the whitelist in the app. Disable school mode if necessary.

For issues not listed here, please refer to the companion app's help section or contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Celly

Feature	Detail
Model Number	KIDSWATCHPK
Color	Rose
Screen Size	1.44 Inches
Connectivity	Cellular (4G)
Special Features	Time display, Step counter, GPS, Alarm clock, SOS, Camera
Water Resistance	IP67 (Dust protected, immersion up to 1m for 30 min)
Battery Composition	Aluminum Oxide
Manufacturer	CELLY
Country of Origin	United States of America

8. WARRANTY INFORMATION

Specific warranty details for the CELLY Kidswatch KIDSWATCHPK are not provided in the product information. Please refer to the retailer's return policy or the official Celly website for warranty terms and conditions.



9. CUSTOMER SUPPORT





For technical assistance, product inquiries, or support, please consult the help section within the CELLY Kidswatch companion application or visit the official Celly website for contact information.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were provided in the available data for this model.

Related Documents - KIDSWATCHPK

	Celly KIDSWATCH User Manual: Features, Setup, Safety, and Specifications Comprehensive user manual for the Celly KIDSWATCH children's smartwatch. Learn about setup, features like GPS and camera, safety guidelines, specifications, and proper disposal.
	Celly TRAINERHALO Fitness Bracelet User Manual Comprehensive user manual for the Celly TRAINERHALO Fitness Bracelet, detailing setup, features, functions, safety guidelines, specifications, and disposal information. Learn how to connect, use, and maintain your fitness tracker.

	<p>Celly TRAINERBAND Fitness Bracelet User Manual</p> <p>Comprehensive user manual for the Celly TRAINERBAND fitness bracelet, covering setup, usage, features, troubleshooting, and specifications. Track your activity, heart rate, blood pressure, and sleep.</p>
	<p>Celly BUZ1 Bluetooth Earphones User Manual</p> <p>User manual for Celly BUZ1 Bluetooth earphones, providing instructions on setup, operation, safety precautions, maintenance, and technical specifications.</p>
	<p>Celly BHTWINSACT Bluetooth Stereo Earphones User Manual</p> <p>Comprehensive user manual for Celly BHTWINSACT Bluetooth Stereo Earphones, covering safety, usage, technical specifications, and compliance information.</p>
	<p>Celly BHTWINSACT Bluetooth Stereo Earphones User Manual</p> <p>User manual for Celly BHTWINSACT Bluetooth stereo earphones, covering setup, usage, safety, technical specifications, and disposal. Learn how to pair, use, and maintain your Celly wireless earbuds.</p>