

LEGO 43217

LEGO Disney and Pixar 'Up' House Building Toy Set 43217 Instruction Manual

Model: 43217

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling, operating, and maintaining your LEGO Disney and Pixar 'Up' House Building Toy Set (Model 43217). This set is designed for builders aged 9 and up, offering an engaging construction experience and a detailed display model inspired by the beloved Disney and Pixar film, *Up*.

The set includes a detailed section of the iconic house with a chimney and balloons, two LEGO minifigures (Carl Fredrickson and Russell), and a LEGO dog figure (Dug). Various accessories are also included to enhance play and display.

2. SETUP AND ASSEMBLY

Follow the step-by-step instructions provided in the included building guide. For an enhanced building experience, utilize the LEGO Builder app, which offers 3D model views, zoom and rotate functions, and progress tracking.

2.1 Unpacking the Set

Carefully open the packaging and sort the LEGO elements by color or type to facilitate the building process. Ensure all bags are accounted for before beginning assembly.

2.2 Building Instructions

Refer to the physical instruction booklet for sequential building steps. Each step illustrates the addition of specific pieces to the model. Pay close attention to the piece count and placement for accurate construction.



Image 2.2.1: The LEGO Disney and Pixar 'Up' House set, showing the packaging and the fully assembled model with minifigures and balloons.



Image 2.2.2: A child engaged in the assembly of the LEGO 'Up' House, demonstrating the hands-on building process.

2.3 Digital Building Experience

The LEGO Builder app provides an interactive 3D guide. Download the app from your device's app store and search for Model 43217. This digital tool can assist with complex steps and offer alternative viewing angles.



Image 2.3.1: The completed LEGO 'Up' House set displayed on a wooden surface, showcasing its intricate details and vibrant colors.

3. OPERATING AND PLAY FEATURES

Once assembled, the LEGO 'Up' House offers various features for imaginative play and display.

3.1 Iconic House Details

The model replicates key architectural elements of the house from the movie, including its distinctive color scheme, chimney, and porch. The interior features multiple rooms with recognizable details.



Image 3.1.1: Close-up view of the interior details of the LEGO 'Up' House, including furniture and the adventure book accessory.

3.2 Minifigures and Accessories

The set includes Carl Fredrickson, Russell, and Dug figures, allowing for recreation of movie scenes or new adventures. Accessories such as the wilderness explorer backpack and the adventure book add to the play possibilities.



Image 3.2.1: The three included LEGO figures: Carl Fredricksen, Russell with his wilderness explorer backpack, and Dug the dog.

3.3 Balloon Feature

The house features a cluster of colorful balloons attached to the chimney, designed to evoke the iconic flying house from the film. These balloons are a central visual element of the model.



Colourful balloons to float off on an adventure

Image 3.3.1: The LEGO 'Up' House model featuring the vibrant cluster of balloons, ready for imaginative adventures.

4. MAINTENANCE

Proper care ensures the longevity and appearance of your LEGO set.

4.1 Cleaning

To clean LEGO elements, use a soft cloth dampened with water and a mild soap solution. Avoid harsh chemicals or abrasive materials. For intricate areas, a soft brush can be used. Ensure all pieces are completely dry before storage.

4.2 Storage

Store the assembled model or individual pieces in a cool, dry place away from direct sunlight to prevent discoloration and material degradation. Keep small pieces in a container to avoid loss.

5. TROUBLESHOOTING

If you encounter any issues during assembly or with the set, consider the following:

5.1 Missing Pieces

In the rare event of missing pieces, please contact LEGO Customer Service directly. They can assist with replacement parts.

5.2 Assembly Difficulties

Double-check the instruction steps. Sometimes a small piece may be misplaced or oriented incorrectly. The LEGO Builder app can provide additional visual assistance.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.32 x 15.04 x 2.78 inches (packaging)
Item Weight	0.64 ounces
Model Number	43217 (Item model number: 6427575)
Recommended Age	9 years and up
Number of Pieces	598
Release Date	April 1, 2023
Manufacturer	LEGO

7. WARRANTY INFORMATION

LEGO products are manufactured to high-quality standards. For information regarding product warranty, including details on defective or missing parts, please refer to the official LEGO website or contact LEGO Customer Service directly. General warranty terms typically cover manufacturing defects.

8. SUPPORT AND CONTACT INFORMATION

For further assistance, questions, or to order replacement parts, please visit the official LEGO Customer Service portal:

- [LEGO Customer Service](#)

You can also find additional resources and community forums on the LEGO website.

