

[Manuals.plus](#) /

› [CONTROL INN](#) /

› Instruction Manual for CONTROL INN Remote Control for Panasonic Inverter Minisplit

CONTROL INN Cs-ys12mkv-6

Instruction Manual

CONTROL INN REMOTE CONTROL FOR PANASONIC INVERTER MINISPLIT (MODEL: CS-YS12MKV-6)

1. INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your CONTROL INN remote control, designed for seamless compatibility with Panasonic Inverter Minisplit air conditioning units, specifically model Cs-ys12mkv-6. This remote serves as an ideal replacement for lost or damaged original units, offering intuitive operation and quick setup.

2. PRODUCT OVERVIEW

The CONTROL INN remote control features an ergonomic design for comfortable handling and clearly labeled buttons for easy operation of your Panasonic Inverter Minisplit. The display screen provides visual feedback on current settings.



Figure 2.1: Front view of the remote control, displaying the screen and primary function buttons.



Figure 2.2: Angled view of the remote control, showcasing its comfortable grip and button layout.

Button Functions:

- **COOL:** Activates the cooling mode.
- **TIMER:** Sets or cancels the timer function for automatic on/off.
- **OFF/ON:** Powers the air conditioner on or off.
- **AIRSWING:** Controls the vertical swing of the air conditioner's louvers.
- **TEMP ▲/▼:** Adjusts the temperature setting up or down.
- **FAN SPEED:** Cycles through different fan speed settings (e.g., Low, Medium, High, Auto).

3. SETUP

Battery Installation:

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 3.1: Back view of the remote control, indicating the battery compartment.

No complex configuration or pairing is typically required for this replacement remote. It is designed to work directly with compatible Panasonic Inverter Minisplit units upon battery installation.

4. OPERATING INSTRUCTIONS

To operate your Panasonic Inverter Minisplit using the CONTROL INN remote control, point the remote directly at the air conditioner's receiver. Ensure there are no obstructions between the remote and the unit.

- **Power On/Off:** Press the **OFF/ON** button to turn the air conditioner on or off.
- **Adjusting Temperature:** Use the **TEMP ▲** button to increase the temperature and the **TEMP ▼** button to decrease it. The current temperature setting will be displayed on the remote's screen.
- **Selecting Mode:** Press the **COOL** button to activate the cooling mode. Other modes (e.g., Fan, Dry, Heat) may be accessible if your specific unit supports them and the remote has corresponding buttons.
- **Fan Speed Control:** Press the **FAN SPEED** button repeatedly to cycle through available fan speeds (e.g., Auto, Low, Medium, High).
- **Air Swing Function:** Press the **AIRSWING** button to activate or deactivate the automatic vertical louver swing, distributing air more evenly.
- **Timer Setting:** Press the **TIMER** button to access the timer settings. Follow the on-screen prompts (if any) or refer to your air conditioner's main manual for specific timer programming steps.

5. MAINTENANCE

Cleaning:

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners,

or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries at the same time with new AAA batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote and the air conditioner's receiver.
 - Confirm the remote is pointed directly at the air conditioner.
- **Display is dim or blank:**
 - This usually indicates low battery power. Replace the batteries.
- **Remote controls some functions but not others:**
 - Verify that your specific Panasonic Inverter Minisplit model supports the function you are trying to use.
 - Ensure the remote is compatible with your exact air conditioner model (Cs-ys12mkv-6).

7. SPECIFICATIONS

Feature	Detail
Brand	CONTROL INN
Model Compatibility	Panasonic Inverter Minisplit Cs-ys12mkv-6
Compatible Devices	Air conditioner minisplit Panasonic
Connectivity Technology	Infrared
Maximum Compatible Devices	1
Dimensions	20 x 5 x 30 cm
Weight	1 kg

8. WARRANTY AND SUPPORT

For any issues not covered in this manual or for further assistance, please contact CONTROL INN customer support. Keep your purchase receipt as proof of purchase for any warranty claims. Specific warranty terms may vary; please refer to the product packaging or seller information for details.