

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Men's Stainless Steel Watch User Manual

OLEVS TJ-DE-G5513QJ-J

OLEVS Men's Stainless Steel Watch User Manual

Model: TJ-DE-G5513QJ-J

INTRODUCTION

Thank you for choosing the OLEVS Men's Stainless Steel Watch. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new timepiece. Designed for elegance and durability, this watch features a classic design with a diamond-accented face, a robust stainless steel bracelet, and reliable quartz movement.

Please read this manual carefully to ensure proper use and to maximize the lifespan of your watch.

SETUP

1. Setting Time and Date

To set the time and date on your OLEVS watch, follow these steps:

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the first or second click position.
2. **Adjust the date/day:** In the first click position, turn the crown clockwise or counter-clockwise to adjust the date and day of the week.
3. **Adjust the time:** In the second click position, turn the crown to set the hour and minute hands. Ensure you set the correct AM/PM for the date change to occur at midnight.
4. **Push in the crown:** Once set, push the crown back into its original position to start the watch movement.

2. Adjusting the Stainless Steel Bracelet

Your watch comes with a durable stainless steel bracelet that can be adjusted to fit your wrist. A special tool is often included for this purpose. If the bracelet is too long or too short, you may need to add or remove links.



Image: The OLEVS Men's Stainless Steel Watch shown with the included bracelet adjustment tool. This tool is used to remove or add links for a custom fit.

If you are uncomfortable adjusting the bracelet yourself, or if you require additional links, please contact OLEVS customer support or a professional jeweler.

OPERATING YOUR WATCH

Key Features:

- **Quartz Movement:** Your OLEVS watch is powered by a reliable original quartz movement, ensuring accurate timekeeping and long battery life.
- **Date and Week Display:** The watch features a clear display for both the current date and the day of the week, enhancing its practicality for daily use.
- **Luminous Hands:** The watch hands are designed with luminous material, allowing for easy readability in low-light conditions.
- **Water Resistance:** This watch is water-resistant up to 30 meters (3ATM), suitable for daily splashes, rain, and hand washing. It is *not* suitable for swimming, diving, or showering with hot water.



Image: A close-up view of the OLEVS watch on a wrist, highlighting the diamond-accented face and clear display.



Image: The OLEVS watch worn on a wrist, showing its profile and how it complements formal attire.

MAINTENANCE

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust and smudges. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** While water-resistant, avoid exposing the watch to extreme temperature changes or prolonged

submersion. Always ensure the crown is fully pushed in before any contact with water. Do not operate the crown when the watch is wet.

- **Battery:** The quartz movement is designed for long-lasting battery performance. When the battery eventually runs out, it should be replaced by a qualified watch technician to maintain the watch's integrity and water resistance.
- **Storage:** When not in use, store your watch in a cool, dry place, away from direct sunlight and strong magnetic fields.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Watch not keeping accurate time.	• Battery may be low or depleted. Replace the battery. • Crown is not fully pushed in. Ensure the crown is securely pushed into its normal operating position.
Bracelet is too long or too short.	• Use the provided adjustment tool to remove or add links. • Contact OLEVS customer support for assistance or additional links.
Date/Day display is incorrect or not changing.	• Refer to the "Setting Time and Date" section for proper adjustment. • Ensure the time is set correctly for AM/PM, as the date changes at midnight.
Water ingress or fogging inside the watch.	• The crown may not have been fully pushed in, or the watch was exposed to water beyond its 30m resistance. • Seek professional repair immediately to prevent further damage.

For any issues not covered here, or for further assistance, please contact OLEVS customer support.

SPECIFICATIONS

Feature	Detail
Brand	OLEVS
Model Number	TJ-DE-G5513QJ-J
Movement	Original Quartz Movement
Case Material	Stainless Steel
Bracelet Material	Stainless Steel
Dial Features	Diamond accents, Date and Week display, Luminous hands
Water Resistance	30 Meters (3ATM) - Suitable for daily splashes, rain, hand washing. Not for swimming or diving.
Package Dimensions	15.1 x 6.4 x 2.7 cm
Item Weight	160 grams

WARRANTY AND SUPPORT

OLEVS is committed to providing high-quality products and excellent customer service.

- **Warranty:** Your OLEVS watch comes with a 12-month warranty from the date of purchase, covering manufacturing defects.
- **Returns:** We offer a 30-day unconditional return policy. Please refer to your purchase platform's return guidelines for details.
- **Customer Support:** If you have any questions, concerns, or require assistance with your watch, please do not hesitate to contact OLEVS customer support. You can reach us via the Amazon website or application. We provide lifetime support for our products.
- **Common Inquiries Handled by Support:**
 - Bracelet adjustment (e.g., needing extra links or adjustment tool).
 - Guidance on watch functions and precautions.
 - Other product-related questions.

We are dedicated to resolving any issues you may encounter promptly and efficiently.

© 2024 OLEVS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BLNNRJ8X>

More documents and user manuals: <https://manuals.plus/>