

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BOBLOV](#) /

› [BOBLOV X2 64GB Body Mounted Camera User Manual](#)

BOBLOV BOBLOVX264GB

BOBLOV X2 64GB Body Mounted Camera User Manual

MODEL: BOBLOVX264GB

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your BOBLOV X2 64GB Body Mounted Camera. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity. The BOBLOV X2 is a compact and lightweight body camera designed for various applications, including personal security, sports, and daily recording, featuring a 1440P video resolution, a 2-inch LCD display, and versatile mounting options.

2. Package Contents

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

What's in the box?



Image: Contents of the BOBLOV X2 Body Camera package, showing the camera, USB cable, lanyard, user manual, package box, short 360° rotate clip, magnet clip, back clip, and magnet back clip.

1. USB Cable
2. Lanyard
3. User Manual
4. BOBLOV X2 Body Camera
5. Package Box
6. Short 360° Rotate Clip
7. Magnet Clip
8. Back Clip
9. Magnet Back Clip

3. Product Overview

The BOBLOV X2 camera features a compact design with an integrated LCD screen and lens on the front. It is equipped with various buttons for easy operation and ports for connectivity.



Image: The BOBLOV X2 Body Camera in hand, displaying its front screen and lens, alongside the magnetic and short clips.

Camera Components:

- **LCD Display:** 2-inch screen for live view, playback, and menu navigation.
- **Camera Lens:** Located on the screen side for convenient recording.
- **Power Button:** For turning the device on/off.
- **Video/Audio Mode Button:** To switch between recording modes.
- **Snapshot Button:** To capture still images.
- **Menu Button:** To access settings.
- **OK Button:** For selection and playback functions.
- **USB Port:** For charging and data transfer.

4. Setup

4.1 Charging the Camera

Before first use, fully charge the camera. The built-in 2000mAh battery provides approximately 7 hours of recording time at 1080P resolution after a 3-hour charge.

Built-in 2000MAH Battery & 64GB Memory

Support Recording when charging



Charging

Fully Charged



Image: The BOBLOV X2 Body Camera being charged via a USB cable, highlighting its 2000mAh battery and 64GB memory, with indicators for charging status and recording time.

1. Connect the provided USB cable to the camera's USB port.
2. Plug the other end of the USB cable into a USB power adapter (not included) or a computer's USB port.
3. The charging indicator will show red while charging and turn green when fully charged.
4. The camera supports recording while charging.

4.2 Attaching Clips and Mounts

The BOBLOV X2 offers versatile wearing methods using the included clips and magnetic mounts.

360° Short Back Clip & Magnetic Clips Provided



Image: Step-by-step guide on how to attach the magnetic clips and the 360-degree rotatable short back clip to the BOBLOV X2 Body Camera.

- **Magnetic Clips:** Attach the 'Outside' magnetic plate to the back of the camera and the 'Inside' magnetic plate to the inside of your clothing. The camera will securely hold in place.
- **Short 360° Rotate Clip:** Slide the short clip onto the camera's back slot until it clicks. This allows for 360-degree rotation for optimal positioning on clothing or backpacks.



Hang on Neck



Handheld for Selfie

Multiple Wearing Methods with Various Parts



Short Clip Clamp to Backpack



Magnets Attract on Clothes

Image: Demonstrates multiple ways to wear the BOBLOV X2 Body Camera, such as hanging around the neck with a lanyard, holding it for selfies, clipping it to a backpack, or using magnetic attraction on clothing.

5. Operation

The BOBLOV X2 is designed for quick and intuitive operation.

Easy Operate, Quick Set-up



Image: An illustration detailing the quick setup and easy operation of the BOBLOV X2, showing button functions for video mode, audio mode, snapshot, menu, and playback.

5.1 Basic Controls:

- **Power On/Off:** Long press the Power button to turn the camera on or off.
- **Video Mode:** Short press the Video/Audio Mode button to start/stop video recording.
- **Audio Mode:** Long press the Video/Audio Mode button to start/stop audio recording.
- **Snapshot:** Short press the Snapshot button to take a photo.
- **Menu:** Short press the Menu button to enter the settings menu.
- **Playback:** Short press the OK button in standby mode to enter playback mode.
- **Mark Video:** In video mode, short press the OK button to mark the current video as important.

5.2 Connecting to a PC:

To manage files, connect the camera to a computer using the provided USB cable.



Image: A visual guide illustrating the connection of the BOBLOV X2 Body Camera to a personal computer for accessing and managing recorded files.

1. Ensure the camera is powered on.
2. Connect the camera to your computer using the USB cable.
3. The camera will appear as a removable disk drive on your computer.
4. You can then access, copy, or delete recorded videos and photos.

6. Features

6.1 High-Resolution Recording

The BOBLOV X2 supports 1440P video recording and 30-megapixel photo capture, ensuring clear and detailed footage.



Image: The BOBLOV X2 Body Camera showcasing its ability to record 1440P video and capture 30-megapixel photos, with examples of recorded content.

6.2 Loop Recording

When the memory card is full, the camera will automatically overwrite the oldest files to continue recording, ensuring continuous operation without manual intervention.



Image: A graphic representation of the loop recording function, showing older video segments being replaced by new ones as the memory fills up.

6.3 Mark Important Videos

You can mark specific video segments as important during recording. These marked files will be protected from being overwritten by the loop recording function.



Image: A display from the BOBLOV X2 camera interface, indicating the ability to mark important videos, with details like resolution, frame rate, and file size visible.

7. Maintenance

- Cleaning:** Use a soft, dry cloth to clean the camera body. For the lens, use a specialized lens cleaning cloth and solution. Avoid harsh chemicals.
- Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the camera regularly, even if not in use for extended periods.
- Firmware Updates:** Check the official BOBLOV website periodically for any available firmware updates to ensure optimal performance and new features.

8. Troubleshooting

- Camera not turning on:** Ensure the battery is charged. Connect to a power source and try again. If the issue persists, perform a reset (refer to the full manual for reset instructions if available).
- Recording issues (e.g., freezing, poor quality):** Check if the memory is full. Ensure the camera's

firmware is up to date. Try formatting the internal memory (this will erase all data).

- **Computer not recognizing camera:** Try a different USB port or cable. Ensure the camera is powered on when connected. Restart your computer.
- **Short clip disengages easily:** Ensure the clip is fully inserted and locked into the camera's back slot. Some users have reported that the clip may be more secure when installed with the locking lever towards the bottom of the camera.

9. Specifications

Feature	Specification
Brand	BOBLOV
Model Number	BOBLOVX264GB
Item Weight	13.7 ounces (approx. 388g)
Package Dimensions	6.06 x 3.78 x 3.03 inches
Batteries	1 Lithium Polymer battery (included)
Color	Black, White
Special Features	Lightweight
Video Capture Resolution	1080p (up to 1440P)
Flash Memory Type	Micro SD (64GB built-in)
Screen Size	2 Inches
Connectivity Technology	USB
Lens Type	Zoom
Image Stabilization	No
Form Factor	Handheld
Battery Capacity	2000mAh
Charging Time	Approx. 3 hours
Recording Time (1080P)	Approx. 7 hours

10. Warranty and Support

BOBLOV products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the warranty card included in your package or visit the official BOBLOV website. Please retain your proof of purchase for warranty claims.



Image: The official BOBLOV brand logo.