**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Colorcool M8

# Colorcool M8 32GB MP3 Player User Manual

Portable Music Player with Bluetooth, FM Radio, Voice Record, and E-book Functionality

## 1. Introduction

Thank you for choosing the Colorcool M8 MP3 Player. This compact and versatile device is designed to provide a high-quality audio experience on the go, featuring Bluetooth connectivity, a built-in speaker, FM radio, voice recording, and e-book capabilities. Please read this manual carefully to ensure proper use and maintenance of your device.




*Figure 1: Colorcool M8 MP3 Player and accessories.*

## 2. What's in the Box

The Colorcool M8 MP3 Player package includes the following items:

- 1 x Colorcool M8 Bluetooth MP3 Player
- 1 x User's Manual
- 1 x Silicon Case
- 1 x Wire Headset
- 1 x USB Type-C Cable
- 1 x AUX-AUX Cable

Your browser does not support the video tag.

*Video 1: Unboxing the Colorcool M8 MP3 Player. This video demonstrates the contents of the package and the initial appearance of the device.*

## 3. Product Overview

The Colorcool M8 is a compact and feature-rich MP3 player designed for portability and ease of use. It boasts a full-touch screen interface and a clip-on design, making it ideal for active lifestyles.




*Figure 2: The compact and lightweight design of the Colorcool M8 MP3 Player, easily fitting into a pocket.*

### Key Features:

- **Bluetooth 5.2:** For stable and low-power connection to Bluetooth headphones and speakers.*(Note: Cannot pair with mobile phones.)*
- **High-Fidelity (HiFi) Sound:** Equipped with a professional intelligent digital noise reduction chip.

- **Internal Storage:** 32GB built-in memory.
- **Expandable Storage:** Micro SD card slot supports up to 128GB.
- **Built-in HD Speaker:** Enjoy music without headphones (can be turned on/off in settings).
- **Multi-functionality:** Includes FM Radio, Voice Recording, E-book reader (TXT format only), Video playback (AVI/AMV), Alarm Clock, Calendar, and Stopwatch.
- **Full-Touch Screen:** Intuitive and easy-to-navigate interface.
- **Portable Design:** Lightweight (32g / 1.13oz) and compact (2.56 × 1.57 × 0.59 inches) with a convenient clip.




*Figure 3: Detailed diagram of the MP3 player's buttons and ports, including Power ON/OFF, Headphone Jack, Volume +/-, TF Card Slot, Previous, Next, Return, Reset, and USB Port.*

## 4. Setup

### 4.1 Charging the Device

Before first use, fully charge your Colorcool M8 MP3 Player. Connect the provided USB Type-C cable to the player's USB port and the other end to a USB power adapter (not included) or a computer's USB port. A full charge takes approximately 1.5 hours and provides up to 20 hours of music playback.




*Figure 4: Charging the MP3 player using the Type-C port.*

## 4.2 Power On/Off

- **To Power On:** Press and hold the Power ON/OFF button located on the top of the device until the screen lights up.
- **To Power Off:** Press and hold the Power ON/OFF button until the device shuts down.

## 4.3 Inserting a Micro SD Card

The Colorcool M8 has 32GB of internal memory, but you can expand it up to 128GB using a Micro SD card. Locate the TF Card Slot on the side of the device. Gently insert the Micro SD card into the slot until it clicks into place. To remove, push the card in again until it pops out.




*Figure 5: The MP3 player supports external memory expansion via a Micro SD card.*

## 5. Operating Instructions

### 5.1 Basic Navigation

The device features a full-touch screen for navigation. Swipe left/right to browse through menus and tap to select options. Physical buttons on the side control volume, track navigation, and return functions.

### 5.2 Music Playback

The Colorcool M8 supports various audio formats including MP3, WMA, APE, FLAC, WAV, DRM, and ACELP. You can manage your music files in the 'Music' folder.

- **Playing Music:** Navigate to the 'Music' icon on the main menu and tap to enter. Select your desired song, artist, or album.
- **Playback Modes:** The player supports shuffle, single loop, and sequential playback modes.




*Figure 6: The music playback interface showing song title, artist, and playback controls.*

## 5.3 Bluetooth Connectivity

Connect your MP3 player to Bluetooth headphones or speakers for wireless audio. *Please note: This device cannot pair with mobile phones.*

- **Pairing:** Go to the 'Bluetooth' menu. Select 'Search for new device' to find available Bluetooth devices. Once found, select your device to pair.




*Figure 7: The MP3 player utilizing Bluetooth 5.2 technology for stable connections to audio devices.*

Your browser does not support the video tag.

*Video 2: Demonstrates how to connect the Colorcool M8 MP3 player to Bluetooth speakers and headphones.*

### 5.4 FM Radio

To use the FM radio function, you must plug in wired headphones as they act as the antenna. The player supports common bands (87.5MHz-108MHz), Japan band (76MHz-90MHz), and European band (87.5MHz-108MHz).

- **Accessing FM Radio:** Select the 'FM Radio' icon from the main menu.
- **Scanning Stations:** Use the on-screen controls to scan for and select radio stations.




*Figure 8: User enjoying FM radio with wired headphones connected to the MP3 player.*

Your browser does not support the video tag.

*Video 3: Instructions on how to use the FM radio function by plugging in headphones as an antenna.*

### 5.5 Voice Recording

The built-in voice recorder allows you to capture audio notes, lectures, or conversations. Recordings are saved in the 'Record' folder.

### 5.6 E-book Reader

Read your favorite e-books directly on the device. The Colorcool M8 supports TXT format only. Transfer your TXT files to the 'E-book' folder on the player.

### 5.7 Other Functions

The MP3 player includes additional useful tools:

- **Alarm Clock:** Set alarms for reminders or wake-up calls.

- **Calendar:** View the current date and manage your schedule.
- **Stopwatch:** Use for timing activities.
- **Pedometer:** Track your steps (ensure the device is clipped securely to your clothing).
- **Video Playback:** Supports AVI/AMV video formats.
- **Image Viewing:** View pictures stored on the device.




*Figure 9: The multi-functional interface of the MP3 player, showcasing its diverse capabilities.*

## 6. Maintenance

- Keep the device dry. Avoid exposure to moisture or liquids.
- Clean the screen and body with a soft, dry cloth. Do not use abrasive cleaners.
- Avoid dropping the device or subjecting it to strong impacts.
- Store in a cool, dry place when not in use.

## 7. Troubleshooting

| Problem | Solution |
|---|---|
| Device does not power on. | Ensure the device is charged. Press and hold the Power ON/OFF button for a few seconds. If unresponsive, try resetting the device using the 'Reset' button (may require a pin). |
| Cannot connect to Bluetooth device. | Ensure Bluetooth is enabled on both devices. Make sure the MP3 player is in pairing mode. Keep devices within range. Remember, the MP3 player cannot pair with mobile phones. |
| FM Radio not working. | Plug in wired headphones; they serve as the antenna for FM radio reception. |
| Music files not recognized. | Check if the music files are in a supported format (MP3, WMA, APE, FLAC, WAV, DRM, ACELP). Ensure files are correctly transferred to the device's internal memory or Micro SD card. |
| Screen is unresponsive. | Try restarting the device. If the issue persists, perform a reset. |

## 8. Specifications

- **Brand:** Colorcool
- **Model Name:** M8-32GB-Black
- **Product Dimensions:** 0.59 x 1.57 x 2.56 inches
- **Item Weight:** 1.13 ounces
- **Memory Storage Capacity:** 32 GB (Internal), expandable up to 128 GB (Micro SD)
- **Connectivity Technology:** Bluetooth 5.2
- **Screen Size:** 1.8 inches
- **Supported Audio Formats:** MP3, WMA, APE, FLAC, WAV, DRM, ACELP
- **Supported Video Formats:** AVI, AMV
- **Supported E-book Format:** TXT
- **Battery:** 1 Lithium Polymer battery (included)
- **Manufacturer:** meiyu
- **Country of Origin:** China

## 9. Warranty & Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Colorcool store on Amazon: Colorcool Store.
The product comes with a 30-day return/replacement policy from the date of purchase.

© 2024 Colorcool. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0BLNPT83G**

More documents and user manuals: **https://manuals.plus/**