

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OUKITEL](#) /

› [OUKITEL WP8 Pro Rugged Smartphone User Manual](#)

## OUKITEL OUKITEL WP8 Pro

# OUKITEL WP8 Pro Rugged Smartphone User Manual

Model: OUKITEL WP8 Pro

## 1. INTRODUCTION

---

Welcome to the OUKITEL WP8 Pro User Manual. This guide provides essential information for setting up, operating, and maintaining your new rugged smartphone. The OUKITEL WP8 Pro is designed for durability and performance, featuring IP68/IP69K waterproof, dustproof, and shockproof capabilities, a 6.49-inch HD display, a 5000mAh battery, and an MT6762D Octa-Core Processor.

Please read this manual carefully before using your device to ensure proper operation and to maximize its lifespan.

## 2. SAFETY INFORMATION

---

- Do not attempt to disassemble or repair the device yourself.
- Use only original or certified chargers and accessories.
- Avoid exposing the device to extreme temperatures or direct sunlight for prolonged periods.
- Ensure all port covers are securely closed before exposing the device to water or dust.
- Dispose of the device and its battery responsibly according to local regulations.

## 3. PRODUCT OVERVIEW

---

### 3.1 Package Contents

- OUKITEL WP8 Pro Smartphone
- USB Cable
- User Manual (this document)
- SIM Ejector Tool (if applicable)

### 3.2 Device Layout

Familiarize yourself with the physical components of your OUKITEL WP8 Pro.



Figure 3.2.1: Front, back, and side view of the OUKITEL WP8 Pro, highlighting its rugged design and camera module.

- **Front:** 6.49-inch HD+ display, front camera, earpiece.
- **Back:** 16MP Triple Camera system, LED flash, fingerprint sensor, OUKITEL branding.
- **Sides:** Power button, volume buttons, customizable button, SIM/TF card slot, USB port.

## 4. SETUP

---

### 4.1 Inserting SIM/TF Card

1. Locate the SIM/TF card slot on the side of the device.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your Nano-SIM cards and/or TF card (up to 256GB) into the tray, ensuring correct orientation.
4. Gently push the tray back into the slot until it is flush with the device body. Ensure the cover is sealed for waterproofing.



Figure 4.1.1: Illustration of SIM and TF card insertion, showing dual SIM or SIM + TF card options.

## 4.2 Charging the Battery

The OUKITEL WP8 Pro comes with a 5000mAh high-capacity battery. For optimal performance, fully charge the device before first use.

1. Connect the USB cable to the phone's charging port.
2. Connect the other end of the USB cable to a power adapter and plug it into a wall outlet.
3. The charging indicator will appear on the screen.

# 5000mAh high-capacity battery

## Long-lasting power day and night

Standby	300 H	40 Hours Phone call	40 H
MP3 music	45 H	38 Hours The film	38 H



Figure 4.2.1: Visual representation of the 5000mAh battery capacity and its long-lasting power.

## 5. OPERATING YOUR SMARTPHONE

### 5.1 Power On/Off

- **Power On:** Press and hold the Power button until the OUKITEL logo appears.
- **Power Off:** Press and hold the Power button, then select "Power off" from the options.

### 5.2 Fingerprint and Face Unlock

The WP8 Pro supports both fingerprint and face unlock for quick and secure access.

1. Go to *Settings > Security > Fingerprint or Face Unlock*.
2. Follow the on-screen instructions to register your fingerprint or face data.

### 5.3 Camera Functions

Capture moments with the 16MP rear triple camera and 8MP front camera. The phone also supports underwater shooting.

**MT6762D Octa-Core Processor 4GB RAM + 64GB ROM**

MediaTek MT6762D Octa-Core processor brings the ultra-efficient 12nm chip process for boosting battery life.

**4GB RAM  
64GB ROM**

**Smooth Operation**


Let the game video not freeze when you are fighting with enemies.

**Figure 5.3.1:** Close-up of the 16MP triple camera system on the rear of the OUKITEL WP8 Pro.

1. Open the Camera app.
2. Select desired mode (Photo, Video, Beauty, Bokeh, More).
3. Tap the shutter button to capture.

## 5.4 NFC Functionality

The OUKITEL WP8 Pro supports NFC for convenient mobile payments (Google Pay) and data transfer.



## Cashless Life With Secure NFC

With multi-function NFC, WP8 Pro supports Google Pay, on-vehicle payment and so on.



## Multi-functional Toolbox

There are compass, noise test, level, magnifying glass, protractor, plumb, alarm bell, etc. in the application toolbox to meet your needs in different scenarios

GLONASS 

GPS Navigation 

Figure 5.4.1: Demonstrating NFC payment functionality with the OUKITEL WP8 Pro.

1. Ensure NFC is enabled in *Settings > Connected devices > NFC*.
2. For payments, open your Google Pay app and follow instructions.
3. To transfer data, touch the back of your phone to another NFC-enabled device.

### 5.5 Android 10 Features

The device runs on Android 10, offering an intuitive user interface and enhanced privacy features.

# Dual LTE Connect to Mobile Network

North & South American Version:

FDD-LTE: B /2 /4 /5 /7 /12/17 /28A /28B  
WCDMA: B /2 /4 /5  
GMS:B2/B3/B5/B8

EU & Japan Version:

FDD-LTE: B1/B3/B7/B8/B19/B20  
WCDMA: B1 /8  
GMS:B2/B3/B5/B8



## The Newest Android 10, Fast And Smooth

The newly upgraded Android 10 operating system can protect your privacy more effectively and run applications quickly



Figure 5.5.1: Screenshots illustrating the Android 10 interface, including game mode and dark theme.

## 6. MAINTENANCE

### 6.1 Waterproofing and Durability

The OUKITEL WP8 Pro is IP68 and IP69K rated for water, dust, and shock resistance. To maintain its rugged features:




Figure 6.1.1: Image demonstrating the ruggedness and waterproof capabilities of the OUKITEL WP8 Pro, including MIL-STD-810G certification.

- Always ensure the USB port cover and SIM tray are fully sealed before exposing the phone to water or dust.
- After exposure to water, especially saltwater, rinse the phone with clean fresh water and dry thoroughly before charging.
- Avoid dropping the phone from heights exceeding 1.5 meters, despite its shockproof design.

## 6.2 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body. For stubborn marks, a slightly damp cloth can be used. Avoid harsh chemicals or abrasive materials.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Phone does not turn on	Battery is depleted.	Charge the phone for at least 30 minutes before attempting to power on.
Cannot connect to Wi-Fi	Incorrect password or out of range.	Verify Wi-Fi password, move closer to the router, or restart the router.
Poor call quality	Weak signal or network issue.	Move to an area with better signal, restart the phone, or contact your carrier.
NFC not working	NFC is disabled or incorrect positioning.	Ensure NFC is enabled in settings and position the phone correctly over the reader.

## 8. SPECIFICATIONS

---

Feature	Detail
Model	OUKITEL WP8 Pro
Dimensions	7.01 x 3.07 x 0.47 inches
Weight	9.2 ounces (260 Grams)
Display	6.49-inch HD+ (2340 x 1080) Corning Gorilla Glass
Processor	MT6762D Octa-Core Processor (MediaTek MT8125, 2 GHz)
RAM	4GB
Storage	64GB ROM (expandable up to 256GB via TF card)
Battery	5000mAh Lithium Polymer (40 hours talk time)
Rear Camera	16MP Triple Camera
Front Camera	8MP
Operating System	Android 10.0
Connectivity	NFC, Dual SIM, GPS
Durability	IP68 Waterproof, Dustproof, Shockproof (MIL-STD-810G)

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the official OUKITEL website or contact your point of purchase. Keep your proof of purchase for warranty claims.

You can also find additional support and FAQs on the [OUKITEL Store on Amazon](#).

For a PDF version of the Instructions for Use, please visit: [OUKITEL WP8 Pro IFU \(PDF\)](#)

## 10. OFFICIAL PRODUCT VIDEOS

---

Watch the official product video for a visual guide to the OUKITEL WP8 Pro.

*No official seller videos available for embedding based on provided data.*

© 2023 OUKITEL. All rights reserved.