

NIPELL A66

NIPELL A66 Wireless Earbuds User Manual

MODEL: A66

Brand: NIPELL

1. INTRODUCTION

This manual provides detailed instructions for the NIPELL A66 Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper operation and to maximize your listening experience. These earbuds feature Bluetooth 5.2 connectivity, an 1800mAh charging case with phone charging function, and IPX5 water resistance.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- Bluetooth Headphones (2x)
- Charging Case (1x)
- Mini USB Type-C Cable (1x)
- Earcaps (8x: XS, S, M, L sizes)
- User Manual (1x)

3. PRODUCT OVERVIEW



Figure 3.1: NIPELL A66 Wireless Earbuds and Charging Case.




Figure 3.2: Earbud Touch Control Area, Indicator Light, Earbuds Microphone, Eartip, Charging Case Power Display, Earbuds Power Display, and USB C & A Port.

The NIPELL A66 earbuds are designed for comfort and high-quality audio. The charging case features an LED digital display to show battery levels for both earbuds and the case itself. Each earbud has a touch control area for easy operation.

4. SETUP AND PAIRING

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB Type-C cable to the charging case and a power source. The LED digital display on the case will indicate the charging status.

LED Digital Display



Figure 4.1: LED Digital Display showing individual earbud and case battery levels.

4.2 Pairing with Your Device

The earbuds feature one-step reconnection. After the first successful connection, simply open the lid of the charging case to automatically reconnect to your device. No need to remove the earbuds from the case for reconnection.

1. Ensure the earbuds are in the charging case and the case is charged.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "A66" from the list of devices to connect.
5. Once connected, a voice prompt will confirm successful pairing.

Opening The Lid to Auto-Reconnect

Take Out to Use Immediately



Digital Power Display



Smart Touch Control



1800mAh Charging Case



Stable Connection



Figure 4.2: Auto-reconnect feature upon opening the charging case lid.

5. OPERATING INSTRUCTIONS

The NIPELL A66 earbuds feature intuitive touch controls for various functions:

Function	Action
Power On/Off	Long tap (either earbud)
Play/Pause Music	One tap (either earbud)
Next Track	Double tap Right earbud
Previous Track	Double tap Left earbud
Answer/Hang Up Call	Double tap (either earbud)
Reject Call	Long tap (either earbud)
Volume Up	Long tap Right earbud
Volume Down	Long tap Left earbud
Activate Voice Assistant (Siri)	Quick triple tap (either earbud)

Video 5.1: Overview of NIPELL Wireless Headphones features and controls.

6. CHARGING

6.1 Earbud and Case Charging

The 1800mAh charging case provides up to 11 full charges for the earbuds, offering 6-8 hours of continuous playback per charge. This allows for up to 88-132 hours of total playtime by alternating earbud use.

With 1800mAh Strong Battery Case



Figure 6.1: 1800mAh strong battery case providing extended playtime.

6.2 Cell Phone Charging Function

The charging case is equipped with a USB-A port, allowing it to function as a portable power bank for your cell phone or other electronic devices in emergencies. This feature helps prevent your phone from running out of power unexpectedly.

Emergency Rechargeable Battery

⚠️ Away from the anxiety of sudden phone shutdown



Figure 6.2: Emergency rechargeable battery function for cell phones.

7. WATER RESISTANCE (IPX5)

The NIPELL A66 earbuds are rated IPX5 water-resistant, meaning they can withstand sweat and light splashes of water. This makes them suitable for use during sports or walking in light rain.

Important Note:

- Do not use the earbuds in the shower or while swimming.
- The charging case is NOT water-resistant.

8. COMFORT AND FIT

The earbuds are designed for a comfortable in-ear fit, dispersing pressure in the ear canal while remaining stable. Four sizes of ear tips (XS, S, M, L) are provided to ensure the best fit for your ears.



Figure 8.1: Comfortable in-ear design with various ear tip sizes for optimal fit.



Figure 8.2: Proper earbud insertion and examples of suitable activities.

9. MAINTENANCE

To ensure the longevity and optimal performance of your NIPPELL A66 Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Drying Wet Earbuds:** If the earbuds get wet, gently shake out any excess water. Tap-dry each earbud with a soft towel and allow them to air dry completely before placing them back into the charging case. This prevents damage to the charging contacts and internal components.
- **Storage:** Store the earbuds in their charging case when not in use to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.

10. TROUBLESHOOTING

If you encounter issues with your NIPPELL A66 Wireless Earbuds, refer to the solutions below:

10.1 Connection Issues (Earbuds not pairing or connecting to device)

1. First, delete any existing Bluetooth pairing name "A66" for the headset on your mobile phone.
2. Then, turn off your phone's Bluetooth function and place both earbuds back into the charging box.

3. After 10 seconds, open the charging case. The left earbud should flash green and blue rapidly, indicating it is ready to pair.
4. Turn on your phone's Bluetooth to search for and pair with "A66".

10.2 Only One Earbud Has Sound

Please check if both earbuds are turned on. Long tap both the Right and Left touch control areas to ensure both earbuds are powered on.

11. SPECIFICATIONS

Feature	Detail
Model Name	Wireless Earbuds (A66)
Connectivity Technology	Wireless (Bluetooth 5.2)
Bluetooth Range	10 Meters / 33 Feet
Battery Life (Earbuds)	6-8 hours per charge
Total Playtime (with case)	Up to 88-132 hours
Charging Case Battery	1800mAh
Charging Time (Earbuds)	1 Hour
Charging Time (Case)	2.5 Hours
Water Resistance Level	IPX5 (Earbuds only)
Frequency Response	20 Hz - 20,000 Hz
Sensitivity	114 dB
Control Type	Touch Control
Item Weight (Earbuds)	0.212 ounces (approx. 6g per earbud)
Material	Polycarbonate (PC), Silicone, Plastic, Acrylonitrile Butadiene Styrene (ABS)

12. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official NIPELL website. Keep your purchase receipt as proof of purchase for any warranty claims.

