

[manuals.plus](#) /› [FORIOUS](#) /› [FORIOUS Kitchen Faucet with Pull-Down Sprayer Instruction Manual - Model FRKF25G](#)

FORIOUS FRKF25G

FORIOUS Kitchen Faucet with Pull-Down Sprayer Instruction Manual

Model: FRKF25G | Brand: FORIOUS

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your FORIOUS Kitchen Faucet with Pull-Down Sprayer. Please read this manual thoroughly before installation and use to ensure proper function and longevity of the product.

2. SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks.
- Do not use abrasive cleaners or harsh chemicals on the faucet's finish, as this may damage it.
- If you are unsure about any step, consult a qualified plumber.

3. PACKAGE CONTENTS

Verify that all components are present before installation.

- FORIOUS Kitchen Faucet Assembly
- Hot and Cold Water Supply Hoses
- Mounting Hardware (nut, washer)
- Weight for Pull-Down Hose
- Quick Connect Adapter
- Instruction Manual (this document)



Image: The complete FORIOUS kitchen faucet assembly in a polished gold finish.

4. SPECIFICATIONS

Feature	Detail
Brand	FORIOUS
Model Number	FRKF25G (PLKF25)
Color	Polished Gold
Material	Stainless Steel
Dimensions (L x W x H)	18 x 5 x 30 cm (7.09 x 1.97 x 11.81 inches)
Weight	1.9 kg (4.19 lbs)
Installation Method	Single Hole, Deck Mounted

Feature	Detail
Flow Rate	1.5 Gallons per Minute
Number of Handles	1
Handle Location	Right
Spout Height	26 cm (10.28 inches)
Spout Reach	18.8 cm (7.4 inches)
Special Features	Pull-down sprayer, 360° swivel, Adjustable temperature limit, Dual function spray
Recommended Use	Kitchen
Country of Origin	China




Image: Detailed diagram illustrating the dimensions of the faucet and the G3/8 hose connections.

5. INSTALLATION INSTRUCTIONS

5.1 Before You Begin

1. Turn off the water supply at the main valve.
2. Clear the area under the sink.
3. Remove your old faucet if applicable.

5.2 Faucet Assembly

1. Insert the faucet body into the single hole on your sink or countertop.
2. From underneath the sink, secure the faucet with the rubber washer, metal washer, and mounting nut. Tighten firmly by hand, then use a wrench for a final snug turn.
3. Connect the hot and cold water supply lines to your angle stops. Ensure the hot water line connects to the 'H' marked hose and the cold water line to the 'C' marked hose.
4. Attach the quick-connect hose from the pull-down sprayer to the corresponding port on the faucet's main body. Ensure it clicks securely into place.
5. Install the weight onto the pull-down hose, approximately 6 inches (15 cm) from the bottom of the loop, to ensure smooth retraction.



Image: Visual guide demonstrating the quick-connect hose attachment and the process of securing the faucet with the mounting nut.



LA SANTÉ AVANT TOUT
Tuyau PEX de qualité alimentaire

Image: Close-up view of the food-grade PEX hose, highlighting its durable and safe construction.

5.3 Post-Installation

1. Turn on the main water supply slowly.
2. Check for any leaks at all connection points. Tighten if necessary.
3. Remove the aerator and flush the faucet for a few minutes to clear any debris from the water lines. Reinstall the aerator.

6. OPERATING INSTRUCTIONS


6.1 Water Flow and Temperature Control

The single lever handle controls both water flow and temperature.

- Lift the handle to turn on the water and increase flow. Push down to turn off.
- Move the handle to the left for hot water and to the right for cold water.

Faciles à Nettoyer

Buses en Silicone



Cartouche en Céramique

Contrôle Flexible de la Température

Pivote à 360°

Tâche Sans souci



Image: Illustration of the faucet's 360-degree swivel capability, easy-to-clean silicone nozzles, and the durable ceramic cartridge for flexible temperature control.

6.2 Pull-Down Sprayer Operation

The pull-down sprayer offers extended reach and two spray modes.

- Gently pull the spray head from the spout to extend the hose.
- Press the button on the spray head to switch between the two spray modes:
 - **Stream Mode:** For filling pots and general washing.
 - **Spray Mode:** A powerful rinse for heavy-duty cleaning.
- After use, the hose will retract automatically due to the installed weight.



Image: The FORIOUS kitchen faucet with its pull-down sprayer extended, demonstrating its 24-inch (61 cm) flexible hose for versatile use.



COURANT



PULVÉRISATION

Image: A visual comparison of the two spray modes: a steady stream for filling, and a powerful spray for rinsing, both operating at 1.5 gallons per minute (GPM).



Image: The faucet in action, illustrating its efficiency for quick cleaning of dishes and rapid filling of containers.

7. MAINTENANCE AND CARE

- Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- Avoid Abrasives:** Do not use abrasive cleaners, steel wool, or harsh chemicals (e.g., ammonia, bleach) as they can damage the finish.
- Nozzle Cleaning:** The silicone nozzles are designed for easy cleaning. Simply rub them with your finger to remove mineral buildup.
- Leak Prevention:** Periodically check all connections for tightness to prevent leaks.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or mineral buildup in nozzles.	Remove and clean the aerator. Rub silicone nozzles to clear debris. Check water supply valves are fully open.

Problem	Possible Cause	Solution
Leaks at Connections	Loose connections or damaged washers.	Ensure all connections are tightened properly. Check and replace washers if damaged.
Sprayer Does Not Retract	Weight on hose is misplaced or obstructed.	Adjust the position of the weight on the pull-down hose. Ensure the hose path under the sink is clear of obstructions.
Water Temperature Issues	Hot/cold supply lines reversed or water heater issues.	Verify hot and cold lines are connected correctly. Check your water heater settings.

9. WARRANTY AND SUPPORT

FORIOUS products are designed for durability and reliability. This faucet comes with a limited warranty. For specific warranty details, please refer to the warranty card included with your purchase or contact FORIOUS customer support.

For technical assistance, replacement parts, or any questions regarding your FORIOUS Kitchen Faucet, please contact our customer support team.

- **Email Support:** Available 24 hours.
- **Phone Support:** Available 12 hours.




Image: An illustration emphasizing the faucet's durability, leak-free design, and lifetime warranty.

Visit the official FORIOUS store for more information: [FORIOUS Store](#)