

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [YABER](#) /

> [YABER U5 Mini Projector User Manual](#)

YABER U5

YABER U5 Mini Projector User Manual

Model: U5 | Brand: YABER

[Introduction](#) [What's in the Box](#) [Product](#)
[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your YABER U5 Mini Projector. Please read these instructions thoroughly before operating the device and retain them for future reference.

2. WHAT'S IN THE BOX

Upon opening the package, verify that all items listed below are present and in good condition.

- YABER U5 Mini Projector
- Power Adapter
- Remote Control
- HDMI Cable
- AV Cable
- Tripod
- Carrying Bag
- User Manual



Image: The YABER U5 Mini Projector shown with its included tripod and carrying bag, illustrating the complete package contents.

3. PRODUCT OVERVIEW

The YABER U5 Mini Projector is a compact and versatile device designed for various multimedia applications. It features advanced connectivity options and a user-friendly interface.

Key Features:

- **5G WiFi & Bluetooth 5.1:** Provides stable and fast wireless connectivity for streaming and audio output.
- **1080P 4K Support:** Delivers high-definition visuals, supporting up to 4K input for clear images.
- **Portable Design:** Compact and lightweight, ideal for both indoor and outdoor use.
- **Multiple Inputs:** Compatible with Phone, HDMI, VGA, and TV Stick devices.
- **80 ISO Lumens:** Offers adequate brightness for various viewing environments.
- **300-inch Large Screen Support:** Capable of projecting a large display for an immersive experience.
- **-50% Zoom Function:** Allows adjustment of screen size without moving the projector.




Image: The YABER U5 Mini Projector displaying a vibrant, high-definition image on a wall, highlighting its 1080P support.



Image: The YABER U5 Mini Projector wirelessly connected to a laptop via 5G WiFi, demonstrating its dual-band connectivity for smooth streaming.

4. SETUP

4.1 Initial Placement

Place the projector on a stable, flat surface. Ensure there is adequate ventilation around the device. The distance from the projection surface (wall or screen) will determine the image size. Use the included tripod for optimal positioning.

4.2 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a suitable electrical outlet.
3. The power indicator light on the projector will illuminate.

4.3 Focusing and Keystone Correction

After powering on, adjust the focus ring on the projector lens until the image is clear. If the image appears trapezoidal, use the keystone correction dial (usually located near the lens or on the top panel) to adjust the image geometry until it is rectangular.

5. OPERATION

5.1 Input Source Selection

Use the remote control or the buttons on the projector to navigate the main menu. Select the desired input source (e.g., HDMI, USB, AV, WiFi Screen Mirroring) from the options displayed.

5.2 Wireless Connectivity (5G WiFi)

1. Select "Screen Mirroring" or "WiFi" from the input source menu.
2. Follow the on-screen instructions to connect to your home WiFi network.
3. For screen mirroring from a smartphone or tablet, ensure your device is connected to the same WiFi network as the projector and enable its screen mirroring feature (e.g., AirPlay for iOS, Miracast for Android).

5.3 Bluetooth Audio Output

1. Access the Bluetooth settings in the projector's menu.
2. Enable Bluetooth and search for available devices.
3. Select your Bluetooth speaker or headphones from the list to pair.




Image: The YABER U5 Mini Projector wirelessly connected to a Bluetooth speaker, illustrating its capability for immersive audio experiences.

6. MAINTENANCE

6.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid using abrasive cleaners or excessive force, which can scratch the lens.

6.2 Cleaning the Projector Body

Wipe the exterior of the projector with a soft, dry cloth. Do not use liquid cleaners directly on the device. Ensure ventilation ports are free from dust and obstructions.

6.3 Storage

When not in use, store the projector in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures. This protects the device from dust and potential damage.

7. TROUBLESHOOTING

7.1 No Image or Distorted Image

- **Check Power:** Ensure the projector is properly connected to power and turned on.
- **Input Source:** Verify the correct input source is selected (HDMI, USB, AV, etc.).
- **Focus/Keystone:** Adjust the focus ring and keystone correction dial for a clear, rectangular image.
- **Cable Connection:** Ensure all cables (HDMI, AV) are securely connected to both the projector and the source device.

7.2 No Sound

- **Volume:** Check the volume settings on both the projector and the source device.
- **Mute:** Ensure neither the projector nor the source device is muted.
- **Bluetooth:** If using Bluetooth, confirm the projector is correctly paired with your audio device.
- **Audio Output:** Verify the audio output settings on your source device.

7.3 WiFi Connection Issues

- **Network Range:** Ensure the projector is within range of your WiFi router.
- **Password:** Double-check the WiFi password for accuracy.
- **Router Restart:** Try restarting your WiFi router.
- **Interference:** Minimize interference from other wireless devices.

8. SPECIFICATIONS

Feature	Detail
Brand	YABER
Model	U5

Product Dimensions	8 x 6.2 x 2.9 inches
Item Weight	2.2 pounds
Display Resolution	1920 x 1080 (Full HD)
Connectivity Technology	Bluetooth 5.1, HDMI, USB, Wi-Fi (5G & 2.4G Dual Band)
Special Feature	80 ISO Lumens
Recommended Uses	Home Cinema

9. WARRANTY & SUPPORT

For warranty information and technical support, please refer to the official YABER website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. Optional protection plans may be available for extended coverage. Please consult your retailer for details on available plans.