

LEHOM G6M

LEHOM G6M Heavy Duty Clothes Rack User Manual

Model: G6M | Brand: LEHOM

1. INTRODUCTION

Thank you for choosing the LEHOM G6M Heavy Duty Clothes Rack. This portable garment rack is designed to provide a compact and efficient closet organization solution for your bedroom or any living space. Constructed from durable metal, it offers freestanding storage with multiple shelves and hanging rods to accommodate a variety of clothing items and accessories. Please read this manual carefully before assembly and use to ensure proper installation and long-lasting performance.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before loading the rack.
- Do not exceed the maximum load capacity of 700 LBS (evenly distributed). Each hanging rod holds up to 70 LBS, and each wire shelf holds 100 LBS.
- For added stability, especially on uneven ground or with heavy loads, utilize the adjustable leveling feet and consider anchoring the unit to a wall using the provided anti-tip straps.
- Keep small parts away from children during assembly.
- Avoid climbing on the rack or allowing children to play on or around it.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- 2 x Support Rail (etc.)
- 3 x Long Clothes Hanger Rod
- 4 x Large Shelf
- 4 x Small Shelf
- Assembly Hardware (connectors, leveling feet, anti-tip straps)



Figure 3.1: Overview of the LEHOM G6M Heavy Duty Clothes Rack, showing its various shelves and hanging rods.

4. SETUP AND ASSEMBLY

The LEHOM G6M Garment Rack is designed for easy assembly with no tools required. Follow these steps for a smooth setup:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging and lay them out. Refer to the "Package Contents" section to ensure all parts are present.

MULTIPLE WAYS TO USE




Figure 4.1: The garment rack offers multiple configuration options, including straight-lined or L-shaped setups, to fit various spaces.

- 2. Assemble Vertical Poles:** Connect the pole sections. Ensure the slip-sleeve locking system is correctly aligned. The top of each pole section is indicated for proper orientation.



Figure 4.2: Detail showing how pole sections connect and the adjustable height mechanism for shelves. A small gap is normal at connection points.

- 3. Attach Shelves:** Slide the shelves onto the poles. The slip-sleeve locking system allows shelves to be adjusted in 1-inch increments. You can conveniently adjust the shelf height according to the objects you

need to store.



Figure 4.3: Shelves are secured by sliding them over the plastic clips on the poles.

- 4. Install Hanging Rods:** Secure the long clothes hanger rods between the appropriate poles. These are ideal for hanging suits, coats, pants, and shirts.



Figure 4.4: The design includes durable hanging rods and adjustable shelves for versatile storage.

- 5. Adjust Leveling Feet:** The storage shelves can be placed on uneven ground using the adjustable leveling feet at the base of each pole.



Figure 4.5: Adjustable leveling feet ensure stability on various floor surfaces.

- 6. Secure with Anti-Tip Straps (Optional but Recommended):** For extra sturdiness and safety, especially in homes with children or pets, anchor the rack to your wall using the provided anti-tip straps.



Figure 4.6: Anti-tip straps provide additional stability by securing the rack to a wall.

Assembly Video Guide:

Your browser does not support the video tag.

Video 4.1: Official LEHOM G6 Garment Rack assembly and usage demonstration. This video illustrates various configurations and how to utilize the rack's features effectively.

5. OPERATING INSTRUCTIONS

The LEHOM G6M Clothes Rack is designed for versatile use. Here are some tips for optimal operation:

- **Hanging Clothes:** Utilize the three long clothes hanger rods for hanging garments such as dresses, coats, shirts, and pants. Distribute weight evenly across the rods to maintain stability.
- **Shelf Storage:** The wire shelves are perfect for folded clothing, storage bins, shoes, or other accessories. Adjust their height as needed to accommodate taller items.
- **Customization:** The modular design allows for various configurations (straight-lined or L-shape) to best suit your space and storage needs. You can also remove shelves if not needed.

STORAGE RACKS CAN BE ADJUSTED ACCORDING TO YOUR NEEDS



Figure 5.1: Example of the garment rack fully utilized with hanging clothes, folded items, and storage boxes on shelves.

6. MAINTENANCE

To ensure the longevity and appearance of your LEHOM G6M Clothes Rack, follow these simple maintenance guidelines:

- **Cleaning:** The black-coated carbon steel surface is rust-resistant and easy to clean. Wipe down the rack with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Regular Checks:** Periodically check all connections and fasteners to ensure they remain tight and secure. Re-tighten if necessary.

- **Weight Distribution:** Always distribute weight evenly across the shelves and hanging rods to prevent stress on the frame and maintain stability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Uneven floor surface; loose connections; overloaded.	Adjust the leveling feet until the rack is stable. Check and tighten all pole and shelf connections. Ensure weight is evenly distributed and not exceeding capacity. Consider using anti-tip straps.
Shelves are difficult to adjust.	Plastic clips not properly seated; too much weight on the shelf.	Ensure the plastic clips are fully snapped into the grooves on the poles. Remove items from the shelf before adjusting its height.
Parts do not fit together.	Incorrect orientation of parts; manufacturing defect.	Double-check the assembly instructions and ensure parts are oriented correctly (e.g., "TOP" indicator on poles). If parts are damaged or clearly defective, contact customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	LEHOM
Model	G6M
Material	Carbon Steel, Chrome
Color	G6M-Black
Product Dimensions (D x W x H)	13.7"D x 70.4"W x 76.8"H
Installation Type	Free Standing
Special Feature	Portable, Adjustable, Heavy Duty
Load Capacity (Total)	700 Pounds (evenly distributed)
Load Capacity (Per Hanging Rod)	70 Pounds
Load Capacity (Per Wire Shelf)	100 Pounds
Assembly Required	Yes (No tools required)

WEIGHT CAPACITY: 700LBS




Figure 8.1: Detailed dimensions and maximum weight capacity for the LEHOM G6M Garment Rack.

9. WARRANTY AND SUPPORT

LEHOM is committed to providing high-quality products and excellent customer service. For any questions, concerns, or issues regarding your LEHOM G6M Heavy Duty Clothes Rack, please contact our professional customer service team. We are always here to assist you, both before and after your purchase. Please refer to your purchase documentation for specific warranty details and contact information.