YING RAY A2-2022110716(HUO)

YING RAY Replacement Remote Control Instruction Manual

For Twin Star Electric Fireplace Heaters

Introduction

This instruction manual provides detailed guidance for the setup, operation, and maintenance of your YING RAY replacement remote control for Twin Star Electric Fireplace Heaters. Please read this manual thoroughly before use to ensure proper functionality and longevity of your device.

Important Note: This remote control is designed as a replacement for specific Twin Star Electric Fireplace Heater models. It is not a universal remote. Please verify your fireplace model or existing remote control model against the compatibility list provided in this manual before attempting to use it.



Figure 1: Front view of the YING RAY Replacement Remote Control.

Product Compatibility

This YING RAY replacement remote control is compatible with the following Twin Star Electric Fireplace Heater models:

- 231RM7094-W500
- 23II800GRA
- 2311800GRA
- 23IRM1500
- 23I1RM1500
- 23IRM1500-O107
- 231RM1500-O107
- And other models in the 23IRM1500 series.

Setup

Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Always replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

Operating Instructions

Remote Control Functions

Familiarize yourself with the buttons on your remote control and their corresponding functions:



Figure 2: Button layout of the YING RAY Replacement Remote Control.

- **Power Button** ( ): Turns the fireplace heater ON or OFF.
- **Flame Button** ( ): Controls the flame effect settings (e.g., intensity, on/off). Refer to your fireplace's manual for specific flame options.
- **Timer Button** ( ): Activates or adjusts the sleep timer function. Press repeatedly to cycle through available timer settings.
- **Temperature Up Button** (**▲ TEMP**): Increases the desired temperature setting.
- **Temperature Down Button** (**▼ TEMP**): Decreases the desired temperature setting.

Point the remote control directly at the infrared receiver on your electric fireplace heater for optimal signal transmission. Ensure there are no obstructions between the remote and the fireplace.

Maintenance

Battery Replacement

When the remote control's range decreases or it becomes unresponsive, it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or wet cloths, as these can damage the remote's finish or internal components.

Troubleshooting

If you experience issues with your YING RAY replacement remote control, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Remote control is unresponsive.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Limited operating range.	Low battery power; Obstruction between remote and fireplace.	Replace batteries. Ensure a clear line of sight to the fireplace's IR receiver.
Specific functions not working.	Remote not compatible with all fireplace features; Fireplace issue.	Confirm compatibility with your specific fireplace model. Consult your fireplace's manual.

Specifications

- **Model Number:** A2-2022110716(HUO)
- **Brand:** YING RAY
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** 0.39 x 0.2 x 0.08 inches (approximate)
- **Item Weight:** 1.06 ounces (approximate, without batteries)
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

Warranty Information

This YING RAY replacement remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper battery installation.
For warranty claims or technical support, please contact your retailer or the manufacturer directly with your purchase details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question