

[manuals.plus](#) /› [Philips](#) /› [Philips Mini Bluetooth Speaker \(Model TAS1505\) - Instruction Manual](#)

Philips TAS1505

Philips Mini Bluetooth Speaker (Model TAS1505) - Instruction Manual

Brand: Philips | Model: TAS1505

1. INTRODUCTION

Thank you for choosing the Philips Mini Bluetooth Speaker. This portable speaker is designed to deliver clear and crisp audio with robust features for various environments. Its compact size, durable construction, and IPX7 waterproof rating make it ideal for outdoor adventures, travel, and everyday use.

What's in the Box:

- Philips Mini Bluetooth Speaker (TAS1505)
- USB Type-C Charging Cable
- Carrying Strap
- Quick Start Guide (not included in this digital manual)



Image: Front view of the Philips Mini Bluetooth Speaker, showcasing its compact design and speaker grille.

2. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before using this product to prevent injury or damage. Keep these instructions for future reference.

- Do not expose the speaker to extreme temperatures (above 45°C or below 0°C).
- Do not disassemble, repair, or modify the product. This may cause fire, electric shock, or other hazards.
- Keep the speaker away from water and liquids when the charging port cover is open. Ensure the cover is securely closed when near water.

- Avoid prolonged exposure to very high volume levels, which may cause hearing damage.
- Use only the provided USB Type-C cable for charging.
- Keep out of reach of children.

3. SETUP

3.1 Charging the Speaker

Before first use, fully charge the speaker. A full charge takes approximately 8 hours.

1. Locate the USB Type-C charging port on the speaker. It is usually protected by a rubber flap.
2. Open the rubber flap and connect the provided USB Type-C cable to the speaker's charging port.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. Once fully charged, the indicator light may change color or turn off.
5. After charging, securely close the rubber flap to maintain the speaker's IPX7 waterproof rating.

3.2 Pairing with a Bluetooth Device

The speaker uses Bluetooth 5.3 for a stable connection up to 10 meters (33 feet).

1. Press and hold the Power button for 2 seconds to turn it on. A sound prompt will indicate it's powered on, and the Bluetooth indicator light will start flashing, indicating pairing mode.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Philips TAS1505" from the list of devices.
4. Once successfully paired, the Bluetooth indicator light on the speaker will stop flashing and remain solid, and you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.



Image: Side view of the Philips Mini Bluetooth Speaker, illustrating its compact dimensions of 2.5"D x 2.5"W x 3.07"H.

4. OPERATING THE SPEAKER

4.1 Basic Controls

The speaker features intuitive touch controls for easy operation.

- **Power On/Off:** Press and hold the Power button for 2 seconds.
- **Play/Pause:** Press the Play/Pause button once to play or pause music.
- **Volume Up:** Press the '+' button to increase volume. Press and hold for continuous volume increase.

- **Volume Down:** Press the '-' button to decrease volume. Press and hold for continuous volume decrease.
- **Next Track:** Press and hold the '+' button (or a dedicated next track button if available, refer to quick start guide).
- **Previous Track:** Press and hold the '-' button (or a dedicated previous track button if available, refer to quick start guide).

4.2 Handling Phone Calls

With its built-in microphone, the speaker allows for hands-free calling.

- **Answer Call:** Press the Play/Pause button once when a call comes in.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds when a call comes in.

Your browser does not support the video tag.

Video: A short demonstration of the Philips Mini Bluetooth Speaker in an outdoor setting, highlighting its portability and sound output.

5. MAINTENANCE

5.1 Cleaning

- Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the charging port cover is closed before cleaning with a damp cloth.

5.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery every few months to maintain its lifespan.

6. TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

- **No Power:** Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
- **No Sound:** Check the volume level on both the speaker and your connected device. Ensure the speaker is correctly paired via Bluetooth.
- **Bluetooth Disconnection/Cannot Pair:** Make sure the speaker is within the 10-meter Bluetooth range of your device. Turn off and on Bluetooth on your device, then try re-pairing. Ensure no other devices are interfering with the Bluetooth signal.
- **Poor Sound Quality:** Move the speaker closer to your device. Ensure there are no obstructions between the speaker and the device. Check the audio source quality.

7. SPECIFICATIONS

Feature	Detail
Model Name	TAS1505

Speaker Type	Outdoor
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters
Audio Output Mode	Mono
Speaker Maximum Output Power	3 Watts
Power Source	Battery Powered
Battery Capacity	480 Milliamp Hours
Play Time	Up to 8 Hours
Charging Time	8 Hours
Water Resistance Level	IPX7 Waterproof (up to 1m deep for 30 minutes)
Product Dimensions	2.5"D x 2.5"W x 3.07"H
Item Weight	7 ounces

8. WARRANTY AND SUPPORT




This Philips Mini Bluetooth Speaker comes with a Limited Warranty. For detailed information regarding warranty terms, conditions, and how to obtain support, please visit the official Philips website or contact their customer service directly.

For further assistance or technical support, please refer to the contact information provided in your product's packaging or on the Philips support website.

© 2024 Philips. All rights reserved.

Related Documents - TAS1505

	<p>Philips TAS1505 Wireless Speaker User Manual Setup, Bluetooth, Specs</p> <p>User manual for the Philips TAS1505 wireless speaker, providing detailed instructions on setup, Bluetooth connectivity, operation, product specifications, troubleshooting, and safety guidelines.</p>
---	---

	<p>Philips TAS1505 Wireless Speaker User Manual</p> <p>Comprehensive user manual for the Philips TAS1505 wireless speaker, covering setup, Bluetooth pairing, operation, product information, and troubleshooting. Learn how to charge, connect, and enjoy your audio.</p>
	<p>Philips TAS1505 Wireless Speaker Quick Start Guide</p> <p>Concise guide to setting up and using the Philips TAS1505 wireless speaker, covering charging, power, Bluetooth pairing, and safety information.</p>
	<p>Philips Shaver 3000X Series X3003/02: Electric Wet & Dry Shaver with SkinProtect Technology</p> <p>Explore the Philips Shaver 3000X Series (X3003/02), an electric wet and dry shaver designed for a comfortable, clean shave. Features include 27 self-sharpening PowerCut Blades, SkinProtect technology, a pop-up trimmer, 40-minute cordless runtime, and IPX7 waterproofing. Learn about its specifications, accessories, and user-friendly design.</p>
	<p>Philips Shaver 3000 Series S3881/00: Wet & Dry Electric Shaver for Fast, Smooth Shaves</p> <p>Discover the Philips Shaver 3000 Series (S3881/00), a wet & dry electric shaver designed for a fast, smooth, and comfortable shave, even on sensitive skin. Features 6D Flex Heads, PowerCut Blades, SkinGlide coating, and 50-minute runtime.</p>
	<p>Philips Shaver Serie 3000X Wet & Dry X3003/00: Rasatura Precisa e Confortevole</p> <p>Scopri il rasoio elettrico Philips Shaver Serie 3000X Wet & Dry (X3003/00) con tecnologia SkinProtect per una rasatura precisa e confortevole. Caratteristiche: lame PowerCut, Wet & Dry, 40 minuti di autonomia, ricarica USB-A, impermeabile IPX7.</p>