

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA Micke Desk - White 56 inch x 20 inch 403.542.78](#)

IKEA

IKEA Micke Desk - Product Instruction Manual

Model: 403.542.78

INTRODUCTION

Thank you for choosing the IKEA Micke Desk. This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your new desk. Please read these instructions carefully before beginning assembly and keep them for future reference.

PRODUCT OVERVIEW

The IKEA Micke Desk is designed for functionality and simplicity, offering a practical workspace solution for homes and offices. Its compact design and integrated storage make it suitable for various environments.



This image displays the IKEA Micke Desk, a white rectangular desk featuring two integrated drawers and a cable

management opening on the top right corner. The desk has a clean, minimalist design with a solid panel leg on the left and a U-shaped steel leg on the right.

Key Features:

- Clean and simple design, suitable for various spaces.
- Integrated cable management to keep wires organized.
- Two spacious drawers with stoppers to prevent accidental removal.
- Durable construction with scratch-resistant surfaces.
- Versatile leg attachment, allowing placement flexibility.

SPECIFICATIONS

| Attribute | Detail |
|-----------------------------|---|
| Brand | IKEA |
| Model Number | 403.542.78 |
| Product Dimensions (Width) | 56.1 inches (142 cm) |
| Product Dimensions (Depth) | 19.7 inches (50 cm) |
| Product Dimensions (Height) | 29.5 inches (75 cm) |
| Maximum Load | 110.2 lbs (50 kg) |
| Number of Drawers | 2 |
| Main Material | Engineered Wood (Tabletop/Panels), Alloy Steel (Legs) |
| Finish Type | Powder Coated (Legs), Acrylic Paint (Panels) |
| Special Feature | Scratch Resistant |
| Mounting Type | Floor Mount |
| Designer | Henrik Preutz |

SETUP INSTRUCTIONS

Unpacking:

Carefully remove all components from the packaging. Inspect all parts for any damage or missing pieces. Keep packaging materials until assembly is complete in case any parts need to be returned or replaced.

Assembly:

This product requires assembly. Please refer to the detailed assembly instructions included in the product packaging. Ensure you have all necessary tools as specified in the assembly guide. Follow the step-by-step diagrams and instructions precisely to ensure proper and safe construction. It is recommended to assemble the desk on a soft, clean surface to prevent scratches.

Important: Ensure all screws and fittings are tightened securely before using the desk. Periodically check and

re-tighten fittings as needed.

OPERATING INSTRUCTIONS

Drawer Usage:

The desk is equipped with two smooth-gliding drawers. Each drawer has a built-in stopper to prevent it from being pulled out too far and falling. To open, gently pull the drawer handle. To close, push the drawer back until it is flush with the desk front.

Cable Management:

The desk features a discreet opening on the top panel for cable management. Route your computer, monitor, and other device cables through this opening to keep your workspace tidy and organized. The design allows cables to be hidden at the back of the desk, preventing clutter on the tabletop.

Work Surface Load:

The desk is designed to support a maximum load of 110.2 lbs (50 kg). Do not exceed this weight limit to ensure stability and prevent damage to the desk.

MAINTENANCE AND CARE

Cleaning:

Wipe the desk clean with a damp cloth and a mild cleaner. Dry thoroughly with a clean cloth. Avoid using abrasive cleaners or harsh chemicals as they may damage the surface finish.

Material Care:

- **Wood-based panels:** Protect from excessive moisture and direct heat. Use coasters for drinks to prevent water rings.
- **Steel Legs:** The powder-coated steel legs are durable. If scratches occur, touch-up paint designed for metal surfaces can be used.
- **Scratch Resistance:** While the surface is scratch-resistant, avoid dragging sharp or heavy objects across it to maintain its appearance.

General Care:

Periodically check all assembly fittings and re-tighten them if necessary to ensure the desk remains stable and safe for use.

TROUBLESHOOTING

Common Issues:

- **Wobbly Desk:** Ensure all screws and fittings are securely tightened. Check that the desk is placed on a level surface. Adjust the feet if available.
- **Stuck/Difficult Drawers:** Check that the drawer runners are correctly aligned and free from

obstructions. Ensure the drawer is not overloaded.

- **Scratches/Dents:** For minor surface imperfections, consider using furniture repair kits or touch-up pens that match the desk's white finish.

If you encounter issues not listed here or require further assistance, please contact customer support.

WARRANTY INFORMATION

For detailed information regarding the warranty for your IKEA Micke Desk, please refer to the warranty documentation provided with your purchase or visit the official IKEA website. The warranty typically covers defects in materials and workmanship under normal use.

SUPPORT

If you have any questions, require replacement parts, or need technical assistance, please contact IKEA customer service. You can find contact information on the official IKEA website or in your purchase documentation. When contacting support, please have your model number (403.542.78) and purchase details ready.

For more information and product updates, visit the official IKEA website: www.ikea.com