

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-272 Professional Cordless Hair Clipper User Manual](#)

VGR V-272

VGR V-272 Professional Cordless Hair Clipper User Manual

Model: V-272 | Brand: VGR

IMPORTANT SAFETY INFORMATION

For your safety and to ensure proper operation of the VGR V-272 Professional Cordless Hair Clipper, please read and adhere to the following guidelines:

- Avoid use in wet conditions. This appliance is not designed for use in showers or baths.
- Keep away from water sources. Do not immerse the clipper in water or other liquids.
- Always unplug the trimmer before cleaning to prevent electrical shock.
- Be cautious when using the blades to prevent skin irritation or injury. Blades are sharp.
- Follow recommended cleaning and maintenance procedures as outlined in this manual to ensure longevity and hygiene.
- Keep out of reach of children.
- Do not operate the appliance if it has a damaged cord or plug, or if it is not working properly.

PRODUCT OVERVIEW

The VGR V-272 is a professional cordless hair clipper designed for precise and efficient hair cutting. It features a T-blade for close cutting, a powerful motor, and a long-lasting Li-ion battery. The device is also IPX5 waterproof for easy cleaning.



Figure 1: VGR V-272 Professional Cordless Hair Clipper with included accessories. This image displays the main clipper unit, a charging cable, a cleaning brush, a small bottle of lubricating oil, and an adjustable guide comb.

Key Features:

- **Professional T-Blade:** Designed for precise, close cutting and detailing.
- **Cordless Operation:** Provides flexibility and ease of use without being tethered to an outlet.
- **Long Battery Life:** Up to 180 minutes of runtime on a single charge with a 1200 mAh Li-ion battery.
- **USB Fast Rechargeable:** Convenient charging via USB, ideal for travel.
- **IPX5 Waterproof:** Allows for easy rinsing of the blades under running water for hygienic cleaning.
- **Adjustable Length Settings:** Features 20 length levels with a 0.5 mm per step precision dial for versatile styling.
- **High-Carbon Steel Blades:** Self-sharpening and durable for long-lasting performance.

- **R-Shaped Sharp Angle Design:** Ensures safe trimming without skin irritation.

SETUP AND CHARGING

Initial Charge:

1. Before first use, fully charge the clipper for approximately 3 hours.
2. Connect the USB charging cable to the charging port on the bottom of the clipper.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
4. The indicator light will illuminate during charging and change when fully charged (refer to device specific light behavior if available, otherwise assume standard).

Attaching Guide Combs:

The VGR V-272 comes with an adjustable guide comb to achieve various hair lengths.



Figure 2: Close-up view of the VGR V-272 clipper's T-blade and the adjustable guide comb mechanism. The comb allows for precise length adjustments.

1. Ensure the clipper is turned off.
2. Align the guide comb with the clipper head and slide it on until it clicks into place securely.
3. Adjust the desired cutting length using the precision dial on the comb. The comb is self-locking for stable trimming.
4. To remove, gently push the comb off the clipper head.

OPERATING INSTRUCTIONS

Basic Operation:



Figure 3: Front view of the VGR V-272 Professional Cordless Hair Clipper, highlighting the power button.

1. Ensure the clipper is charged.
2. Attach the desired guide comb if needed, or use without for 0mm bald head cutting.
3. Press the power button to turn on the clipper.
4. Hold the clipper with the blade flat against the skin or at the desired angle for cutting.
5. Move the clipper slowly and steadily against the direction of hair growth.
6. For detailing or outlining, use the T-blade without a guide comb.
7. After use, press the power button to turn off the clipper.

Adjusting Cutting Length:

The adjustable guide comb allows for 20 different length settings, with increments of 0.5 mm.

- With the guide comb attached, rotate the precision dial on the comb to select your desired length.
- Ensure the comb is securely locked at the chosen setting before beginning to cut.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your VGR V-272 clipper.

Cleaning the Blades:



Figure 4: Detailed view of the VGR V-272 clipper's T-blade, showing the mechanism for cleaning and oiling.

1. Turn off the clipper and unplug it if connected to power.
2. Remove any attached guide combs.
3. Use the included cleaning brush to brush away loose hairs from the blades and the clipper body.
4. Since the clipper is IPX5 waterproof, you can rinse the blades under running water. Ensure the main body of the clipper is not submerged.
5. Allow the blades to air dry completely before reattaching any combs or storing.

Oiling the Blades:

To maintain optimal cutting performance and blade longevity, it is recommended to oil the blades regularly, especially after cleaning or every few uses.

1. Apply 1-2 drops of the included lubricating oil (or a suitable clipper oil) to the teeth of the blades.
2. Turn on the clipper for a few seconds to allow the oil to distribute evenly across the blades.
3. Wipe off any excess oil with a soft, dry cloth.

Storage:

Store the clipper in a cool, dry place, away from direct sunlight and moisture. Ensure the blades are clean and oiled before storing for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully (approx. 3 hours).
Clipper runs slowly or pulls hair.	Blades are dirty or not oiled.	Clean the blades and apply lubricating oil.
Clipper makes unusual noise.	Blades are misaligned or damaged.	Check blade alignment. If damaged, contact customer support.
Guide comb does not stay on.	Comb not properly attached or damaged.	Ensure comb is clicked into place. If damaged, replace comb.

SPECIFICATIONS

Model: V-272

Brand: VGR

Power Source: Battery Powered

Battery Type: 1200 mAh Li-ion Battery (included)

Runtime: Up to 180 minutes

Charging Time: Approximately 3 hours

Blade Material: High Carbon Steel

Waterproof Rating: IPX5

Motor Power: 6200±500RPM

Product Dimensions: 18 x 8 x 5 cm

Item Weight: 350 g (0.77 Pounds)

Special Features: Portable, Cordless, Rechargeable

Recommended Uses: Hair

WARRANTY AND SUPPORT

VGR offers a **12-month quality warranty** for the VGR V-272 Professional Cordless Hair Clipper.

If you encounter any issues or are not satisfied with this product, please do not hesitate to contact VGR customer service. They aim to respond within 24 hours and provide a satisfactory resolution.

For support, please refer to the contact information provided with your purchase or visit the official VGR website.



© 2023 VGR. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.