

[Manuals.plus](#) /

> [Rilyson](#) /

> Rilyson 5-Piece Wicker Patio Furniture Set Instruction Manual

Rilyson 5-Piece Rattan Outdoor Sectional Conversation Set

Rilyson 5-Piece Wicker Patio Furniture Set Instruction Manual

Model: 5-Piece Rattan Outdoor Sectional Conversation Set

INTRODUCTION

Thank you for choosing the Rilyson 5-Piece Wicker Patio Furniture Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new outdoor furniture. Please read these instructions thoroughly before assembly and retain them for future reference.

SAFETY INFORMATION

Always follow the assembly instructions carefully. Do not exceed the weight capacity of the product. Keep the product clean by wiping it with a damp cloth. Keep sharp objects away from the product to prevent damage. Do not leave children unattended near the product.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 2 x Swivel Rocking Chairs
- 2 x Ottomans
- 1 x Side Table
- Assembly Hardware (bolts, washers, wrench)

5-Pieces Swivel Rocker Chair set



Figure 1: Overview of the 5-piece set components and their dimensions.

ASSEMBLY INSTRUCTIONS

Assembly is required for this furniture set. Please follow these general steps. Refer to the included hardware pack for specific fasteners.

1. **Unpack all components:** Carefully remove all items from the packaging and lay them out on a soft, clean surface to prevent scratches.
2. **Identify parts:** Match each component with the parts list and diagrams.
3. **Assemble chairs:** Attach the chair base to the seat frame using the provided bolts and washers. Do not fully tighten bolts until all connections are made.
4. **Assemble ottomans:** Attach the legs to the ottoman frame.
5. **Assemble side table:** Connect the table legs to the tabletop and base.
6. **Final tightening:** Once all components are loosely assembled, carefully tighten all bolts evenly. Do not overtighten.
7. **Place cushions:** Position the seat and back cushions on the chairs and ottomans.

It is recommended to have two people for assembly to ensure stability and ease of construction.

OPERATING INSTRUCTIONS

Swivel Rocking Chairs

The chairs are designed for both rocking and 360-degree swivel motion, providing versatile comfort.

- **Rocking Function:** Gently lean back and forth to engage the smooth rocking mechanism.
- **360-Degree Swivel:** Rotate the chair in any direction to easily change your view or conversation angle.



Figure 2: The chair's gentle glide and rocking feature.

Rotate 360 Degree Easily Change Direction



Figure 3: The chair can rotate 360 degrees for easy direction changes.

Ottomans

The ottomans serve multiple purposes:

- **Footrest:** Use to elevate your feet for enhanced relaxation.
- **Extra Seating:** Can be used as additional seating for guests.
- **Side Table:** With the cushion removed, the ottoman can function as a small side table.

QUALITY WICKER OTTOMAN

Full Handwoven PE Wicker
(Weather resistant and durable)

Thick Puffy Cushion
(Water resistant fabric)

Durable Steel Frame
(Heavy-duty and no rust)

Stable Wedge-Shape Feet
(Non-slip pads for safety)

Large Size (Can be used
as a table and chair)



Figure 4: The ottoman features handwoven PE wicker and a thick cushion.

Side Table

The included side table is ideal for holding beverages, books, or small decorative items.

MAINTENANCE

Proper care will extend the life and appearance of your Rilyson patio furniture set.

- **Cleaning:** Wipe the wicker and frame with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals.
- **Cushion Care:** The cushions are made with water-resistant fabric. However, for prolonged life, it is recommended to store cushions indoors or cover the set during heavy rain or extended periods of non-use. Spot clean cushions with a mild detergent and air dry.
- **Frame Inspection:** Periodically check all bolts and connections to ensure they remain tight. Retighten as necessary.
- **Winter Storage:** In colder climates, store the furniture indoors or cover it with a weather-resistant cover during winter months to prevent damage from frost and snow.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Furniture feels wobbly	Loose bolts or uneven surface.	Check and tighten all assembly bolts. Ensure furniture is placed on a flat, even surface.
Swivel chair not rotating smoothly	Debris in the swivel mechanism or lack of lubrication.	Clean any debris from the swivel base. Apply a silicone-based lubricant if necessary.
Cushions appear flattened	Prolonged use or exposure to moisture.	Fluff cushions regularly. Ensure they are dry before storage.

SPECIFICATIONS

Feature	Detail
Brand	Rilyson
Color	Mixed Grey/Blue
Style	Modern
Assembly Required	Yes
Material Type	Steel, Polyester, PE Rattan Wicker
Product Care Instructions	Wipe with Damp Cloth
Chair Dimensions (L x W x H)	32 x 32 x 35 inches
Chair Seat Cushion Dimensions (W x D x H)	22 x 24 x 4 inches
Chair Back Cushion Dimensions (W x D x H)	22 x 5 x 22 inches
Side Table Dimensions (L x W x H)	20 x 20 x 22 inches
Ottoman Dimensions (L x W x H)	22.8 x 22.8 x 14 inches
Ottoman Seat Cushion Dimensions (W x D x H)	22.8 x 22.8 x 3.5 inches
Chair Weight Capacity	250 lbs
Side Table Weight Capacity	55 lbs

WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your Rilyson Patio Furniture Set, please contact Rilyson customer service. Refer to your purchase documentation for specific warranty details.