

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gizoon](#) /
- › [Gizoon 4-Drawer Dresser \(Model 22AP\) - Assembly and Care Manual](#)

Gizoon 22AP

Gizoon 4-Drawer Dresser (Model 22AP) - Assembly and Care Manual

Brand: Gizoon | Model: 22AP

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Gizoon 4-Drawer Dresser (Model 22AP). Learn how to safely set up and care for your new storage furniture.

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** This dresser includes an anti-tip device. It is crucial to install this device to prevent serious injury from tipping furniture. Always secure the dresser to a wall using the provided hardware.
- **Weight Limits:** Do not exceed the recommended weight limits. The top surface can hold up to 55 lbs (25 kg). Each drawer can hold up to 33 lbs (15 kg). Overloading may cause instability and damage.
- **Assembly:** Assembly requires at least two people. Ensure all parts are present and undamaged before beginning. Do not use power tools unless specifically instructed, as overtightening can damage components.
- **Children Safety:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser. Always close drawers completely after use.
- **Placement:** Place the dresser on a level surface. Avoid placing it near heat sources or in direct sunlight to prevent material degradation.

2. PACKAGE CONTENTS

Verify all components are present before starting assembly. If any parts are missing or damaged, please contact customer support.



Figure 2.1: All parts included in the package. Please check against the parts list in your

physical manual.

A comprehensive assembly guide with a detailed parts list is included in your product packaging. Please refer to it for specific component identification.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. An electric screwdriver (not included) can speed up the process, but manual screwdrivers are provided.



Figure 3.1: Assembly requires attention to detail. Ensure adequate workspace and wear gloves to prevent injury.

1. Step 1: Prepare the Workspace

Clear a spacious area for assembly. Lay out all parts and hardware. Refer to the included manual for a complete list of components.

2. Step 2: Assemble the Frame

Connect the side panels to the base and top panel using the designated screws and dowels. Ensure all connections are secure but do not overtighten.

3. Step 3: Install Drawer Slides

Attach the drawer slides to the inner sides of the dresser frame. Make sure they are level and aligned correctly for smooth drawer operation.

4. Step 4: Assemble Drawers

Construct each drawer by attaching the sides, back, and bottom panel. Then, attach the drawer front with the integrated handle. Install the corresponding drawer slides onto each drawer.

5. Step 5: Insert Drawers

Carefully slide each assembled drawer into its respective slot on the dresser frame. Test each drawer for smooth movement.

6. Step 6: Install Anti-Tip Device

Locate a suitable wall stud and attach the anti-tip bracket to the wall and the back of the dresser using the provided screws and strap. This step is critical for safety.

4. OPERATING INSTRUCTIONS

Your Gizoon 4-Drawer Dresser is designed for easy and efficient storage.

- **Opening/Closing Drawers:** Use the embedded handles to gently pull and push the drawers. Avoid forcing them.
- **Weight Distribution:** Distribute items evenly within the drawers to prevent strain on the slides and maintain stability. Place heavier items in lower drawers.
- **Top Surface Use:** The top surface can be used for decorative items or frequently accessed essentials, ensuring the weight limit of 55 lbs (25 kg) is not exceeded.



Figure 4.1: Smooth drawer rails ensure effortless opening and closing.



Figure 4.2: The embedded handle design provides a sleek look and easy grip.

5. MAINTENANCE AND CARE

To ensure the longevity and appearance of your dresser, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Movement:** When moving the dresser, always lift it rather than dragging it to prevent damage to the legs and frame.



Figure 5.1: The dresser features a waterproof board and curved safety corners for durability and safety.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose screws.	Check that drawer slides are correctly installed and all screws are tightened. Ensure the dresser is on a level surface.
Dresser feels wobbly.	Loose frame connections or uneven floor.	Verify all frame screws are tight. Adjust the dresser's position or use shims if the floor is uneven. Ensure the anti-tip device is installed.
Drawers fall down or do not close properly.	Incorrect drawer assembly or damaged slides.	Review assembly steps for drawers and slides. Contact customer support if parts appear damaged.

7. SPECIFICATIONS

Brand: Gizoon

Model Name: 4 Drawer Dresser

Item Model Number: 22AP

Product Dimensions: 16.2"D x 28.1"W x 32.3"H

Color: White

Material: Wood (MDF)

Furniture Finish: White

Number of Drawers: 4

Item Weight: 52.9 Pounds

Top Board Weight Capacity: 55 lbs (25 kg)

Each Drawer Weight Capacity: 33 lbs (15 kg)

Assembly Required: Yes



Figure 7.1: Detailed dimensions and weight capacities of the dresser.

8. WARRANTY AND SUPPORT

Gizoon products come with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official Gizoon website.

For any assembly questions, missing parts, or support needs, please contact our dedicated customer service team. Contact information can be found on the Gizoon website or in your product packaging.

Gizoon Store: [Visit the Gizoon Store on Amazon](#)

9. PRODUCT VIDEOS

Watch these official product videos for additional guidance and visual demonstrations.

Your browser does not support the video tag.

Video 9.1: An overview of the Gizoon 4-Drawer Dresser, showcasing its features and design in a room setting.