

[Manuals.plus](#) /

> [Hoover](#) /

> Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner User Manual

Hoover BH53600V

Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner User Manual

Model: BH53600V | Brand: Hoover

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner. Combining powerful suction and everyday convenience, this vacuum effectively picks up stubborn debris throughout your home. Its dual cyclonic filtration technology captures 99.4% of dirt and dust particles with no loss of suction. This lightweight stick vacuum is optimized to clean any surface with its multi-surface brush roll and specialized tools, allowing it to convert to a handheld vacuum. The innovative ONEPWR battery system delivers up to 45 minutes of continuous, fade-free run time. Please read this manual thoroughly before first use and keep it for future reference.





Figure 1: Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner.

KEY FEATURES

- **All-Terrain Stick Vacuum:** Switch between floor types with the multi-surface brush roll. With self-standing functionality, you can pause to move obstacles or empty the dirt cup while the vacuum stays upright.
- **Powerful and Quiet Cleaning:** Dual Cyclonic filtration technology captures 99.4% of dirt and dust particles with no loss of suction. The Hushstone system delivers a quieter clean without compromising power.

- **Above Floor Cleaning Versatility:** Clean beyond your floors and target hard-to-reach areas, upholstery and stairs with specialized tools to convert to a handheld vacuum.
- **ONEPWR Battery System:** Experience whole-home portability and cordless convenience with up to 45 minutes of continuous run time. Grab and go to tackle tough messes anytime, anywhere.

SETUP

Follow these steps to assemble your Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list are present.
2. **Attach Wand to Floor Nozzle:** Insert the bottom end of the extension wand into the top of the multi-surface floor nozzle until it clicks securely into place.
3. **Attach Handheld Unit:** Align the handheld vacuum unit with the top of the extension wand and push down firmly until it clicks into position.
4. **Charge Battery:** Before first use, fully charge the ONEPWR battery. Insert the battery into the charging cradle and plug the charger into a power outlet. The battery indicator lights will show charging progress.





Figure 2: Front view of the assembled vacuum.



Figure 3: Inserting the ONEPWR battery into the handheld unit.

OPERATING INSTRUCTIONS

Your Hoover ONEPWR WindTunnel Emerge offers versatile cleaning modes:

- **Power On/Off:** Press the power button located on the handle to turn the vacuum on or off.
- **Suction Control:** Use the +/- buttons on the handle to adjust suction power for different cleaning needs.
- **Floor Cleaning:** For general floor cleaning, use the vacuum in its upright stick configuration. The multi-surface brush roll is designed for various floor types, from hard floors to carpets.
- **Self-Standing Feature:** The vacuum can stand upright on its own, allowing you to pause cleaning to move obstacles or attend to other tasks without needing to lean it against a wall.
- **Handheld Mode:** To convert to a handheld vacuum, press the release button on the wand to detach the handheld unit. Attach desired specialized tools (crevice tool, dusting brush) directly to the handheld unit for above-floor cleaning.



Figure 4: Vacuuming a hard floor with the main nozzle.



Figure 5: Utilizing the handheld mode for cleaning upholstery.

Official Product Video

Your browser does not support the video tag.

Video 1: Official Hoover ONEPWR Emerge Cordless Vacuum demonstration, showcasing its features and ease of use.

MAINTENANCE

Regular maintenance ensures optimal performance of your vacuum cleaner:

- **Emptying the Dirt Cup:** The removable, easy-to-empty dirt cup should be emptied regularly, especially when debris reaches the "MAX" fill line. Press the release button to detach the dirt cup and empty contents into a trash bin.
- **Cleaning the Filter:** The foam filter should be cleaned periodically to maintain suction power. Refer to the full user manual for detailed instructions on removing and cleaning the filter.
- **Cleaning the Brush Roll:** Inspect the multi-surface brush roll regularly for tangled hair or debris. Use scissors or the included cleaning tool to carefully remove any obstructions.



Figure 6: Easy-empty dirt cup being emptied into a trash bin.



Figure 7: Cleaning the multi-surface brush roll to remove tangled hair.

If you encounter issues with your vacuum, try these common troubleshooting steps:

- **No Power:** Ensure the battery is fully charged and properly inserted. Check if the power button is pressed firmly.
- **Loss of Suction:** Empty the dirt cup. Check and clean the filter. Inspect the brush roll and nozzle for any blockages.
- **Brush Roll Not Spinning:** Ensure there are no obstructions in the brush roll. Check if the vacuum is in the correct mode for the floor type.

For more detailed troubleshooting, please refer to the comprehensive User Manual PDF available online or contact Hoover customer support.

SPECIFICATIONS

Feature	Detail
Brand	Hoover
Model Name	Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum
Model Number	BH53600V
Power Source	Battery Powered (ONEPWR Lithium Ion)
Runtime	Up to 45 minutes
Charging Time	2.5 Hours
Capacity	0.4 Liters (Dust Cup)
Item Weight	7.26 pounds
Product Dimensions	7.5"L x 10.5"W x 44.25"H
Special Features	Portable, Self-Standing, Converts to Handheld, HushTone System
Included Components	Dusting Brush, Crevice Tool

WARRANTY & SUPPORT

Your Hoover ONEPWR WindTunnel Emerge Cordless Stick Vacuum Cleaner comes with a **3-year limited warranty**. For detailed warranty information, product registration, or customer support, please refer to the official User Manual PDF or visit the Hoover website. You can access the full User Manual [here](#).