

[Manuals.plus](#) /

> [vidaXL](#) /

> vidaXL 4-Panel Room Divider, Black, 200x200 cm, Fabric - Instruction Manual

vidaXL 350185

vidaXL 4-Panel Room Divider, Black, 200x200 cm, Fabric - Instruction Manual

Model: 350185

INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your vidaXL 4-Panel Room Divider. Please read this manual thoroughly before use to ensure proper setup and safe handling. This room divider is designed to offer privacy, divide spaces, block sunlight, or serve as a decorative element in your home.



Image: The vidaXL 4-Panel Room Divider, black, set up in a room to create a private space.

SAFETY INFORMATION

- Ensure the room divider is placed on a flat, stable surface to prevent tipping.
- Do not allow children to climb on or hang from the divider.
- Keep the divider away from open flames, heaters, and other heat sources.
- Avoid placing heavy objects on the divider.
- Handle with care during movement to prevent damage or injury.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 4 x Fabric Panels (Black, 100% Polyester)
- Iron Frame Components (Poles, Connectors)
- Assembly Hardware (Screws, Allen Key if applicable)
- Instruction Manual

SETUP AND ASSEMBLY

Follow these steps to assemble your room divider:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame Sections:** Connect the iron poles using the provided connectors to form the individual panel frames. Ensure each connection is secure.
3. **Attach Fabric Panels:** Slide or attach the black fabric panels onto the assembled frame sections. Ensure the fabric is taut and evenly distributed.
4. **Connect Panels:** Join the individual panel frames together using the designated hinges or connectors to form the complete 4-panel divider.
5. **Final Check:** Verify that all screws are tightened and all connections are firm. The divider should stand upright and be stable.



Image: Detail of a single panel, showing the fabric attached to the iron frame.

OPERATING INSTRUCTIONS

The vidaXL 4-Panel Room Divider is designed for flexible use:

- **Unfolding:** Gently extend the panels to the desired width and configuration. The hinged design allows for various angles.
- **Stability:** For optimal stability, position the panels in a slight accordion or zigzag pattern rather than a straight line. This distributes weight and prevents tipping.
- **Folding for Storage:** To store, simply fold the panels back together. The compact design allows for

easy storage in small spaces.

- **Placement:** Use the divider to create distinct zones in a room, block unwanted views, or reduce direct sunlight from a window.



Image: The room divider fully extended, demonstrating its use for space separation.

MAINTENANCE

Proper care will extend the life of your room divider:

- **Cleaning:** Wipe the fabric panels and iron frame with a soft, dry cloth to remove dust and light dirt.
- **Stains:** For stubborn stains on the fabric, gently dab with a slightly damp cloth and mild soap, then wipe dry immediately. Avoid saturating the fabric.
- **Avoid Chemicals:** Do not use harsh chemical cleaners, abrasive materials, or solvents, as these can damage the fabric or frame finish.
- **Inspection:** Periodically check all frame connections and hinges to ensure they remain tight and secure. Tighten any loose screws as needed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Divider is unstable or tips easily.	Panels are too straight; loose connections.	Angle panels in a zigzag pattern for better balance. Check and tighten all frame connections. Ensure placement on a level surface.
Fabric panels appear loose or saggy.	Improper attachment during assembly; fabric stretched.	Re-check how fabric panels are attached to the frame. Ensure they are securely fastened.
Difficulty folding the divider.	Hinges are stiff or obstructed.	Gently manipulate hinges. Ensure no fabric or debris is obstructing the folding mechanism.

SPECIFICATIONS

- **Brand:** vidaXL
- **Model Number:** 350185
- **Dimensions (W x H):** 200 x 200 cm (78.7 x 78.7 inches)
- **Material:** Fabric (100% Polyester), Iron
- **Color:** Black
- **Number of Panels:** 4
- **Special Feature:** Foldable
- **Weight:** 3.77 Kilograms
- **Care Instructions:** Clean with a dry cloth




Image: Dimensional diagram illustrating the 200 cm width and 200 cm height of the room divider.

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the documentation included with your purchase or contact vidaXL customer service directly. Contact details can typically be found on the vidaXL official website or your purchase receipt.

