

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-319 Electric Shaver User Manual](#)

## VGR VGR V-319

# VGR V-319 Electric Shaver User Manual

Model: VGR V-319

## IMPORTANT SAFETY INFORMATION

---

Please read all safety instructions carefully before using the VGR V-319 Electric Shaver. Failure to follow these instructions may result in injury or damage to the product.

- For safe operation, use this shaver on dry or wet skin, but avoid using it while charging.
- As the shaver is IPX6 waterproof, you can rinse it under running water for easy cleaning.
- To maintain optimal performance and prevent skin irritation, ensure the shaver is fully charged before each use.
- Store the shaver in a clean, dry place to prevent bacterial growth.
- Always follow provided directions for maintenance and care.

## PRODUCT OVERVIEW

---

The VGR V-319 is a premium cordless, rechargeable electric shaver designed for both wet and dry shaving. It features a 3-head rotary system with 3D floating heads for a close and comfortable shave.



Image: The VGR V-319 Electric Shaver, showing the main unit, USB charging cable, cleaning brush, and protective cap.

## Key Features:

- **3D Floating Heads:** Automatically adapts to facial contours for a smooth and close shave.
- **IPX6 Waterproof:** Allows for easy cleaning under running water and supports wet or dry shaving.
- **Wet & Dry Shave:** Can be used for a quick dry shave or with foam/gel for a refreshing wet shave.
- **2-Color LED Indicators:** Displays battery status (Blue for operating/charging/full, Red for low battery).
- **Travel Lock:** Prevents accidental activation during travel.
- **Magnetic Suction Head:** For easy attachment and removal of the shaver head.

## GETTING STARTED (SETUP)

---

### Package Contents:

- 1 x VGR V-319 Electric Shaver
- 1 x USB Charging Cable (Note: USB adapter not included)
- 1 x Protective Cap

- 1 x Cleaning Brush
- 1 x User Manual (this document)

## Charging the Shaver:

1. Ensure the shaver is turned off.
2. Connect the USB charging cable to the shaver's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, laptop, USB charger, power bank).
4. The LED indicator will show charging status. A full charge takes approximately 1 hour.
5. Once fully charged, the blue light will remain on. Disconnect the shaver from the power source.

**VGR**<sup>®</sup>  
V O Y A G E R

# 90 MINUTES OPERATING

600mAh Li-ion battery  
1 hours quick charge

600 mAh  
Capacity

1 Hours  
Charge Time

90 Min  
Work Time

Convenient And Safe USB Charging

Computer Laptop USB Charger Powerbank

VGR

The image is a vertical advertisement for the VGR V-319 electric shaver. It features a black shaver with three rotary heads and a power button. To the left of the shaver, there are three green progress bars representing battery capacity (600mAh), charge time (1 hour), and work time (90 minutes). Below these, icons represent various USB charging sources: a computer monitor, a laptop, a USB charger, and a power bank. The VGR logo is visible at the top left and bottom right of the graphic.

Image: Visual representation of the VGR V-319's charging specifications, including 600mAh battery, 1 hour charge time, and 90 minutes operating time.

## Battery Indicator:

- **Blue Light:** Indicates the shaver is operating, connected to charging, or fully charged.
- **Red Light:** Indicates the battery level is lower than 15%. Recharge the shaver promptly.

## OPERATING INSTRUCTIONS

## Turning On/Off and Travel Lock:

- **To Turn On/Off:** Press the On/Off button once.
- **To Activate Travel Lock:** Hold the On/Off switch for 3 seconds. The shaver will lock in the off position to prevent accidental activation.
- **To Deactivate Travel Lock:** Hold the On/Off switch for 3 seconds again.



Image: Diagram illustrating key features of the VGR V-319, including the On/Off button, magnetic suction head, USB charging port, and fully washable design.

## Shaving Techniques:

The VGR V-319 can be used for both dry and wet shaving.

- **Dry Shaving:** For a quick and convenient shave, ensure your face is clean and dry. Move the shaver in small, circular motions against the direction of hair growth.
- **Wet Shaving:** For a smoother and more refreshing shave, apply shaving foam or gel to your face. Move the shaver in small, circular motions. The IPX6 waterproof design allows for safe use in the shower.

**VGR**<sup>®</sup>  
V O Y A G E R

# IPX6 WATERPROOF

Whole body is washable  
Easier to clean or shave



Image: Illustration highlighting the IPX6 waterproof rating of the VGR V-319, indicating it is fully washable and suitable for both dry and wet shaving.

For optimal results, stretch your skin slightly with your free hand to make the hairs stand upright.

## MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and hygiene of your VGR V-319 Electric Shaver.

### Daily Cleaning:

1. Turn off the shaver.
2. Gently pull the shaver head assembly upwards to detach it from the main body. The magnetic suction allows for easy removal.
3. Rinse the shaver head under warm running water. You can also rinse the main body of the shaver as it is IPX6 waterproof.
4. Use the provided cleaning brush to remove any stubborn hair clippings from the blades and the shaver body.
5. Allow all parts to air dry completely before reattaching the shaver head and placing the protective cap.

### Deep Cleaning (Periodically):

For a more thorough clean, you can carefully remove the individual rotary blades from the shaver head assembly and rinse them

separately. Ensure they are reassembled correctly before reattaching the head.

**Important:** Do not use abrasive cleaning agents or harsh chemicals to clean the shaver, as this may damage the finish or internal components.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted. Travel lock is activated.	Charge the shaver for at least 1 hour. Hold the On/Off button for 3 seconds to deactivate travel lock.
Shaver performance is poor / pulling hair.	Blades are dirty or clogged with hair. Blades are dull. Battery is low.	Clean the shaver head thoroughly. Consider replacing the shaver head (contact support for availability). Recharge the shaver.
Shaver does not charge.	USB cable or power source is faulty. Charging port is dirty.	Try a different USB cable or power source. Clean the charging port gently with a dry brush.
Red light indicator stays on.	Battery is low.	Recharge the shaver immediately.

If the problem persists after trying these solutions, please contact customer support.

## SPECIFICATIONS

Feature	Detail
Model Name	VGR V-319
Product Type	Electric Rotary Shaver
Power Source	Battery Powered (Cordless, Rechargeable)
Battery Type	1 x Li-ion battery (Included)
Battery Capacity	600mAh
Charging Time	Approx. 1 hour (when battery is empty)
Running Time	Approx. 90 minutes
Rated Voltage	100V-240V
Input Voltage	5V
Output Power	8W
Waterproof Rating	IPX6 (Fully Washable)
Dimensions (L x W x H)	18 x 12 x 6 cm
Item Weight	450 Grams
Blade Material	Stainless Steel
Color	Black
Manufacturer	Ningbo VGR Electric Appliance Co., Ltd., Yiwu Gemei Electric Appliance Co. Ltd

## WARRANTY AND SUPPORT

---

The VGR V-319 Electric Shaver comes with a **12-month quality warranty** from the date of purchase.

If you encounter any issues with your product or are not satisfied, please do not hesitate to contact VGR customer service. Our team is committed to providing a satisfactory resolution within 24 hours.

For support, please refer to the contact information provided on the product packaging or the official VGR website.

