

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Smart Weigh](#) /

› Smart Weigh Gray Digital Kitchen Scale SW-KSGRAY User Manual

Smart Weigh SW-KSGRAY

Smart Weigh Gray Digital Kitchen Scale User Manual

Model: SW-KSGRAY

INTRODUCTION

Thank you for choosing the Smart Weigh Gray Digital Kitchen Scale. This manual provides essential information for the proper setup, operation, and maintenance of your new kitchen scale. Please read these instructions carefully before use to ensure accurate measurements and prolong the life of your device.

SETUP

1. Unpacking and Placement

- Carefully remove the scale from its packaging.
- Place the scale on a flat, stable, and level surface to ensure accurate readings. Avoid placing it on soft or uneven surfaces.
- Keep the scale away from strong electromagnetic fields, extreme temperatures, and direct sunlight.

2. Battery Installation

The Smart Weigh Digital Kitchen Scale requires two (2) AAA batteries, which are included.

1. Locate the battery compartment on the underside of the scale.
2. Open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Image: Smart Weigh Gray Digital Kitchen Scale. The scale is gray with a digital display showing "0.263 kg". Several fresh strawberries are placed on the weighing platform.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn on the scale, press the **TARE** button. The display will illuminate and show "0".
- The scale features an automatic shut-off function. If the scale is not used for approximately 120 seconds, or if the weight on the platform remains unchanged, it will automatically turn off to conserve battery life.

2. Unit Conversion

The scale can measure in multiple units.

- Press the **UNIT** button to cycle through the available measurement units: grams (g), ounces (oz), milliliters (mL), kilograms (kg), and pounds and ounces (lbs:oz).
- Select the desired unit before or during weighing.

Precise Units



Image: Precise Units. The image shows the digital kitchen scale on a countertop with a bowl of fruit. Above the scale, labels indicate various measurement units: oz, g, lb'oz, fl'oz, and mL, highlighting the scale's unit conversion capability.

3. Tare Function

The tare function allows you to subtract the weight of a container, enabling you to measure only the contents.

1. Place an empty container on the weighing platform.
2. Press the **TARE** button. The display will reset to "0".
3. Add the items you wish to weigh into the container. The display will show the net weight of the items.

4. Weighing Items

- Ensure the scale is on a flat surface and powered on, displaying "0".
- Place the item(s) to be weighed directly onto the center of the weighing platform, or use a container with the tare function.
- The weight will be displayed on the backlit LCD screen.

Accurate Measurements




Image: Accurate Measurements. A person is shown adding butter to a white bowl placed on the digital kitchen scale, illustrating the scale's precision in measuring ingredients.

Easy to Use with a User-friendly Format



LED Display



Volume Measurement



Auto-Off



Image: Easy to Use with a User-friendly Format. The image displays the digital kitchen scale with icons and text pointing to its key features: LED Display, Volume Measurement, and Auto-Off function.

MAINTENANCE

1. Cleaning

- To clean the scale, wipe the surface with a soft, damp cloth.
- Do not immerse the scale in water or use abrasive cleaning agents, as this can damage the electronic components.
- Ensure the scale is completely dry before storage or next use.

2. Storage

- Store the scale in a cool, dry place.
- Its compact design allows for easy storage in drawers or cabinets.
- Avoid placing heavy objects on the scale when not in use.

TROUBLESHOOTING

If you encounter issues with your Smart Weigh Digital Kitchen Scale, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Scale does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new AAA batteries.
Inaccurate readings.	Scale is on an uneven surface, overloaded, or affected by drafts/vibrations.	Place scale on a flat, stable surface. Ensure weight does not exceed 5 kg / 11 lbs. Avoid drafts. Recalibrate if necessary (refer to support).
Display shows "Err" or "O-Ld".	Scale is overloaded.	Remove items immediately. Do not exceed the maximum weight capacity of 5 kg / 11 lbs.
Auto-off function activates too quickly.	This is a standard power-saving feature (120 seconds of inactivity).	This is normal operation. To prevent auto-off during use, ensure there is activity on the scale.

SPECIFICATIONS

Feature	Detail
Model	SW-KSGRAY
Brand	Smart Weigh
Color	Gray
Weight Limit	5 kg / 11 lbs
Readout Accuracy	+/- 1 gram
Measurement Units	g, oz, mL, kg, lbs:oz
Display Type	Backlit LCD
Special Features	Auto Shut Off, Tare Function
Power Source	2 x AAA Batteries (included)
Product Dimensions	8 x 6 x 1 inches
Item Weight	5 ounces
Material	Plastic

IDEAL DIMENSIONS TO FIT PERFECTLY IN ANY KITCHEN



Image: Ideal Dimensions. The image shows the gray digital kitchen scale with its dimensions clearly marked: 6 inches in width, 8 inches in length, and 0.5 inches in thickness, illustrating its compact size.

WARRANTY AND SUPPORT

Warranty Information

Smart Weigh offers a **2-year warranty** on all its products. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

Customer Support

For any questions, concerns, or warranty claims, please contact our friendly customer service team. You can find contact information on the official Smart Weigh website or through your purchase platform.



