

IRONCK HK-CD-67

IRONCK 94.5" Office Computer Desk User Manual

Model: HK-CD-67

INTRODUCTION

Thank you for choosing the IRONCK 94.5" Office Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

For your safety and to prevent damage to the product, please observe the following precautions:

- Always assemble the desk on a stable, level surface.
- Do not overload the desk as it may tip over. The maximum weight recommendation is 800 pounds.
- Never insert objects into the electrical outlets that are not designed for them.
- Always unplug the desk from the power source when not in use or when leaving the room.
- Keep children and pets away from the assembly area.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as needed.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Desk panels (various sizes)
- Metal frame components
- Monitor stand
- Movable small table
- Keyboard tray
- Power outlet unit with USB ports
- CPU storage shelves

- Headphone hook
- Assembly hardware (screws, bolts, Allen wrench)
- Installation instructions

SETUP AND ASSEMBLY

Assembly typically takes about 1 hour for most people. It is recommended to have two people for easier assembly.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface (like a carpet) to prevent scratches. Refer to the included parts list and diagrams to identify each piece.
2. **Assemble the Metal Frame:** Begin by connecting the main metal frame components according to the provided diagrams. Ensure all connections are finger-tightened initially.
3. **Attach Desk Panels:** Secure the main desktop panels to the assembled metal frame. Once all panels are in place, fully tighten all screws with the provided Allen wrench.
4. **Install Power Outlet Unit:** Carefully insert the power outlet unit into the designated cutout on the desktop. Ensure it is flush and secure. Connect the power cord.
5. **Assemble CPU Storage and Shelves:** Attach the CPU storage shelves and any additional storage shelves to the frame as indicated in the instructions.
6. **Attach Keyboard Tray:** Install the sliding rails for the keyboard tray and then attach the keyboard tray itself.
7. **Position Monitor Stand and Movable Table:** The monitor stand and small movable table are designed to be freely placed on the desktop. Position them according to your ergonomic needs.
8. **Attach Headphone Hook:** Secure the headphone hook to the desired location on the desk frame.
9. **Final Check:** Double-check all connections to ensure they are tight and secure. The desk should be stable and level.




Figure 1: Overall dimensions and layout of the IRONCK 94.5" Office Computer Desk, showing the L-shaped configuration, monitor stand, keyboard tray, and storage shelves.



Figure 2: Close-up view of the integrated power outlet unit on the desk, featuring two standard plug outlets and three USB ports for convenient device charging.

4 Ways to Use Freely placed movable small table




Figure 3: Illustration demonstrating four different possible configurations for the desk, highlighting the flexibility of the L-shaped design and the movable small table.

OPERATING INSTRUCTIONS

Using the Power Outlet Unit

- Plug the desk's main power cord into a grounded wall outlet.
- Use the two standard AC outlets for powering devices such as monitors, laptops, or lamps.
- Use the three USB ports to charge compatible electronic devices like smartphones and tablets.
- Do not exceed the maximum electrical load capacity of the outlets.

Ergonomic Features


- **Monitor Stand:** The included 39" x 6" monitor stand helps raise your screen to an ergonomic viewing height, reducing neck and eye strain. Position it centrally or as needed for your setup.
- **Movable Small Table:** This additional small table can be freely placed on the desktop to expand your workspace or

provide a dedicated spot for accessories.

- **Keyboard Tray:** Utilize the sliding keyboard tray to keep your keyboard and mouse at a comfortable height, freeing up desktop space.
- **CPU Storage:** The dedicated shelf underneath the desk provides convenient storage for your CPU tower, saving space and improving legroom.



Figure 4: A close-up view of the monitor stand, showing how it elevates a monitor and provides storage space underneath for books or accessories.



Ergonomic Design

Relax spine with monitor riser

Release your back and reduce neck and eyes strain while helping you develop a right sitting posture




Figure 5: An illustration demonstrating the ergonomic benefits of using a monitor riser, showing correct and incorrect posture for computer use.



Figure 6: View of the CPU storage area beneath the desk, designed to accommodate computer towers and other equipment, keeping them off the floor.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Electrical Unit:** Keep the power outlet unit clean and free of dust. Do not spill liquids onto the unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and bolts are fully tightened. Adjust leveling feet if present, or place shims under legs on uneven floors.
Power outlets or USB ports are not working.	Desk not plugged in; circuit breaker tripped; faulty device.	Verify the desk's power cord is securely plugged into a working wall outlet. Check your home's circuit breaker. Test with a different device. If issues persist, contact customer support.
Parts missing during assembly.	Packaging error.	Review the package contents list. Contact IRONCK customer support with the specific part number(s) needed.

SPECIFICATIONS

Feature	Detail
Brand	IRONCK
Model Number	HK-CD-67
Product Dimensions	94.5" (L) x 37" (W) x 35" (H)
Color	Vintage Brown
Material Type	Engineered Wood, Metal
Maximum Weight Recommendation	800 pounds
Special Features	Built-in Power Outlet (2 AC, 3 USB), Monitor Stand, Movable Small Table, Keyboard Tray, CPU Storage Shelves, Headphone Hook, Cable Management Grommets
Item Weight	86 pounds

WARRANTY AND SUPPORT

The IRONCK 94.5" Office Computer Desk comes with a limited warranty. For specific warranty details, please refer to the documentation included with your purchase or contact IRONCK customer support.

If you encounter any issues or have questions regarding your desk, please contact IRONCK customer support for assistance.

- **Customer Support:** Refer to your purchase documentation for contact information or visit the official IRONCK website.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question