

[manuals.plus](#) /

› [AULCMEET](#) /

› [AULCMEET YAW1F9 AC Remote Control User Manual for Gree Air Conditioners](#)

## AULCMEET YAW1F9

# AULCMEET YAW1F9 AC Remote Control User Manual

Model: YAW1F9 | Brand: AULCMEET

Compatible with Gree Air Conditioners: YAW1F1, YAW1F4, GWH24ACD-K3NNA1A

## 1. INTRODUCTION

This manual provides instructions for the AULCMEET YAW1F9 replacement AC remote control. This remote is designed to be compatible with various Gree Air Conditioner models, including YAW1F1, YAW1F4, and GWH24ACD-K3NNA1A. It offers direct functionality without the need for complex setup procedures.

## 2. SETUP AND BATTERY INSTALLATION

The AULCMEET YAW1F9 remote control requires two AAA 1.5V batteries for operation. No programming or pairing is needed; simply insert the batteries, and the remote is ready for use.

- Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Slide the cover downwards to open.
- Insert Batteries:** Insert two new AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
- Close the Battery Compartment:** Slide the battery cover back into place until it clicks securely.





Figure 1: Back of the remote control showing the battery compartment and battery specifications.

#### Important Battery Information:

- Battery type: AAA 1.5V x 2.
- Do not mix new and worn or different types of batteries.
- Do not dispose of batteries in fire; they may explode or leak.

### 3. OPERATING INSTRUCTIONS

The remote control features clearly labeled buttons for various functions. Point the remote control directly at the air conditioner's receiver when operating.



Figure 2: Front of the remote control with button layout.

#### Button Functions:

- **On/Off:** Powers the air conditioner on or off.
- **Fast Cool:** Activates a rapid cooling mode.
- **Mode:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Fan:** Adjusts fan speed.

- **Swing:** Controls the louver swing function.
- **Sleep:** Activates sleep mode for energy-efficient and quiet operation.
- **Timer:** Sets the timer for automatic on/off operations.
- **I Feel:** Activates the "I Feel" function, which senses the temperature at the remote's location.
- **Light:** Controls the display light on the air conditioner unit.
- **Wifi:** (If applicable) Activates or controls the Wi-Fi function of the air conditioner.
- **Temperature Up/Down (▲ / ▼):** Adjusts the desired temperature setting.

For specific functions and advanced settings, refer to your Gree Air Conditioner's original user manual.

## 4. MAINTENANCE

---

### Battery Replacement:

Replace batteries when the remote control's display becomes dim or the remote fails to operate the air conditioner. Always replace both batteries simultaneously with new AAA 1.5V batteries.

### Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

### Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

### Key Board Locking Feature:

To start or stop key board locking, long press the temperature Up (▲) and Down (▼) buttons simultaneously for 3 seconds.

## 5. TROUBLESHOOTING

---

### • Remote not responding:

- Check if the batteries are inserted correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Confirm the remote is pointed directly at the air conditioner.

### • Air conditioner not performing desired function:

- Verify that the correct operating mode (Cool, Heat, Fan, etc.) is selected on the remote.
- Check the temperature setting.
- Ensure the air conditioner unit is powered on and functioning correctly.

### • Keypad is locked:

- Long press the temperature Up (▲) and Down (▼) buttons simultaneously for 3 seconds to unlock the keypad.

## 6. SPECIFICATIONS

---

<b>Model</b>	YAW1F9
<b>Brand</b>	AULCMEET
<b>Compatible Devices</b>	Gree Air Conditioners (YAW1F1, YAW1F4, GWH24ACD-K3NNA1A)
<b>Connectivity Technology</b>	Infrared
<b>Power Source</b>	2 x AAA 1.5V Batteries (not included)
<b>Product Dimensions</b>	6.6 x 2 x 0.7 inches
<b>Item Weight</b>	2.6 ounces
<b>Special Feature</b>	Ergonomic design
<b>Max Number of Supported Devices</b>	1 (Direct replacement)

## 7. WARRANTY AND SUPPORT

This product is a replacement remote control. For warranty information or technical support, please refer to the policies of the original seller or contact the manufacturer, AULCMEET, directly. Keep your purchase receipt for any warranty claims.

For specific operational details of your Gree Air Conditioner, please consult the original manual provided with your air conditioning unit.