

Merax PP188015EAA

Merax Luggage Set User Manual

Model: PP188015EAA

INTRODUCTION

Thank you for choosing the Merax Luggage Set. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new luggage. Please read these instructions carefully to ensure optimal performance and longevity of your product.

PRODUCT FEATURES

- **Durable ABS Material:** Constructed from lightweight and robust ABS material, offering strong resistance to stress, high and low temperatures, and impact.
- **Reinforced Corner Guards:** Built-in reinforced corner guards provide additional protection and minimize damage.
- **Spacious Interior:** Large storage capacity with a fully lined interior and zippered compartments to keep your belongings organized.
- **Convenient Handles:** Features low-profile top and side handles for easy handling.
- **TSA-Approved Lock:** Integrated TSA-approved combination lock allows customs inspection without damaging the lock, enhancing security.
- **360° Spinner Wheels:** Multi-directional silent spinner wheels rotate 360 degrees for smooth maneuverability.
- **UV-Radiation Protection:** Protective anti-aging feature with built-in UV-radiation protection for long-lasting usage.

SETUP

Unpacking and Initial Inspection

Your Merax Luggage Set is designed to nest within each other for efficient storage. Carefully remove each piece from the packaging. Inspect all components for any signs of damage. If any part is damaged or missing, please contact customer support.

Setting the TSA Combination Lock

1. The initial combination is set to 0-0-0.

2. With the lock set to 0-0-0, push the reset button (a small button usually located next to the dials) with a pen or pointed object until you hear a click.
3. Set your desired 3-digit combination by turning the dials.
4. Push the tab or lever to the side (where you would normally open the lock) until you hear a click. This will set your new combination.
5. Test your new combination to ensure it works correctly before scrambling the dials.




Image: Close-up of the TSA combination lock on the Merax luggage.

Adjusting the Telescopic Handle

The telescopic handle can be adjusted to multiple heights for comfortable maneuvering. Press the button on top of the handle and pull up or push down to adjust. Release the button to lock the handle in place.



Image: Telescopic handle extended, highlighting its multi-step adjustment and durability testing.

OPERATING YOUR LUGGAGE

Using the Spinner Wheels

The Merax Luggage features multi-directional 360° spinner wheels. This allows for effortless gliding in any direction, reducing strain on your arm and shoulder. Push or pull the luggage from any side for smooth movement.



Image: Detailed view of the 360° spinner wheels and their features.

Packing and Interior Organization

Utilize the fully lined interior and zippered compartments to separate and organize your items. The garment straps help secure clothing and prevent shifting during transit.

- Spacious Interior
- Zippered Pocket
- Garment Strap



Image: Interior view of the luggage, demonstrating its organizational features.

Expanding Your Luggage (if applicable)

Some Merax luggage models feature an expandable zipper. To expand, simply unzip the expansion zipper located around the perimeter of the suitcase. This provides additional packing capacity.

+25% Expandable



Image: The luggage expanded, showing increased capacity.

MAINTENANCE

Cleaning

To clean the hard case exterior, wipe with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners or solvents that could damage the finish. For the interior, vacuum or wipe with a damp cloth as needed.

Wheel and Handle Care

Regularly check the spinner wheels for any debris or hair that might impede smooth movement. Clean as necessary. Ensure the telescopic handle extends and retracts smoothly. Do not force the handle if it gets stuck.

Storage

Store your luggage in a cool, dry place away from direct sunlight to preserve the UV-radiation protection and material integrity. The nested design allows for compact storage of the entire set.

TROUBLESHOOTING

- **Stuck Telescopic Handle:** Ensure the release button is fully depressed. Check for any obstructions in the handle mechanism. Do not apply excessive force.
- **Stiff Wheels:** Clean any debris from around the wheels. A small amount of silicone-based lubricant can be applied to the wheel axles if needed.

- **Lock Issues:** If you forget your combination, you may need to contact Merax customer support for assistance. Do not attempt to force the lock open as this may damage it.
- **Zipper Malfunction:** Ensure the zipper teeth are aligned. If a zipper is stuck, try applying a small amount of lubricant (like graphite from a pencil) to the teeth.

SPECIFICATIONS

Feature	Detail
Product Dimensions	20.47 x 12.6 x 30.71 inches
Item Weight	19.8 pounds (total for set) / 9 Kilograms
Department	Unisex
Manufacturer	Merax
Item Model Number	PP188015EAA




Image: Detailed size specifications for each luggage piece in the set.

PRODUCT OVERVIEW VIDEO

Video: An official overview of the Merax Luggage Sets, demonstrating key features and design.

WARRANTY AND SUPPORT

For any problems or inquiries regarding your Merax Luggage Set, please feel free to contact Merax customer support. Refer to your purchase documentation for specific warranty details and contact information.