

[Manuals.plus](#) /

> [AGARO](#) /

> AGARO HS1107 4-in-1 Hair Styler User Manual

## AGARO HS1107

# AGARO 4-in-1 Hair Styler

MODEL: HS1107

## Introduction

The AGARO HS1107 4-in-1 Hair Styler is a versatile hair styling tool designed to provide multiple styling options including straightening, crimping, curling, and brushing. This device features keratin-infused ceramic coated plates for smooth results and offers variable temperature settings to suit different hair types. Please read this manual thoroughly before use to ensure safe and effective operation.



Image: AGARO 4-in-1 Hair Styler Model HS1107, illustrating its capabilities for curling, crimping, straightening, and brushing hair.

## Safety Information

- Always ensure your hands are dry before plugging in or unplugging the appliance.
- Do not use this appliance near water, in a bathroom, or over a basin filled with water.
- Keep the appliance away from children.
- Unplug the appliance immediately after use and before cleaning.
- Allow the appliance to cool down completely before storing.
- Do not wrap the power cord around the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer or a qualified service agent to avoid a hazard.

## **Product Features**

---

- 4-in-1 Hair Styler: Functions as a straightener, crimper, curler, and brush.
- Keratin Infused Ceramic Coated Plates: Designed for a silky smooth finish and reduced hair damage.
- 3 Temperature Settings: 140°C, 170°C, and 200°C for various hair types.
- Styling Settings Button: Allows easy selection of the desired styling mode.
- Temperature Display: Provides clear indication of the selected heat setting.
- Hanging Loop: For convenient storage.
- 360° Swivel Power Cord: Prevents tangling during use.
- Cool Touch Tip: For safe handling during styling.



Image: Detailed view of the styler's controls and ergonomic features, including the styling mode button, hanging loop, swivel cord, and cool touch tip.

## Setup

1. Unpack the AGARO HS1107 Hair Styler and ensure all components are present and undamaged.
2. Remove any protective packaging or labels from the styling plates.
3. Place the styler on a heat-resistant, flat surface.
4. Plug the power cord into a suitable electrical outlet (220-240V~, 50/60Hz).

## Operating Instructions

Ensure your hair is clean, dry, and detangled before styling. For best results, apply a heat protectant spray.

1. **Power On:** Press and hold the power button until the temperature display illuminates.
2. **Select Styling Mode:** Push the styling settings button to cycle through the 4-in-1 functions: straightener, crimper, curler, or brush. The selected mode will be indicated.
3. **Adjust Temperature:** Use the '+' and '-' buttons to select your desired temperature (140°C, 170°C, or 200°C). Refer to the 'Temperature Settings' section for guidance.
4. **Heat Up:** Allow the styler to heat up to the selected temperature. The temperature display will show the

current temperature.

#### 5. Style Your Hair:

- **Straightener:** Clamp a section of hair between the plates and glide down slowly from roots to ends.
- **Crimper:** Clamp a section of hair between the crimping plates for a few seconds, then release and move to the next section.
- **Curler:** Wrap a section of hair around the curling barrel, hold for a few seconds, then release.
- **Brush:** Use the brush attachment to add volume or smooth hair while applying gentle heat.

6. **Power Off:** After styling, press and hold the power button until the display turns off. Unplug the appliance from the power outlet.

## 4 in 1 Hair Styler



Image: Demonstrations of the styler's four functions: curling, straightening, crimping, and brushing.



Image: Examples of hair curling and straightening using the AGARO HS1107 hair styler.



Image: Examples of hair crimping and volume brushing using the AGARO HS1107 hair styler.

## Temperature Settings

The AGARO HS1107 offers three distinct temperature settings to cater to different hair types and styling needs:

- **140°C:** Ideal for very thin or fine hair, minimizing heat exposure.
- **170°C:** Suitable for normal hair, providing effective styling without excessive heat.
- **200°C:** Recommended for very coarse or thick hair, ensuring efficient styling.



Image: Visual guide to the three temperature settings and their recommended hair types.

## Maintenance

---

1. Ensure the appliance is unplugged and completely cool before cleaning.
2. Wipe the styling plates and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
3. Ensure no moisture enters the appliance.
4. Store the styler in a dry, safe place, away from children. Use the hanging loop for convenient storage.

## Troubleshooting

---

- **Appliance not turning on:** Check if the power cord is securely plugged into a working outlet. Ensure the power button is pressed and held correctly.
- **Not heating up:** Verify that the temperature setting is selected. Allow sufficient time for the styler to reach the desired temperature.
- **Hair snagging:** Ensure hair is completely dry and detangled before use. Do not use on excessively large sections of hair.
- **Styling results are not satisfactory:** Adjust the temperature setting according to your hair type. Ensure

you are using the correct styling mode for your desired look.

## Specifications

<b>Model Number</b>	HS1107 (Item model number: 33873)
<b>Power Supply</b>	220-240V~, 50/60Hz
<b>Power Consumption</b>	58W
<b>Plate Material</b>	Keratin Infused Ceramic Coated
<b>Temperature Settings</b>	140°C / 170°C / 200°C
<b>Product Dimensions (LxWxH)</b>	32.5 x 4 x 5.5 cm
<b>Item Weight</b>	398 g
<b>Cord Type</b>	360° Swivel Power Cord



Image: Product dimension illustration, showing the styler's length.

## Product Overview Video

---

Watch this video for a quick overview of the AGARO 4-in-1 Hair Styler's features and functions.

Video: A brief preview demonstrating the AGARO 4-in-1 Hair Styler, highlighting its various styling capabilities and design.

## Warranty and Support

---

This AGARO HS1107 Hair Styler comes with a **2-year warranty** from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please contact AGARO customer service. Keep your purchase receipt as proof of purchase.