Vida Designs Denver Chest

Vida Designs Denver 4-Drawer Chest Instruction Manual

Model: Denver Chest (3331367) | Brand: Vida Designs

Introduction

This manual provides comprehensive instructions for the assembly, use, and maintenance of your Vida Designs Denver 4-Drawer Chest. Designed for efficient storage, this chest features four spacious drawers and a durable construction. Please read these instructions carefully before assembly and use to ensure proper setup and safe operation.



Image: The Vida Designs Denver 4-Drawer Chest, a light wood-finish chest with four drawers, positioned in a modern room next to a floor lamp and a mirror.



Image: A diagram illustrating key features of the chest, including a spacious top, premium materials, beveled drawer fronts, roomy drawers, and effortless glide mechanisms.

Safety Information

To prevent injury and ensure the stability of your furniture, please observe the following safety guidelines:

- Always assemble the chest on a soft, clean surface to prevent scratches.
- Ensure all screws and fittings are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not allow children to climb on the furniture.
- **Anti-Tip Kit:** An anti-tip kit is included to enhance home safety. It is crucial to secure the chest to a wall using the provided kit to prevent accidental tipping, especially in households with children.



Image: An illustration showing the correct method of securing furniture to a wall with an anti-tip kit (green checkmark) and a warning against children climbing on unsecured furniture (red crossmark).

Package Contents

Before beginning assembly, please verify that all components and hardware are present. Refer to the separate assembly instructions sheet for a detailed list of parts.

- Chest panels (top, bottom, sides, back)
- Drawer panels (fronts, sides, backs, bottoms)
- Drawer runners/slides
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip kit
- Assembly instruction manual

Setup and Assembly

The Vida Designs Denver 4-Drawer Chest is designed for straightforward assembly. Follow the step-by-step instructions provided in the separate assembly guide included in your package.

1. **Preparation:** Clear a spacious area and lay out all components on a soft, clean surface to prevent damage.
2. **Follow Instructions:** Refer to the detailed diagrams and instructions in the assembly manual. Ensure each step is completed correctly before proceeding.
3. **Secure Fittings:** Tighten all screws and fasteners firmly, but do not overtighten to avoid stripping the wood.
4. **Install Anti-Tip Kit:** Once the chest is fully assembled and in its final position, install the anti-tip kit as per its specific instructions. This is a critical safety step.

Operating and Use

Your Denver 4-Drawer Chest is designed for organized storage of various items. The drawers feature an effortless glide mechanism for smooth opening and closing.

- **Drawer Functionality:** Gently pull the drawer fronts to open and push to close. Avoid forcing drawers.
- **Weight Capacity:** Observe the maximum weight limits for safe use.



Image: A diagram illustrating the external dimensions of the chest (70cm W x 95.5cm H x 40cm D) and internal drawer dimensions (64.9cm W x 19cm H x 29.8cm D). It also shows weight capacities: 15kg per drawer, 10kg for the top panel, and 70kg total weight capacity.



Image: The chest with its drawers partially open, revealing neatly folded clothing items such as t-shirts, trousers, socks, and baby clothes, demonstrating the ample storage space.

Maintenance and Care

Proper care will help maintain the appearance and longevity of your chest.

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent moisture damage.
- **Heat and Moisture:** To prevent surface marks from hot or wet items, always use coasters or protective mats.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

Troubleshooting

If you encounter any issues with your chest, consider the following common solutions:

- **Drawers not closing smoothly:** Check if the drawer runners are correctly aligned and free from obstructions. Ensure all assembly screws are tightened.
- **Wobbling:** Verify that the chest is placed on a level surface. Re-tighten all assembly hardware. Ensure the anti-tip kit is properly installed.
- **Missing parts:** If any parts were missing upon delivery, contact customer support immediately.

Specifications

Brand	Vida Designs
Model Number	3331367
Product Name	Denver Chest
Color	Pine (Light Wood Finish)
Material	Engineered Wood, Pine Wood
Dimensions (L x W x H)	40 x 70 x 96 cm
Item Weight	21 Kilograms
Number of Drawers	4
Care Instructions	Wipe with a dry cloth
ASIN	B0BMM2VCRZ

Warranty and Support

For information regarding warranty coverage or to obtain support for your Vida Designs Denver 4-Drawer Chest, please refer to your purchase documentation or contact the retailer where the product was purchased. Spare parts availability information is not provided in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question