



Manuals+



[Manuals.plus](#) /

› [Andis](#) /

› Andis EasyClip Professional-Animal Clipper Kit User Manual

Andis 24820

Andis EasyClip Professional-Animal Clipper Kit User Manual

Model: 24820 | Brand: Andis

1. PRODUCT OVERVIEW

The Andis EasyClip Professional-Animal 7-Piece Detachable Ceramic Blade Clipper Kit is designed for efficient and quiet grooming of dogs, especially those with heavy coats. Its single-speed motor ensures a calm experience for pets, while the 12-foot power cord and detachable blade system offer convenience and versatility for achieving professional-looking grooms.

Key Features:

- **Powerful Single-Speed Motor:** Designed for quiet operation to keep pets calm during grooming.
- **Detachable Ceramic Blade System:** Allows for easy cleaning, maintenance, and quick blade changes.
- **Long Power Cord:** A 12-foot cord provides ample reach and flexibility during grooming sessions.
- **Durable Construction:** Built for professional use and longevity.
- **7-Piece Kit:** Includes the clipper, four attachment combs, blade oil, and a hard storage case.



Figure 1: The Andis EasyClip Professional-Animal Clipper.



Figure 2: Complete 7-piece kit with clipper, four attachment combs, blade oil, and hard storage case.



Figure 3: Key features of the Andis EasyClip Professional-Animal Clipper.

2. SAFETY INFORMATION

Always prioritize safety when using electric grooming tools. Read and understand all instructions before use. Keep the clipper away from water sources and do not use it on infants or humans. Ensure the blade guard is on when not in use. Regular cleaning and maintenance are crucial to prevent injury and ensure optimal performance.

- Always use the trimmer with the guard on the blade.
- Keep the trimmer away from water sources.
- Do not use on infants or humans.
- Clean and maintain the trimmer according to the manufacturer's instructions to prevent skin or eye injury.

3. SETUP

3.1 Unboxing and Initial Inspection

Upon receiving your Andis EasyClip Professional-Animal Clipper Kit, carefully open the packaging and remove all components. Verify that all items listed in the kit contents (clipper, 4 attachment combs, blade oil, and hard storage case) are present and undamaged. Inspect the clipper and blades for any visible defects or shipping damage.



Figure 4: Contents of the Andis EasyClip Professional-Animal Clipper Kit.

3.2 Attaching and Detaching Blades

The Andis EasyClip features a convenient detachable blade system for easy cleaning and swapping. To attach a blade, align the blade with the clipper head and push firmly until it clicks into place. To detach, simply push near the teeth of the blade and slide it off.

DETACHABLE BLADE SYSTEM

- Achieve the maximum amount of cut lengths by using different blade sizes
- Easy to clean and disinfect




Figure 5: Detaching the blade from the clipper.

3.3 Attaching Combs

The kit includes four attachment combs to achieve various hair lengths. Select the desired comb and slide it onto the clipper blade until it securely snaps into position. Ensure the comb is fully seated before beginning to groom.



Figure 6: Included attachment combs for varying hair lengths.

4. OPERATING INSTRUCTIONS

4.1 General Usage


Before grooming, ensure your pet's coat is clean, dry, and free of mats or tangles. Brush the coat thoroughly to remove loose hair and debris. Plug the clipper into a suitable power outlet. Turn the clipper on using the power switch. Hold the clipper firmly and move it smoothly through the pet's coat, following the direction of hair growth for a longer cut or against it for a shorter cut. Always use an appropriate attachment comb to prevent cutting too short or causing skin irritation.



Figure 7: Demonstrating the clipper in use on a dog.

4.2 Recommended Coat Types

This clipper is particularly effective for various coat types, from heavy and curly to light and fine. Refer to the guide below for specific breed recommendations.



THIS CLIPPER IS BEST FOR:

HEAVY/CURLY COAT BREEDS
Poodle, Pomeranian, Saint Bernard, Golden Retriever, German Shepherd, Bichon Frise, Doodle

MEDIUM COAT BREEDS
Cavalier King Charles Spaniel, Cairn Terrier, Miniature Schnauzer, West Highland White Terrier

LIGHT COAT BREEDS
Chinese Crested, Maltese, Yorkshire Terrier, Silky Terrier, Shih-tzu, Havanese, Lhasa Apso

Figure 8: Recommended coat types for the Andis EasyClip Clipper.

4.3 Grooming Tips

Understanding basic dog anatomy and sensitive areas is crucial for safe and effective grooming. Always wash, dry, and brush your pet before grooming for best results. This helps prevent blade dulling and ensures a smoother cut.




Figure 9: Grooming basics: Knowing sensitive areas of a dog's body.



Figure 10: Pro grooming tip: Always wash, dry, and brush before grooming.

4.4 Product Demonstration Video

Your browser does not support the video tag.

Video 1: Official demonstration of the Andis Easy Clip Groom Clipper in use.

5. MAINTENANCE

5.1 Cleaning the Blades

After each use, it is important to thoroughly clean the clipper blades to maintain performance and hygiene. Detach the blade from the clipper. Use a blade brush to remove any hair or debris from between the teeth. For deeper cleaning, you can use specialized blade cleaning solutions.




Figure 11: Example of Andis clipper blades.

5.2 Oiling the Blades

Regular oiling is essential for smooth operation and to prevent blades from overheating. Apply a few drops of Andis blade oil across the teeth of the blade and a drop at each inside rear corner. Turn the clipper on for about 10 seconds to distribute the oil. Wipe off any excess oil with a clean cloth.



Figure 12: Close-up view of the clipper blade, where oil should be applied.

5.3 Clipper Maintenance Video

Your browser does not support the video tag.

Video 2: Official guide on how to maintain your Andis clippers, including cleaning and oiling.

6. TROUBLESHOOTING

If you encounter any issues with your Andis EasyClip Professional-Animal Clipper, please refer to the common

troubleshooting tips below. For more detailed information or persistent problems, consult the full user manual.

- **Clipper not turning on:** Ensure the power cord is securely plugged into a working outlet. Check the power switch.
- **Blades pulling hair or cutting poorly:** Blades may be dull, dirty, or improperly oiled. Clean and oil the blades, or replace them if dull. Ensure the blade is correctly attached.
- **Clipper overheating:** This can be caused by prolonged use or insufficient oiling. Turn off the clipper, allow it to cool, and apply blade oil before resuming.
- **Excessive noise or vibration:** Ensure the blade is properly seated and secured. Regular maintenance, including oiling, can help reduce noise.

For comprehensive troubleshooting and repair information, please download the official [User Manual \(PDF\)](#).

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	7 x 2 x 1.5 inches
Item Weight	2.84 Pounds
Item Model Number	24820
UPC	040102248207
Manufacturer	Andis
Country of Origin	USA
Recommended Uses	Animal Clipper
Color	Purple
Hair Type Compatibility	All
Power Source	Corded Electric

8. WARRANTY AND SUPPORT

For detailed warranty information, product registration, and additional support, please visit the official Andis website or refer to the full user manual provided with your kit.

Official User Manual: [Download PDF](#)

Andis Brand Store: [Visit Store](#)



